

### Core Script

- TNT — Touch • Name • Tell safe
- PMS — Properly Mounted & Secured
- NLD — No Leaks or Damage
- CBB — Not Cracked, Bent, Broken
- ABC — Abrasions, Bulges, Cuts (hoses/tires)



### Engine Compartment

- Hoses/Lines: PMS, NLD, ABC
- Belts: Proper tension, no frays
- Fluids: Oil, Coolant, PS at level
- Leaks: None under engine



### In-Cab & Start

- Safe start: Neutral, PB set
- Gauges: Oil, Temp, Volts normal
- Horn/Wipers/Defroster work
- Emergency gear: Extinguisher • Triangles



### Air Brake Checks

- Applied & Leak tests — state specs
- Low-air warning & spring brake
- Service/Parking brake tests
- Verbalize PSI/time results



### Steering/Suspension

- Steering play within limits
- PMS: Pitman, drag link, tie rods
- Springs • U-bolts • Shocks: PMS, NLD



### Coupling

- Air/Electrical: PMS, NLD, ABC
- Fifth Wheel: Locked, no gap
- Platform/Mounting: PMS, no cracks
- Kingpin/Apron: Not bent/damaged



### Lights • Tires • Rims

- Lights/Reflectors: Clean, proper color
- Tires: Even wear, proper PSI
- Rims: No cracks/illegal welds
- Lugs: Present, no rust trails



### Trailer & Rear

- Side/Rear: Secure, DOT tape
- Landing gear up • doors secure
- Splash guards present
- Brakes/Drums/Linings: PMS

