



If your stairs are not plumb and level, rise and run measurements by themselves, will not give you an accurate stair angle. Use a level to find out how level your stairs are.