



USER GUIDE

CONFERENCE CALLING



Cloud Telematics




Initiate a Conference Call:

Assuming that you are already in a conversation and wish to bring a third party together in a 3-way conference.

- 1) Press conference button to bring up conference dialing screen.



- 2) Dial the third party number followed by SEND key.
- 3) When the call is established to the third party, press the "ConfCall" soft key to initiate 3-way conference.




Cancel a Conference Call:

- 1) Press "Kick" soft key in conference dialing screen to resume the two-way conversation.



Hold The Conference:

- 1) Press hold button to hold the conference call with all parties are on hold;
- 2) Press "ReConf" soft key to resume conference call; or select the corresponding blinking LINE to speak with an individual party.



End The Conference:

The conference will be terminated for all three parties if the conference initiator hangs up or presses "EndCall" soft key.