



THE VILLAGE
1228 Nepean Hwy, Cheltenham

USER MANUAL

Intercoms & Access Control



Prepared by

EPSILON SECURITY

47 Levanswell Rd

MOORABBIN

Tel: 03 9553 6888

Fax: 03 9553 6887

salesvic@epsilonsecurity.com.au

Section 1

Contacts

- 1.1 Installer & Emergency Service

Section 2

Intercoms

- 2.1 Intercom User Manual
- 2.2 Miro Monitor User Instructions
- 2.3 Call Stations User Instructions

Section 3

Access Control

- 3.1 Access Control User Manual

SECTION 1 CONTACTS

1.1 Service & Emergency Contact

Epsilon Security Service Department

47 Levanswell Rd

Moorabbin, Vic, 3189

Phone: 03 9553 6888

Email: servicevic@epsilonsecurity.com.au

NB. After hours service callout may attract after hour's service & callout rates unless otherwise prior arrangement

SECTION 2 INTERCOMS

3.1 Intercom User Manual

1. When a visitor calls a resident on the intercom system, they call the apartment number by using the keypad and the bell symbol on the bottom right end side of the panel.



2. The video monitor inside the called unit sounds an electronic tone and the resident can answer using the handset. Colour vision of the calling entry is displayed and two-way communication takes place between the video monitor handset and the hands-free external entry station.



EPSILON

SECURITY




3. If the caller is to be admitted, the resident presses the video monitor button with the key symbol, and the door/gate will be released

4. If lift control is present, the key button also enables the lift function.



5. The resident replaces the handset securely in the cradle provided on the video monitor. The video links will automatically time out.


3.2 Miro Monitor User Instructions



1. Door opener button
2. Green LED located under door opener button
3. 4. 5. Button
6. Two-coloured LED
7. Terminals for system connection
8. Configuration dip-switch
9. Pre-set for in/out connection with accessory Sch. 1750/50
10. Brightness
11. Colour
12. Screws to fasten video door phone to the supplied metal bracket.

3.3 Call Station User Instructions

I. Digital Door Station – ELEKTA BLACK – 1083/15



The Intercom System is very easy to use. Visitors are to call from the video call stations by pressing the unit number and "BELL" and the call will be forwarded to the Internal apartment.

SECTION 4 ACCESS CONTROL

4.1 Access Control User Manual

1. Entry to the complex is gained by valid RF/proximity combined tag.



2. To enter at a point controlled by proximity reader present the proximity tag to the proximity reader at a distance nominally less than 5 cm.



3. The proximity reader at rest has a constantly illuminated red LED, when presented with a valid tag the LED color will change to green alerting the user that access has been authorized.



4. The latching mechanism will be open for a pre set time allowing entry.
5. Access to car park is by RF remote control. RF/proximity combined tags that are valid allow access at proximity readers and also at RF receiver points.
6. In order to use the tag for remote control switching of car park entry grille, on approach to the grille at a distance nominally 25 meters or less, depress the left button of the RF/proximity tag once. This action will cause the grille to open for a pre set period and then close after the vehicle has passed through the entry.

Prepared & installed by

Epsilon Security

47 Levanswell Road

Moorabbin

Tel: 03 9553 6888

Fax: 03 9553 6887

salevic@epsilonsecurity.com.au

www.epsilonsecurity.com.au