

# **KIT MAPS MANUAL**

**THE DEVICE OFFERS A SET OF 5 PERFORMANCE MODES, STORM, EASY-RIDER, ROAD, FREEDOM AND ANARCHY.**

**THERE IS ALSO 5 DIFFERENT ENGINE MAPPING OPTIONS (A B C D E) FOR THIS GROUP OF MODES.**

**Map A is the default setting for the device and is the most suitable for motorcycles with 107-114-117 engine or stage 1.**

**Maps B C D E may be necessary for motorcycles with the 103-110 engine or with non-original engine stage 2, stage 3, stage 4, kits or with ECM already modified with non-original devices.**

**These map options decrease accelerator response slightly so that B is less responsive than A, C less responsive than B and so on.**

**The device will be delivered with the default group A. To switch to another map follow the instructions below.**

**(When you receive the device is ready for installation and does not require any settings)**

# **KIT MAPS MANUAL**

**Instructions for changing the maps**

# Position A anarchy



## MAP A (Default)

- **Position the SALVAHD R-BY-W switch in position A (Anarchy)**
    - **Twist accelerator to full throttle**
  - **Turn the key and injection button ON (engine off)**
    - **Wait 15 seconds**
  - **Position key and injection button OFF**
- Map A is ready**

# Position B freedom



## MAP B (Default)

- Position the SALVAHD R-BY-W switch in position B (freedom)
    - Twist accelerator to full throttle
  - Turn the key and injection button ON (engine off)
    - Wait 15 seconds
  - Position key and injection button OFF
- Map B is ready**

# Position C road



## MAP C (Default)

- **Position the SALVAHD R-BY-W switch in position C (road)**
    - **Twist accelerator to full throttle**
  - **Turn the key and injection button ON (engine off)**
    - **Wait 15 seconds**
  - **Position key and injection button OFF**
- Map C is ready**

# Position D easy rider



## MAP D (Default)

- Position the SALVAHD R-BY-W switch in position D (easy rider)
    - Twist accelerator to full throttle
  - Turn the key and injection button ON (engine off)
    - Wait 15 seconds
  - Position key and injection button OFF
- Map D is ready**

# Position E storm



## MAP E (Default)

- **Position the SALVAHD R-BY-W switch in position E (storm)**
    - **Twist accelerator to full throttle**
  - **Turn the key and injection button ON (engine off)**
    - **Wait 15 seconds**
  - **Position key and injection button OFF**
- Map E is ready**