

BR TRIGGER

WARNING

ATTENTION! Always check that the weapon is unloaded!

It is advisable to contact experienced and prepared personnel to carry out the assembly. Your life is important to us and could be seriously compromised if you do not have this trigger properly installed. The company SIDHE declines all responsibility in the event of incorrect assembly.

ATTENTION! Always check that the weapon is unloaded!

ATTENTION! DO NOT lubricate the trigger!

ATTENTION! Always make sure that the trigger is dry, clean and in a position to operate safely!

The installation procedure alone can be a very dangerous activity if you do not ensure that the weapon you are working on is not unloaded first. When unloading ensure that the muzzle of the gun is pointed in a safe direction.

ATTENTION:

The adjustment of the trigger's system can only be changed by expert and authorized personnel. The company SIDHE declines all responsibility in the event of tampering, modification, incorrect assembly, calibration beyond the limits. The safety of the trigger system must be verified before each use.

Trigger is not calibrated because it will be set in operation according to the requirements and characteristics of the rifle on which it will be mounted.

We recommend using on grub screw (1-2-3) LOCTITE 222 or similar and leave to dry for minimum 24 hours before setting them.

1: Adjustment grub screw for sear engagement

2: Adjustment grub screw for pull force

3: Adjustment grub screw for overtravel

We recommend: it is advisable to calibrate to bring pull force to the minimum set sear engagement desired. Verify mechanism that is safe then eventually increase pull force.

