

## ATLAS PARKAS SIZING CHART

## **PARKAS SIZING**

Inches

| Sizes | Matching Coverall Sizes | Chest | Weight  |
|-------|-------------------------|-------|---------|
| xs    | 36-38                   | 36-38 | 150-160 |
| S     | 40-42                   | 40-42 | 170-180 |
| М     | 44-46                   | 44-46 | 190-200 |
| L     | 48-50                   | 48-50 | 210-220 |
| XL    | 52-54                   | 52-54 | 230-240 |
| 2XL   | 56-58                   | 56-58 | 250-260 |
| 3XL   | 60-62                   | 60-62 | 270-280 |
| 4XL   | 64-66                   | 64-66 | 290-300 |

Chest Stand natually, Measure full circumference under your arms.

Waist Stand natually, remove your belt, measure the full circumference at natual waist, just above hip bones.

Please remember that this sizing guide is just a guide and that every persons body shape varies, so fit may vary from person to person.

## Atlas Workwear Ltd.

4727 101 Steet Edmonton, AB T6E 5C6

TF: 1(866) 688-5878
Tel: 1(780) 249-5878
Info@atlasworkwear.ca

