

**MDA/Android** – How to Download the Mandatory Magnus App, Use Your Install Code and Log In (All Android devices including phones and tablets)

1. Go to the Google Play Store and search MAGNUS DRIVER.

2. Click the INSTALL button on the MAGNUS DRIVER APP by MAGNUS TECHNOLOGY

GROUP.




3. Once the app has downloaded, click **OPEN** or open the app from your home screen.



4. A pop-up will ask if you **ALLOW "MAGNUS DRIVER"** to access this device's **LOCATION? ALL** drivers **MUST** click **"ALLOW ONLY WHILE USING THE APP"**. This is required for the app to work properly.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT




JAN. 2024\_CG


1 of 2



5. On the **INSTALL CODE** screen, enter the install code **234878** and click **REGISTER**.



- 6. Next you will enter your **DRIVER ID** and **PASSWORD**. These are the same numbers.
- 7. Click the **LOGIN** button.



8. The next pop-up will notify you that "MAGNUS DRIVER" would like to send you NOTIFICATIONS. Click <u>ALLOW</u>. This will ensure that you are notified of any new or updated loads.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT



JAN. 2024\_CG 2 of 2




MDA/iOS – How to Download the Mandatory Magnus App, Use Your Install Code and Log In (All iOS devices including iPhones and iPads)

- 1. Go to the App Store and search MAGNUS DRIVER.
- 2. Click the GET button on the MAGNUS DRIVER APP by VTV Solutions, then click INSTALL.






- 3. Once the app has downloaded, click **OPEN** or open the app from your home screen.
- 4. On the **INSTALL CODE** screen, enter the install code **234878** and click **REGISTER**.



5. Next you will enter your **DRIVER ID** and **PASSWORD**. These are the same numbers.

6. Click the LOGIN button.



JAN. 2024\_CG 1 of 2



7. A pop-up will ask if you ALLOW 'MAGNUS DRIVER" to access your location. <u>ALL</u> drivers MUST click "ALLOW WHILE USING APP". This is required for the app to work properly.

THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT



8. The next pop-up will notify you that "MAGNUS DRIVER" would like to send you NOTIFICATIONS Click ALLOW. This will ensure that you are notified of any new or updated loads.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT



9. The final pop-up will notify you that "MAGNUS DRIVER" would like to access your MOTION & FITNESS ACTIVITY. Click OK. This is required to provide location updates for loads.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT



JAN. 2024\_CG 2 of 2



### MDA – FINISHED VEHICLE LOADING


- FINDING YOUR LOADS
- VIEWING YOUR LOADS
- LOADING VEHICLES
  - LOADING OPTIONS
  - EDITING A LOADED VEHICLE
- SUBMITTING A LOADED LOAD

### **FINDING YOUR LOADS**

You can find your assigned loads under MENU>LOADS.

1. When you have new or updated loads there will be a red dot indicator on the menu icon, as well as a red number indicator on the **LOADS** menu option. Click "**LOADS**" to see your loads.





- 2. If there are no loads listed on the screen, pull down to refresh or click **REFRESH** in the top right corner.
- 3. Click on **SELECT WITH VIN SCAN** to find a load by scanning a VIN. You can also scroll to find the load you need. \*\* If you cannot find the load that you are looking for, contact DISPATCH to have them RESEND the load to your device. Make sure that you are **ONLY LOGGED IN TO ONE** (1) **DEVICE PRIOR TO DOING THIS.**

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT

NOTE: First time users will receive a pop-up window asking permission for "MAGNUS DRIVER" access to their CAMERA. This access is required to scan, take photos of vehicles, accessories, damages and more.


#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT

- 4. New loads will be marked as New.
- 5. Updated loads will be marked as **Updated**.

JAN. 2024\_CG 1 of 18




- 6. If configured, you will see your DRIVER ESTIMATED PAY (DEP) on this screen.
- 7. Click on a load to view the load details.



- 8. If enabled by the dispatch company, you may be asked to **ACCEPT** or **DECLINE** the load before proceeding. These loads will be marked as "**ACTION REQUIRED**" on the **LOADS** page.
  - If you ACCEPT the load, you will be able to proceed with loading.
  - If you **DECLINE** the load, you will not be able to proceed with loading.







JAN. 2024\_CG 2 of 18




### **VIEWING YOUR LOADS**

- 1. Click on a load. You can also pull up a load by using VIN SCAN (step 3 on the previous page).
- 2. 2. Click on the load details to bring up options for this load.





- Click NAVIGATE TO... for directions to the origin location. This will open your device's map application.
- 4. Click the PHONE NUMBER to call the origin location.
- 5. Click SHOW NOTES to show any notes for the origin location. THIS IS VERY IMPORTANT!
- 6. Click **SCHEDULED PICKUP** to change the scheduled pickup/delivery time/date.
- 7. Click **CANCEL** to close this window and go back to the load details.
- 8. Click **LOAD** to start the loading process.
- 9. Click **DELETE** to delete this load. If you delete a load by accident, you will need to contact **DISPATCH** to have them resend it to your device.



JAN. 2024\_CG 3 of 18




### **LOADING VEHICLES**


- 1. Select LOAD from the LOAD SUMMARY screen (see previous page).
- 2. On the **CLIENT SUMMARY** screen, if configured, you can use the top menu to send the dispatch company notification that you have **ARRIVED** at the origin location.
- 3. Click the **BARCODE SCANNER** icon to scan VINs to load vehicles, if preferred. Alternatively, you can also click on each vehicle to load the (step 7 below).
- 4. Click the CAMERA icon to take PHOTOS of the VEHICLES at the ORIGIN location.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT

- 1. Click the **REFRESH** icon to fetch load updates.
- 2. Click the QUESTION MARK icon to open a legend for the icons.



7. Click on a vehicle to being up the loading options.



JAN. 2024\_CG 4 of 18




### **LOADING OPTIONS**


- 1. Click on LOAD select this option to load a vehicle.
- 2. Enter the **POSITION** of the vehicle on the truck.
- 3. Select the **DIRECTION** of the vehicle on the truck.
- 4. Click SAVE and ADD DAMAGE to add damages to the vehicle (see Step 9 below).

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT


NOTE: ALL DRIVERS MUST READ AND FOLLOW ALL YARD/ORIGIN INSTRUCTIONS EXACTLY. IF RULES ARE NOT FOLLOWED EXACTLY, YOU RISK BEING HELD LIABLE FOR A DAMAGE CLAIM.


5. Click **SAVE** to load this vehicle **WITHOUT** damages being entered.





- 6. Mark UNLOADABLE select this option to mark a vehicle if it is UNLOADABLE.
- 7. Select a reason this vehicle is unloadable.
- 8. Click SUBMIT.





JAN. 2024\_CG 5 of 18




- 9. Click **DAMAGE** select this option to add **DAMAGE** to a vehicle.
- 10. Click ADD or PRESS HERE TO ADD ONE to add a damage.
- 11. Select the AREA of damage.
- 12. Select the **TYPE** of damage.
- 13. Select the **SEVERITY** of the damage.

#### AIAG DAMAGE CODES MUST BE USED TO NOTE ALL DAMAGES.

- 14. Enter or select a **COMMENT**, if needed.
- 15. **ADD PHOTOS** even if there are no visible damages. This shows the condition of the vehicle at the time prior to loading.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT

- 16. Click SAVE to save the damage to the vehicle.
- 17. **REPEAT STEPS 10-16** to add **ADDITIONAL** damages to the same vehicle.




18. **PHOTOS** – select this option to add **GENERAL PHOTOS** of a vehicle.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT

- 19. Click on a CATEGORY to add a photo for that category.
- 20. REPEAT STEP 19 for ALL PHOTOS needed.





JAN. 2024\_CG 6 of 18



21. CAMERA – select this option to take any ADDITIONAL PHOTOS that are not related to


damage or the vehicle.



- 22. **EDIT** select this option to edit the vehicle details.
- 23. Edit the necessary vehicle information. VIN numbers may or may not be editable.


#### IF THERE IS A DISCREPANCY WITH THE FULL VIN - CALL DISPATCH IMMEDIATELY


24. Click SAVE to save any changes you make.





25. **INFO** – select this option to view **IMPORTANT INFO** for this load, including **PICKUP** or **DELIVERY INSTRUCTIONS**. An **ORANGE TRIANGLE** will indicate there is info here that **MUST** be looked at and followed.







26. CANCEL – select this option to close this menu and go back to the CLIENT SUMMARY


screen.



### **EDITING A LOADED VEHICLE**

- 1. Click on a loaded vehicle.
- 2. Click EDIT POS/DIR to edit the position and/or direction of the vehicle on the truck.
- 3. Click "RESET to NOT LOADED" to "UNLOAD" this vehicle in the app.








### SUBMITTING A LOADED LOAD


- 1. Vehicles will be marked as loaded on the **CLIENT SUMMARY** screen.
- Once all vehicles are loaded, the load status will change to LOADED/UNSENT.
- All DAMAGES that have been recorded will also be noted on the CLIENT SUMMARY screen.


#### VERIFY THAT ALL PRE-NOTED DAMAGES ARE SHOWING

4. Once all vehicles have been loaded, click the **SUBMIT** button.



- 5. Make sure to CONFIRM that the Pre-Confirmation screen looks CORRECT, then click SUBMIT.
- The load status will be updated to LOADED/SENT.
- 7. If you notified **DISPATCH** of your arrival at the origin, you can now notify them that you are departing.





JAN. 2024\_CG 9 of 18




### MDA – FINISHED VEHICLE DELIVERY

### **DELIVERING YOUR LOADS**

Once your load has a status of **LOADED/SENT** on the **LOADS** screen, you will be able to find it on the **DELIVERIES** screen.

1. Click **DELIVERIES** to view your loads that are ready to be delivered.



- Loads that have NOT been DELIVERED will be marked as LOADED/UNSENT on the DELIVERIES screen.
- 3. Loads that are COD will be indicated here.
- 4. Click on the **DELIVERY ESTIMATE DATE/TIME** to change it. If the **DATE/TIME** has passed, it will be highlighted in **RED**.
- 5. Click **SAVE** to save any changes you make.





6. Click on the **LOAD DETAILS** to bring up options for this load.



JAN. 2024\_CG 10 of 18




### **DELIVERING VEHICLES**

- 1. Select **DELIVER** from the **DELIVERIES** screen (see previous page).
- 2. If this is a COD load, then you will be taken to the COLLECT COD screen.
- 3. Enter the **AMOUNT COLLECTED** by you.
- 4. Choose where it was paid by CASH or CHECK.
- 5. If paid by CHECK, enter the CHECK NUMBER.
- 6. Click COLLECT. Click OK to confirm that the COD has been collected.
- 7. Alternatively, you can click the **PREVIOUSLY PAID** button if the COD amount was previously paid. Click **OK** to confirm this on the pop-up.



- 8. On the **CLIENT SUMMARY** screen, you can use the top menu to send **DISPATCH** notifications that you have **ARRIVED** at the destination. Confirm by clicking **OK** on the subsequent pop-up.
- 9. Click on the **BARCODE SCANNER** icon to deliver vehicles by scanning VINs, if preferred, or you can click on each vehicle to delivery them.
- 10. Click on the CAMERA icon to take photos of the destination location if desired.
- 11. Click the **REFRESH** icon to fetch load updates.
- 12. Click the QUESTION MARK ? icon to open a legend for the icons.




JAN. 2024\_CG 11 of 18




### **DELIVERY OPTIONS**


1. If there are **NO DAMAGES** to be recorded at delivery, click **DELIVER ALL UNITS** to delivery all vehicles at once. Click OK to confirm delivering all vehicles.

IT IS REQUIRED THAT ALL DAMAGES ENTERED AT THE ORIGIN <u>MUST</u> BE ALSO ENTERED AT DELIVERY.



- 2. Click on a vehicle to bring up the delivery options.
- 3. Select **DELIVER** to delivery a vehicle.





Select DAMAGE to ADD DAMAGE to a vehicle.

IT IS REQUIRED THAT ALL DAMAGES ENTERED AT THE ORIGIN <u>MUST</u> BE ALSO ENTERED AT DELIVERY.

- 5. Click ADD or PRESS HERE TO ADD ONE to add a damage.
- 6. Select the **AREA** of damage.
- 7. Select the **TYPE** of damage.
- 8. Select the **SEVERITY** of the damage.

AIAG DAMAGE CODES MUST BE USED TO NOTE ALL DAMAGES.


9. Enter or select a **COMMENT** if needed.





10. Add PHOTOS for all vehicles regardless if there is damage or not.

#### THIS IS REQUIRED BY PROFICIENT AUTO TRANSPORT


- 11. Click **SAVE** to save the damage to the vehicle.
- 12. **REPEAT STEPS 5-11** to add **ADDITIONAL DAMAGES** to the **SAME** vehicle.








- 13. Select **PHOTOS** to add general photos of a vehicle.
- 14. Click on a CATEGORY to add a PHOTO for that CATEGORY.
- 15. REPEAT STEP 14 for ALL photos needed.





16. Select CAMERA to take any additional photos that are not related to damage or the vehicle.





JAN. 2024\_CG

13 of 18



17. **INFO** – select this option to view **IMPORTANT INFO** for this load, including **PICKUP** or **DELIVERY INSTRUCTIONS**. An **ORANGE TRIANGLE** will indicate there is info here that **MUST** be looked at and followed.






18. CANCEL – select this option to close this menu and go back to the CLIENT SUMMARY


screen.



### **EDITING A DELIVERED VEHICLE**

- 1. Click on a delivered vehicle.
- 2. Click "RESET to LOADED" to "UNDELIVER" this vehicle in the app. Confirm by clicking OK on the subsequent pop-up.








#### SUBMITTING A DELIVERED LOAD

- 1. Vehicles will be marked as **DELIVERED** on the **CLIENT SUMMARY** screen.
- 2. Once all vehicles are delivered, the load status will change to DELIVERED/UNSENT.
- 3. Any damages that have been recorded will also be noted on the CLIENT SUMMARY screen.

#### VERIFY THAT ALL PRE-NOTED DAMAGES ARE SHOWING

4. Once all vehicles have been delivered, click the **SUBMIT** button.



- 5. If you have noted **DAMAGES DURING DELIVERY**, you will be prompted to **ACCEPT** or **DISPUTE** the damages.
- 6. If you AGREE with the damages as noted, click ACCEPT.
- 7. To ACCEPT ALL DAMAGES noted, click ACCEPT ALL DAMAGES.



NOTE: If you enter **DAMAGES** on a vehicle that WERE NOT PRE-NOTED at the origin **PRIOR TO PICKUP**, YOU MAY BE HELD LIABLE FOR THESE **DAMAGES** and any **DAMAGE CLAIM SUBMITTED**.

Also, if you enter **DAMAGES** on a vehicle that are **NOT THE SAME** as the **DAMAGES** that you entered at **PICKUP**, **YOU MAY BE HELD LIABLE FOR THESE DAMAGES** and any **DAMAGE CLAIM SUBMITTED**.



8. If you DO NOT AGREE with the damages as noted, click DISPUTE.

IF THERE ARE ANY ISSUES AT DELIVERY, CALL **DISPATCH** (904) 802-0575 or **COMPLIANCE** (904) 459-2892 **IMMEDIATELY** TO REPORT IT.

- 9. Make changes as needed on the ALTERNATE DAMAGE screen.
- 10. Click **SAVE** to save your alternate damage.
- 11. When you are done with **DAMAGES**, click **NEXT**.








- 12. Start completing the CLIENT REPORT by entering the RECEIVING PERSON'S NAME.
- 13. Select whether the load is **STI** (Subject to Inspection). This means that there is **NOBODY AVAILABLE** to conduct a **JOINT INSPECTION** of the vehicle to **CONFIRM** the **CONDITION** of the vehicle at delivery.
- 14. If the receiver has **REFUSED TO SIGN**, click the "**RECEIVER REFUSES TO SIGN**" checkbox. If this is checked, the **RECEIVER SIGNATURE** will not be required.

NOTE: If there is NOBODY AVAILABLE to sign or if they have REFUSED TO SIGN for a vehicle, DO NOT PRINT or WRITE A NAME IN THE "RECEIVER SIGNATURE" BOX.

This is considered submitting **FRAUDULENT DOCUMENTATION** which could result not only in a potential **DAMAGE CLAIM**, but it is a **DIRECT VIOLATION OF YOUR SIGNED BROKER AGREEMENT WITH PROFICIENT AUTO TRANSPORT.** 






- 15. If the receiver HAS NOT REFUSED, obtain the RECEIVER SIGNATURE. Click anywhere in the RECEIVER SIGNATURE area to open the SIGNATURE screen.
- 16. Have the RECEIVER use their finger to sign their name in the SIGN HERE box.
- 17. Click **CLEAR** if you need to redo the signature.
- 18. Click **SIGN** when done.

NOTE: AGAIN ~ If there is NOBODY AVAILABLE to sign or if they have REFUSED TO SIGN for a vehicle, DO NOT PRINT or WRITE A NAME IN THE "RECEIVER SIGNATURE" BOX.


This is considered submitting **FRAUDULENT DOCUMENTATION** which could result not only in a potential **DAMAGE CLAIM**, but it is a **DIRECT VIOLATION OF YOUR SIGNED BROKER AGREEMENT WITH PROFICIENT AUTO TRANSPORT.** 

THIS WILL DIRECTLY AFFECT YOUR DISPATCH STATUS AND MAY RESULT IN NOT ONLY BEING PERMANENTLY REVOKED FROM WORKING WITH PROFICIENT AUTO TRANSPORT,

YOU ALSO RUN THE RISK OF BEING <u>REPORTED</u> TO BOTH THE <u>DOT</u> (DEPT. of TRANSPORTATION) AND THE <u>FMCSA</u> (FEDERAL MOTOR CARRIER SAFETY ADMINISTRATION).









- 19. Follow the same process to obtain your signature for **DRIVER SIGNATURE**.
- 20. If there are any one-time email(s) you would like to send **PROOF OF DELIVERY** to, enter them here.
- 21. Click SUBMIT.
- 22. The load status will be updated to DELIVERED/SENT.
- 23. If you notified **DISPATCH** of your arrival at the destination, you can now notify that that you are departing. Confirm by clicking **OK** on the subsequent pop-up.





### PROFICIENT AUTO TRANSPORT CONTACT INFORMATION

MAIN OFFICE (904) 772-1175 / (888) 928-0312

DISPATCH (904) 802-0575 <u>BrokerDispatch@proautotran.com</u>

ACCOUNTS PAYABLE EXT. 450 CarriersAP@proautotran.com

CLAIMS EXT. 469 / EXT. 476 BrokerageClaims@proautotran.com

COMPLIANCE (904) 459-2892 / EXT. 903 Compliance@proautotran.com

10057 103<sup>rd</sup> Street Jacksonville, FL 32210

www.proficientautotransport.com

JAN. 2024\_CG 18 of 18

### AIAG >

#### **DAMAGE AREA CODES** (1st AND 2nd DIGITS)

05/23

www.aiag.org

-	ANTENIA (ANTENIA DAGE	50	DIGIT FROMT INTERIOR TRIAL PANEL
1	ANTENNA/ANTENNA BASE	50	RIGHT FRONT INTERIOR TRIM PANEL
2	BATTERY, SMALL, LOW VOLTAGE (IF	51	TONNEAU COVER
•	HIGH VOLTAGE USE CODE 49)	52	DECK LID/TAILGATE/HATCHBACK
3	BUMPER/COVER/EXTERIOR-FRONT	53	SUNROOF/GLASSROOF
4	BUMPER/COVER/EXTERIOR-REAR	54	UNDERCARRIAGE-OTHER
5	BUMPER GUARD/STRIP-FRONT	55	CARGO AREA-OTHER
6	BUMPER GUARD/STRIP-REAR	56	CONVERTIBLE TOP
7	DOOR-BACK CARGO-RIGHT	57	WHEEL COVERS/CAPS
8	DOOR-BACK CARGO-LEFT	58	OPEN
9	DOOR,-CARGO (SLIDING) R/L	59	WIPERS, ALL
10	DOOR-LEFT FRONT DOOR-LEFT REAR	60	JUMPED CHOCK
		61 62	BOX INTERIOR, PICK-UP TRUCK
12	DOOR RICHT REAR		ENTIRE VEHICLE
13 14	DOOR-RIGHT REAR FENDER-LEFT FRONT	63 64	RAILS, TRUCK BED/LIGHTBAR DEFLECTOR/SPOILER, REAR
15	QTR PANEL/PICK-UP BOX-LEFT	65	LUGGAGE RACK/STRIPS/DRIP RAIL
16			DASH/INSTRUMENT PANEL
17	FENDER-RIGHT FRONT	66	OPEN
	QTR PANEL/PICK-UP BOX-RIGHT	67	
18	FLOOR MATS-FRONT	68	CARPET-FRONT
19 20	FLOOR MATS-REAR	69 70	CENTER POST LEFT
	GLASS WINDSHIELD	70 71	CENTER POST LEFT
21 22	GLASS REAR GRILLE	72	CORNER POST / PILLAR, REAR, LEFT LEFT FRONT TIRE
23	THROW-INS/LOOSE ITEMS	73	LEFT FRONT WHEEL/RIM
23		74	LEFT REAR TIRE
	(ACCESSORIES, CIGARETTE	75	LEFT REAR WHEEL/RIM
	LIGHTER, HEADPHONES, CORDS,	76	RIGHT REAR TIRE
24	MULTIMEDIA KIT) HEADLIGHT/COVER/TURN SIGNAL	77	RIGHT REAR WHEEL/RIM
25	LAMPS-FOG/DRIVING/SPOT LIGHT	78	RIGHT FRONT TIRE
26	HEADLINER	79	RIGHT FRONT WHEEL/RIM
27	HOOD	80	COWL
28	KEYS	81	GAS/BATTERY DOOR/FUEL CAP
29	KEYLESS REMOTE	82	FENDER-REAR LEFT
30	MIRROR-OUTSIDE LEFT	83	FENDER-REAR RIGHT
31	MIRROR-OUTSIDE RIGHT	84	TOOLS/JACKS/SPARE-TIRE MOUNT &
32	MAJOR DAMAGE (OEM USE ONLY)	04	LOCK
33	FRONT MULTI-MEDIA AND/OR SPEAKERS	85	IMPROPER CHOCK SECUREMENT
34	REAR MULTI-MEDIA AND/OR SPEAKERS	00	AND/OR VEHICLE SPACING. DO NOT
35	ROCKER PANEL/OUTER SILL-LEFT		TRANSMIT THIS CODE.
36	ROCKER PANEL/OUTER SILL-RIGHT	86	PARKING SONAR SYSTEM
37	ROOF	87	A-PILLAR/CORNER POST, FRONT, LEFT
38	RUNNING BOARD/STEP-LEFT	88	A-PILLAR/CORNER POST, FRONT, RIGHT
39	RUNNING BOARD/STEP-RIGHT	89	TRAILER HITCH, WIRING HARNESS,
40	SPARE TIRE	00	TOW HOOKS
41	CHARGING CABLE FOR BATTERY	90	FRAME
• • •	ELECTRIC VEHICLE (BEV)	91	EXHAUST SYSTEM
42	SPLASH PANEL/SPOILER-FRONT	92	LICENSE PLATE BRACKET
43	OPEN	93	STEERING WHEEL/AIRBAG
44	GAS TANK	94	SEAT-FRONT LEFT
45	TAIL LIGHT/HARDWARE	95	SEAT-FRONT RIGHT
46	TRUCK CAB, REAR	96	SEAT-REAR
47	CORNER POST/PILLAR, REAR, RIGHT	97	CARPET-REAR
48	LEFT FRONT INTERIOR TRIM PANEL	98	INTERIOR
49	BATTERY, LARGE, HIGH VOLTAGE	99	ENGINE COMPARTMENT-OTHER

### AIAG >

#### **DAMAGE TYPE CODES** (3rd AND 4th DIGITS) www.aiag.org

05/23

15 CM UP TO 30 CM 30 CM AND OVER

	1	BENT	
D	2	INOPERABLE	
	3	CUT	
12	4	DENTED - PAINT OR CHROME DAMAGED	
_	5	CHIPPED - EXCEPT GLASS AND PANEL E	DGE
	6	CRACKED - EXCEPT GLASS	
=	7	GOUGED	
	8	MISSING	
	9	SCUFFED	
	10	INTERIOR STAINED/SOILED	
-	11	PUNCTURED	
	12	SCRATCHED -EXCEPT GLASS	
-	13	TORN	
14 DENTED PAINT/CHROME NOT DAMAGED			
_	15	FULL BODY CAR COVER - DAMAGED	
	16	THERMAL EVENT/FIRE	
00	18	MOLDING/EMBLEM/WEATHER-STRIP DA	MAGED
-	19	MOLDING/EMBLEM/WEATHER-STRIP LO	
	21	GLASS BROKEN	
-	22	GLASS CHIPPED	
	23	GLASS SCRATCHED	
		MARKER LIGHT DAMAGED	
_	25	DECAL/PAINT STRIPE DAMAGED	
	29	CONTAMINATION, EXTERIOR	
	30	FLUID SPILLAGE, EXTERIOR	
S	31	THEFT/VANDALISM	
7.50	34	CHIPPED PANEL EDGE	
		INCORRECT PART OR OPTION NOT AS IN	VOICED
4			
-	-	HARDWARE - LOOSE/MISSING	
N	00	THE EGGGETHIOCHT	
<u>س</u>		DAMAGE GEVERNE	V CODEC
_		DAMAGE SEVERIT	A CODE2
		(INCH MEASUREMENTS IN LEN	GTH/DIAMETER)
7		200 200 200 200 200 200 200 200 200 200	The state of the s
10	1	Up TO & INCLUDING 1"	LESS THAN 2.5 CM
- 57	2	OVER 1" UP TO & INCLUDING 3"	2.5 CM UP TO 7.5 CM
<del>t</del>	3	OVER 3" UP TO & INCLUDING 6"	7.5 CM UP TO 15 CM
- O			

**OVER 12"** 

Multiple damages on the same panel, regardless of severity, need to be treated as a DMG-1v6 severity 3 or greater & follow specific OEM guidelines.

OVER 6" UP TO & INCLUDING 12"

MISSING/MAJOR DAMAGE



# TIPS

### TRICKS



Here are some tips & tricks to ensure that damages are properly documented and to help avoid unnecessary damage claims.

- 1. Keep in mind that drivers are permitted to log into **ONLY 1** device while using the mandatory Magnus app. If drivers are logged into multiple devices (ex. Phone, tablet), the app will not work correctly, and loads will not be visible.
- 2. Remember that **ALL** drivers are required to enable **GPS location services while using the Magnus app**. This allows us to confirm if a vehicle was delivered to the correct location should it be reported as missing. This is also part of your signed **Broker Agreement**.
- 3. Make sure to note ALL damages at BOTH PICKUP and DELIVERY!
  - ✓ ALL pre-existing damages MUST be noted on the Magnus app prior to loading.
  - ✓ Always read **ALL** yard / origin instructions. These do vary based on location.
  - ✓ Make sure to get pre-existing damages VERIFIED if required according to the yard / origin instructions.
  - ✓ If the yard / origin **REQUIRES** damages to be verified and signed off and they <u>ARE NOT</u>, you <u>WILL</u> be held liable for a damage claim if one is submitted.
  - ✓ Always use the **AIAG DAMAGE CODES** when entering damages. Manufacturers <u>WILL NOT</u> accept damages that are written out when denying a damage claim.
  - ✓ Always take photos of **ALL** vehicles regardless if there is damage or not. Although a damage claim **CANNOT** be denied based solely on photos, by showing the condition of the vehicle prior to loading, photos **MAY** help support a denial.
  - ✓ Before you turn in a yard exit sheet or manifest, UPLOAD a photo of it using the MAGNUS APP. If there ARE damages, make sure that the VERIFICATION SIGNATURE or STAMP is showing in the photo. If it is uploaded, it is immediately available to us if we are notified of potential damage.
- 4. If you are delivering **AFTER HOURS** or **STI** (Subject to Inspection), **DO NOT** write a person's name on the delivery receipt or sign it in the Magnus app.
  - ✓ Always confirm the delivery hours and instructions.
  - ✓ Verify that STI is accepted by the destination.
  - ✓ Upload photos of each vehicle (regardless of condition). Try to include photos showing the destination in the background.
  - ✓ If there <u>IS</u> damage, upload photos from different angles (near and far) and try to use something to show the relevance to the size (such as a pen). Of course, make sure the damages are noted in the **MAGNUS APP**.
  - ✓ Check the STI box in the MAGNUS APP. DO NOT sign / write someone's name. (This is FALSIFYING INFORMATION and a DIRECT VIOLATION of your signed Broker Agreement.



# TIPS

### TRICKS



1. If a vehicle is delivered STI (Subject to Inspection) or we are UNABLE TO CONFIRM or VERIFY the signature for delivery is VALID, it is like WRITING A BLANK CHECK!



- 2. A DAMAGE CLAIM is based on "A change in the condition of a vehicle from the time that the carrier has care, custody and control of the vehicle". This means from the first time that you touch the vehicle at the origin until it is RECEIVED by the destination. If it is delivered STI, it is NOT considered to be received UNTIL the destination CONFIRMS that they have received the vehicle.
- 3. If pre-existing damages are noted prior to loading at the origin **BUT** they are **NOT** entered at **DELIVERY**, the destination has **NO IDEA** what damages you noted. This leaves them open to enter the damages as **THEY** determine them to be. This **MAY NOT** match what you have pre-noted. If they submit a claim for damages **OTHER THAN** what you noted, **YOU MAY BE LIABLE FOR THAT DAMAGE CLAIM**.
- 4. Damage NOTIFICATIONS MUST BE RECEIVED from the DESTINATION:
  - 1. Signature during joint inspection within 48 business hours
  - 2. STI delivery within 72 business hours
- 5. A **DAMAGE CLAIM <u>MUST</u> BE RECEIVED** from the **MANUFACTURER** within **9-12 MONTHS** from the date of delivery (as per contract).
- Your signed Broker Agreement states that ALL drivers MUST use the MANDATORY MAGNUS APP and ALWAYS ENABLE GPS LOCATIONS SERVICES while using the app to transport on behalf of Proficient Auto Transport.

JAN. 2024\_CG 2 of 3



# TIPS

### TRICKS





- 1. Loads WILL NOT be paid UNTIL an INVOICE has been RECIEVED and CONFIRMED CORRECT.
- 2. If at any time it is determined that the MANDATORY MAGNUS APP was NOT used CORRECTLY during transport as according to your signed Broker Agreement, you will be fined an ADMINISTRATIVE FEE PER VIN. Your carrier profile with us will also be reviewed and monitored for accuracy. This MAY RESULT in a change in your dispatch status including being PERMANENTLY REVOKED
- 3. If you utilize a factoring company and you receive a **DAMAGE CLAIM**, it is **YOUR RESPONSIBILITY** to notify them of the short pay amount.

#### PROFICIENT AUTO TRANSPORT CONTACT INFORMATION

MAIN OFFICE (904) 772-1175 / (888) 928-0312

DISPATCH (904) 802-0575 <u>BrokerDispatch@proautotran.com</u>

ACCOUNTS PAYABLE EXT. 450 <u>CarriersAP@proautotran.com</u>

CLAIMS EXT. 469 / EXT. 476 BrokerageClaims@proautotran.com

COMPLIANCE (904) 459-2892 / EXT. 903 Compliance@proautotran.com

10057 103<sup>rd</sup> Street Jacksonville, FL 32210

www.proficientautotransport.com

JAN. 2024\_CG 3 of 3