

EQUIPMENT IDENTIFICATION ASSISTANCE



TRAKSTAR (RECTANGLE BODY)

SERIAL NUMBERS START WITH
C1C2 / C7B



TRAKSTAR II (SHORT SQUARE BODY)

SERIAL NUMBERS START WITH
C1E2



TRANSTAR

SERIAL NUMBERS START WITH
T8N / T8S / T9N / T9S / T9T / V2A




TRANSTAR II (SHORT BODY)

SERIAL NUMBERS START WITH
T9TXXXXX-V3 / T9U / V3A



1306

SERIAL NUMBERS START WITH
C3E



1545 SERIES

SERIAL NUMBERS START WITH
C3N / C3S



LATERAL LAUNCHER GEN 2

SERIAL NUMBERS START WITH
ZOOM CAMERA = C2D2
TRANSPORTER = D6M
1545 LAT W/SONDE CAMERA = C3S



MINI TRACTOR

SERIAL NUMBERS START WITH
D3B



OMNISTAR PROBE

SERIAL NUMBER START WITH
C1A2