

BELL METAL CLUB HORIZONTAL BANDSAW

- If you are unfamiliar – ASK A MONITOR. KNOW WHERE THE EMERGENCY SHUT OFF IS.
- Before use, look for damage, missing guards, and blade condition.
- Only objects that can be clamped securely can be cut on this machine. Long material must be supported on both ends.
- Cutting fluid is used to prolong blade life and allow high quality cuts without heat distortion or damage – Stop the saw if there is not a free-flow of cutting fluid.
- The speed of the automatic feed should be SLOW – Turning up the feed speed will damage the blade.
- Use eye protection against metal particles and cutting fluid.
- The moving blade can catch loose hair, clothing, gloves and pull body parts into cutting edges. Only grab the cutting head at the outboard handle.
- Remove all scrap pieces and other objects from the cutting surface. Do not reach into the saw while it is running. Cut stock often has sharp edges.
- Do not leave the saw running unattended.
- Clean the saw and the work area before leaving the area.
- Notify the Monitor, if the saw is damaged, guards missing or inoperable.

