

## **Dish Machine De-Liming Instructions**

- 1. Drain Dish Machine Tanks
- Clean Dish Machine—Remove and clean scrap trays, then return into machine.
- Remove Dish Detergent and Rinse Aid from dispensing Bowls.
- 4. Refill Dish Machine Tanks with clean water.
- 5. Add De-limer—Pour .5 to 3 oz. of delimer per gallon of water capacity for the dishmachine into the appropriate tank(s). A one gallon bottle of delimer contains 128 oz. If this is an initial treatment or there is a severe lime problem, increase the amount of delimer being used.
- 6. Run Dish Machine with delimer for several cycles or at least <u>5</u> minutes
- 7. Drain Dish Machine Tanks
- 8. Refill Tanks with clean water and run at least <u>2</u> cycles
- 9. Drain Dish Machine Tanks
- 10. Replace Dish Detergent and Rinse Aid to their **correct** dispensing bowls. Detergent goes into red bowl, rinse into blue bowl.