

300 EAST



BEEHIVE 2

BEEHIVE 1

E2

E1

E3

G1

G2

G3

G1

G2

18

17

16

15

2

3

4

5

400 EAST

3
6
1

3
6
3

3
6
5

3
6
7

3
6
9

3
7
1

3
7
3

3
7
5

D2

D1

D4

D4

D5

D5

F1

F

C4

C2

9

10

11

12

C

14

13

B1

B

A1

A2

A4

A3

C1

C3

C5

C6

- MAIN SHUTOFF
- DEFUNCT TIMER
- ACTIVE TIMER
- STOP & WASTE
- VALVE BOX
- BACKFLOW

400 SOUTH