

MASPORT ROTARY MOWER

OVERVIEW

A commercial grade rotary mower designed for heavyduty lawn cutting, mulching and collecting.

- Cutting Width: 540 mm (21"), Quadcut 4-blade
- Cutting Depth: 13-69 mm, 11 positions
- Engine: Briggs & Stratton 190 cc OHV
- Drive: Variable self-propelled
- Fuel: Unleaded 1.1L tank | Weight: 43 kg
- Best For: General mowing, scalping, renovation preparation, grass clippings clean-up

BEFORE YOU START

Safety Gear

 Safety Boots, Eye Protection, Hearing Protection

Pre-Use Checks

- 1. Read the User Guide
- 2. Ensure the fuel tank is filled with unleaded petrol (provided).
- 3. Inspect for loose parts or damage
- 4. Clear or mark any obstacles such as stones, toys, or irrigation equipment

WARNINGS / DO NOT

- **O** Use SP drive throttle unless mower is running
- Neverse the mower while SP drive engaged
- ♦ Use on slopes exceeding a 15-degree incline
- Note: Leave the engine running unattended
- Nefuel while the engine is running or hot
- Operate without using safety gear

PRO TIPS

- Mow when the grass is dry but the soil still holds some moisture, this reduces dust.
- Do a second cut at a perpendicular angle to the first to reduce high spots and prep for consistent renovation results.

CONTACT US OR BOOK ONLINE @ TSVTURF.COM.AU





HOW TO USE

Starting the Engine

- 1. Ensure engine red fuel switch is on
- 2. Set the throttle to full & firmly pull the starter handle
- 3. Move the throttle to desired power

Adjusting Cutting Height

- 1. Use the single lever height adjuster to set the desired mowing height
- 2. Start higher if the lawn is long or thick, and gradually lower if preparing for scalping or renovation

Operating the Mower

- 1. Engage the SP drive lever to walk at a steady pace
- 2. Mow in straight passes, avoid reversing mower
- 3. Only use the SP drive throttle when the engine is running

AFTER USE

Cleaning

- Ensure equipment is clean before return
- Let engine cool before brushing off debris
- Avoid using water to prevent rust

Maintenance

- Check for loose parts and top up fuel if required
- Ensure air filter is kept clean and dry

Storage and Transport

- Store dry, indoors, away from direct sunlight
- Secure during transport to prevent movement

This guide is a summary only. By hiring this equipment, you agree to the full Terms & Conditions provided at the time of hire, including your responsibility for safe use, proper care, and any damage caused. TSV Turf Renovations is not liable for injury or property damage resulting from misuse or failure to follow instructions.



