



7

Whether the ball holes out or misses short, the ball will return back to you.



Changing the Alley width.

Remove the aluminum insert , flip and rotate ends to go from one level of difficulty to the other.



8

Let the ball come all the way out of the device to the front, and you are ready to load the ball for the next stroke.



For more information
please go to:
www.puttingalley.com

Instruction videos
Putting tips
Games to play



Tour Edition **Putting Alley®** Putting Stroke Isolator **Quick Start Guide**


Questions / Comments
sales@puttingalley.com
www.puttingalley.com

US Patents
9,028,336
9,498,695
9,616,312

TourEdition.Rev3


1

Lay the Putting Alley® base on a flat level surface. Use a level, or smartphone level, to make sure the base is horizontally level.




2

Place the aluminum Alley insert into base, slanted end facing up and in front. Use either 1 inch or 1/2 inch side.



3

Drop a ball in front of The Putting Alley® isolator.



4

Use your putter to load the ball into the starting area by pushing the ball through the open slot until it drops onto the front of the Alley.



5

Make sure the ball is centered on the Alley. If necessary, use your putter to nudge the ball and it will self center.



6

Ready to make a stroke. Putt the ball all the way on the alley to the Putting Alley® logo for a successful putt.

