



TO FIND A RECORDING AND EXPORT TO A USB MEMORY

Right click on the main display and select **MENU**

Select **PLAYBACK**




Only Your camera (UFO HUNTER) should be selected



Select the day you want to review

Recorded video will be red bars along the bottom of the time scale




Select the one you want to review and use the normal play, rewind, fast forward buttons at the bottom of the screen.

TO EXPORT A RECORDING TO USB MEMORY

Insert USB memory in the open USB slot on the back. Allow a few moments for the system to recognize it.

Use the SCISSOR icon on the bottom of the screen to clip the video (beginning and then the end) you want to save on USB memory



Click on **FILE MANAGEMENT** icon to save the recording to your USB.

