

PARTS LIST, (Continued)

For Drawing #602396

<u>Item</u>	<u>Part No.</u>	<u>Description</u>
R13	82441	27,000 Ohm ±10% 1/2 w. Resistor
R14	82448	.1 Meg. ±10% 1/2 w. Resistor
R15	82450	.15 Meg. ±10% 1/2 w. Resistor
R16	82684	.13 Meg. ± 5% 1/2 w. Resistor
R17	82684	.13 Meg. ± 5% 1/2 w. Resistor
R18	82682	62,000 Ohm ± 5% 1/2 w. Resistor
R19	82460	1 Meg. ±10% 1/2 w. Resistor
R20	82421	560 Ohm ±10% 1/2 w. Resistor
R21	82753	4700 Ohm ±10% 1 w. Resistor
R22	602346	16,000 Ohm ±15% Level Control
R23	82705	15,000 Ohm ±10% 1 w. Resistor
R24	82822	6800 Ohm ±10% 2 w. Resistor
R25	82464	2.2 Meg. ±10% 1/2 w. Resistor
R26	82760	18 Ohm ±10% 1 w. Resistor
RY1	602378	Control Relay
S1	12034	3-Contact Socket
S2	300152	Phono, Receptacle
S3	302204	8-Contact Socket
S4	602326	11-Contact Socket
S5	602325	3-Contact Socket
S6	602204	4-Contact Socket
S7	602386	2-Contact Socket
S8	602386	2-Contact Socket
S9	F8897	2-Contact Socket
SW1	602340	Library Control Switch
SW2	602342	Program Timer Switch
SW3	602381	Control Circuit Switch
SW4	602339	Main Line Switch & Circuit Breaker
T1	602354	Indicator Transformer
T2	602353	26 v. Control Transformer
T3	602353	26 v. Control Transformer
T4	602383	Power Transformer
T5	602384	6 v. Filament Transformer
TS1	602387	3-Screw Terminal Strip
TS2	602376	4-Screw Terminal Strip