



WATCHMAN

Quick Setup Instructions

Step 1: Connecting Watchman to your WiFi

- a. Power ON your Watchman and wait for the display to show "Offline".
- b. Go to WiFi settings on your tablet/mobile/PC, and look for ppC_noInternet_..... network
- c. Connect to ppC_noInternet_..... network (refer figure below on left)





- d. If a popup shows, click on "Connect only this time" (refer figure above on right)
- e. Once connected, go to a browser (google Chrome, Safari etc) and type 192.168.4.1 in URL field and hit enter.
- f. Click on "Scan WiFi networks" (refer figure below on left)
 - i. You may need to click it more than once to load all WiFis at your location





- g. Select WiFi, input your WiFi password and connect to it.
- h. As it connects, click OK on the popup and let Watchman auto-restart (refer figure above on right).
 - i. You may need to scroll the page down to see the popup

Step 2: Setting up for logs and alerts

[If you are an existing customer, skip step "a" and "b" below]

- a. Go to https://watchman.online/ and click "Register" button.
- b. Once registered, you will receive an activation email (if it does not arrive within a few minutes, please check spam folder). Click on activation link before your first login.
- c. Login (to https://pp-code.com/), click on "Activate/Add your Product" and follow the steps, [Please find the product ID on the back of your Watchman]
- d. Once activated, it will take you to Watchman page where you will see your Watchman. Click on it, you will be at the log page. Please note that first log is test log (sent by the system). **Your actual logs may appear an hour later**.
- e. On the same page (top right in red color), you will see "Alert Configuration", click on it to configure your alerts.

Download our App "Watchman Online" – for easy access to logs.

FOR TECHNICAL ISSUES, PLEASE CONTACT US: tech@pp-code.com or 732 410-6771 (vmail only).

https://watchman.online/