

WI 042- Installing Aberlink on remote computer	Date 08/05/14	Issue- 1	Author- Chris Walkley
--	------------------	----------	-----------------------

This instruction details how to install Aberlink 3D on stand alone units to allow the opening of inspection files for viewing, editing, report compilation. You do not require a keylok / software protection device.

Step 1.

Download software from www.aberlink.com via downloads. If new installation then download setup.exe if upgrading an existing installation then you can run the upgrade.exe

Also click on the view all files button on the same page, then select the Drivers and configs directory, then choose Aberlink offline, then select file offline registry setter (maybe in .zip format to enable download, this will need extracting once you have the download).

Downloaded files will be located in the downloads folder within windows explorer. Place these files on the desktop for ease of location.


Step 2


Locate the file on your computer and double click to run.

 Setup-3035(Build18).exe	08/07/2013 12:27	Application	27,500 KB
---	------------------	-------------	-----------

Step 3

Click Next >






Step 4


Click Next >

Use default destination folder, click Next >





Step 6

Choose the Retrofit option as shown below and click Next >, also click Next > twice more to the next options asking to create a shortcut in start menu and the desktop




Step 7

Click Install



Step 8

Click Next > on this window, and on Finish on the following prompt.



Step 9

Double click on below icon to set the aberlink software to work correctly.




Step 10



Double click on icon on desktop

Step 11



Click on cancel, to start the software in demo mode, click OK to No Dongle detected message. The Aberlink screen should now be visible and used the same way as the software on the measuring device.