


# MOTION AMPLIFY



## Intended Use

- Protect from free liquids.
- Use speakers only indoors.
- Ensure adequate ventilation.
- Avoid operating in damp rooms.
- Choose a stable and level surface.
- Your loudspeaker is maintenance free.
- Use a soft cloth and brush for cleaning.
- This product contains magnetic material.
- Ensure correct polarity when connecting.
- Do not expose speakers to direct sun light.
- Wrapping foil may be hazardous to children.
- Keep speakers away from any sources of heat.
- Do not place the speaker in an enclosed cabinet.
- Speaker for reproducing and amplifying audio signals.
- Allow two hours to acclimate, before using the speakers.
- The speakers are recommended for use in private settings.
- No manufacturer liability for damage caused by improper use.
- Dispose of the loudspeakers within applicable legal regulation.
- Remove speakers from packaging, without touching the drivers.
- Continuous exposure to loud music can cause damage to your hearing.
- Only connect to amplifiers that match the specifications of your speaker.
- Ensure that the delivery is complete and is without damage. In the event of damage, do not connect the speaker and contact [motionamplify.com](http://motionamplify.com)



**IIWIIIXIIII**

**Weight** 20 kg

**Woofers** 13 cm

**Tweeter** 25 mm

**Midtone** 100 mm

**Impedance** 2.0  $\Omega$ m

**Type** three way passive

**Inputpower** 110 watt sine

**(W x H x D) cm** (19 x 45 x 45)

**Switchable** bassreflex // closed

**Resolution dB** 40Hz - 20kHz +- 1db

**Crossover** 12 dB 11.95 db 0.0230  $\Omega$ m

**Equalizationfilter** 12 dB 11.84db 0.1  $\Omega$ m



### **Counter Switch**

Positioned on the back. For switching between bassreflex and closed mode.

### **Speaker cable connection terminal**

Connect your 110 watt amplifier here with a loudspeaker cable. Only connect to amplifiers that match the specifications of your speaker. Too much power can damage the speaker if the amplifier volume is set to high.