
MOTION AMPLIFY

IIWIIXIX

Intended Use

- Protect from free liquids.
- Use speakers only indoors.
- Ensure adequate ventilation.
- Avoid operating in damp rooms.
- Choose a stable and level surface.
- Your loudspeaker is maintenance free.
- Use a soft cloth and brush for cleaning.
- This product contains magnetic material.
- Ensure correct polarity when connecting.
- Do not expose speakers to direct sun light.
- Wrapping foil may be hazardous to children.
- Keep speakers away from any sources of heat.
- Do not place the speaker in an enclosed cabinet.
- Speaker for reproducing and amplifying audio signals.
- Allow two hours to acclimate, before using the speakers.
- The speakers are recommended for use in private settings.
- No manufacturer liability for damage caused by improper use.
- Dispose of the loudspeakers within applicable legal regulation.
- Remove speakers from packaging, without touching the drivers.
- Continuous exposure to loud music can cause damage to your hearing.
- Only connect to amplifiers that match the specifications of your speaker.
- Ensure that the delivery is complete and is without damage. In the event of damage, do not connect the speaker and contact motionamplify.com



IIWIIXIX

Weight 40kg

Woofer 20 cm

Tweeter 25 mm

Midrange 100 mm

Impedance 2.0 Ωhm

Type three way passive

InputPower 170 watt sine

 $(W \times H \times D)cm (28 \times 100 \times 47)$

Switchable bassreflex // closed

Resolution dB 40Hz - 20kHz +- 1db

Crossover 12 dB 11.95 db $0.0230 \Omega hm$

Equalizationfilter 12 dB 11.84db 0.1 Ω hm



Counter Switch

Positioned on the back. For switching between bassreflex and closed mode.

Speaker cable connection terminal

Connect your 170 watt amplifier here with a loudspeaker cable. Only connect to amplifiers that match the specifications of your speaker. Too much power can damage the speaker if the amplifier volume is set to high.