



ROSSWULF

Thank you for purchasing our Stainless Mesh Velocity Stack Screens. Each Ross Wulf Kit consists of 2 screens.

Tools required:

Pliers

Ross Wulf Screens fit within the throat of most Velocity Stacks. They may be adjusted slightly with pliers to fit slight variations in the diameter of the Velocity stack (air horn). Push the dome into the velocity stack with your fingertips on the outer ring. To remove the dome, use small pliers to grip the tabs on the outer ring. If the dome screen fits too loosely, use pliers to adjust the edges of the slotted skirt, slightly bending 4 corners is usually adequate. Make sure that the fit of the screen is tight enough to require removal with pliers and will not dislodge with simple finger pressure.

DO NOT PUSH or PRY ON THE MESH DOME - YOU MAY DAMAGE THE MESH.

Ross Wulf LLC
Las Vegas, NV 89183
206.794.0125
@rosswulf46
sales@rosswulf.com