

The original password is 000. When the password knob is turned to 000, Align them with the grooves,the lock will be unlocked.




How to change password:


1. Use the original password to unlock the lock, rotate the U-shaped ring 180 degrees to reach the following direction:




2. Press the U-shaped ring to achieve the following effect:



3. Now you can turn the knob to set a new password, such as changing it to 666



4. Pull out the U-ring, lock the lock, and randomly shuffle the password.



5. Now, congratulations on completing the setup. Your new password is 666.

In the future, you can use the new password 666