

IP5000-series Telephone Quick Reference Card

Make a Call

Dial the number, handsfree speakerphone is started. Continue to use the speaker or lift the handset. During handsfree press **Spkr** to hang up.

Answer a Call

Lift the handset or press Spkr.

Call Forward - Any Call

All Calls: Press Ext.+ #6011 + Destination Number

Busy: Press Ext. + #6021 + Destination Number

No Answer: Press Ext. + #6031+ Destination Number + Timer (Sec, 2 digits)

<u>Busy, No Answer:</u> Press Ext. + **#6041**+ Destination Number + Timer (Sec, 2 digits)

Cancel: Press Ext. + #6051

Mic/Mute Button

While on a handsfree call, press the **Mic** button. The indicator will turn off. The call is muted. Press **Mic** again to resume.

Volume Control

Handset Volume

During a call, press down **Vol** ▲ or **Vol** ▼.

Speaker Volume: Calls and

Background Music

Press **Spkr**, use **Vol** ▲ or **Vol** ▼. Press **Spkr**, to exit.

Speaker Volume: Ring Tone, Handsfree
Answerback, and Off-Hook Call Announce

With an idle phone and the handset on-hook: Press **Vol** \blacktriangle or **Vol** \blacktriangledown .

Call Transfer

Simple Transfer

- While on a call, press the TRNS soft key.
- 2. Dial the extension number and the call is transferred.
- 3. Hang Up.

To Announce the Call

- 1. While on a call, press Cnf/Trn.
- 2. Dial the extension number, stay on the line.
- 3. When the called party answers, announce the call.
- 4. Hang Up.

Note: During call transfer you can press the flashing extension button to reconnect to the original call.

Call Hold

- While on a call, press the **Hold** button.
- 2. To return to the held call, press the held line's button.

If you do not return to the held call, it rings your phone. If you are on another call you hear two tone bursts. If the held party hangs up the call is released.

Caller ID History

These steps require your phone to have a Caller ID feature button programmed.

- 1. Press the Caller ID feature button.
- Use the Vol ▲ and Vol ▼ ot the NEXT and PREV softkeys to scroll through the caller ID history.
- Press CALL to dial the displayed number.

Conference Calls

- 1. While on a call, press Cnf/Trn.
- 2. Dial another station or outside number.
- 3. After the called party answers press **Cnf/Trn**. All parties are in conference.
- 4. Repeat Steps 1~3 to add more lines. You can conference up to 8 parties.

Note: If you get busy tone or the station does not answer, press the flashing extension button to return to the conference.

© 2011~2012 Toshiba America Information Systems, Inc.
All rights reserved.



IP5000-series Telephone Quick Reference Card

Make a Call

Dial the number, handsfree speakerphone is started. Continue to use the speaker or lift the handset. During handsfree press **Spkr** to hang up.

Answer a Call

Lift the handset or press Spkr.

Call Forward - Any Call

All Calls: Press Ext.+ #6011 + Destination Number

Busy: Press Ext. + #6021 +

Destination Number

No Answer: Press Ext. + #6031+ Destination Number + Timer (Sec. 2 digits)

<u>Busy, No Answer:</u> Press Ext. + **#6041**+ Destination Number + Timer (Sec, 2 digits)

Cancel: Press Ext. + #6051

Mic/Mute Button

While on a handsfree call, press the **Mic** button. The indicator will turn off. The call is muted. Press **Mic** again to resume.

Volume Control

Handset Volume

During a call, press down **Vol** ▲ or **Vol** ▼.

Speaker Volume: Calls and Background Music

Press **Spkr**, use **Vol** ▲ or **Vol** ▼. Press **Spkr**, to exit.

Speaker Volume: Ring Tone, Handsfree Answerback, and Off-Hook Call Announce

With an idle phone and the handset on-hook: Press **Vol** \blacktriangle or **Vol** \blacktriangledown .

Call Transfer

Simple Transfer

- While on a call, press the **TRNS** soft key.
- 2. Dial the extension number and the call is transferred.
- 3. Hang Up.

To Announce the Call

- 1. While on a call, press Cnf/Trn.
- 2. Dial the extension number, stay on the line
- 3. When the called party answers, announce the call.
- 4. Hang Up.

Note: During call transfer you can press the flashing extension button to reconnect to the original call.

Call Hold

- 1. While on a call, press the **Hold** button.
- 2. To return to the held call, press the held line's button.

If you do not return to the held call, it rings your phone. If you are on another call you hear two tone bursts. If the held party hangs up the call is released.

Caller ID History

These steps require your phone to have a Caller ID feature button programmed.

- 1. Press the Caller ID feature button.
- Use the Vol ▲ and Vol ▼ ot the NEXT and PREV softkeys to scroll through the caller ID history.
- 3. Press **CALL** to dial the displayed number.

Conference Calls

- 1. While on a call, press Cnf/Trn.
- 2. Dial another station or outside number.
- 3. After the called party answers press **Cnf/Trn**. All parties are in conference.
- 4. Repeat Steps 1~3 to add more lines. You can conference up to 8 parties.

Note: If you get busy tone or the station does not answer, press the flashing extension button to return to the conference.

© 2011~2012 Toshiba America Information Systems, Inc. All rights reserved.

