

Wood Stove Instructions

Before Starting a Fire in the Wood Stove:

- * Gloves are available
- * Check to see if the Wood Stove is Hot

* Gather necessary materials: lighter, paper, cardboard, & kindling.

To Start a Fire in the Wood Stove:

- 1. Slightly open the draft door located below the lip of the stove. Slide damper rod located on the lip of the stove to the right, HIGH.
- 2. Using the foot pedal, open the lid of the stove. Keep pressure on the foot pedal to keep the lid open.
- 3. Reaching down into the stove, place 3 or 4 crumpled up paper balls in one corner with cardboard on top, next place 5 to 6 pieces of lightweight kindling on top, then add one small dry log.
- 4. Light a corner of the paper using the lighter or matches. Remove your foot from the pedal closing the lid.
- 5. Add larger kindling or heavier logs until fire is burning well.
- 6. Close and latch the draft door.
- 7. Continue to add wood as needed.
- 8. When the Hut is warm push the damper rod to the left, LOW.
- 9. Refill wood box from the outside before leaving or if you need more.
- 10. DO NOT REMOVE ASHES!
- * Always leave the draft door closed and the damper rod in LOW when you leave the building.