

Hamilton Beach Percolator


Instructions



How to Make Coffee

BEFORE FIRST USE: Clean the urn by following the steps in "How To Clean."

NOTE: For best results, always use cold, fresh tap water.




1 Remove cover, coffee basket, and stem.



2 Fill urn to desired water level. You must brew a minimum of 15 cups. Do not fill beyond 45-cup line.



3 Wet coffee basket (to help keep small particles of ground coffee from sifting through).




4 Make sure stem is properly seated in heating unit well in center or urn may not percolate.

Water Level*	Amount of Ground Coffee*
45 cups - 6435ml	2 ¹ / ₄ cups (225g)
35 cups - 5005ml	1 ³ / ₄ cups (175g)
25 cups - 3575ml	1 ¹ / ₄ cups (125g)
15 cups - 2145ml	³ / ₄ cup (75g)


NOTE: We recommend using coffee that has been ground specifically for use in a **percolator-type** coffeemaker. However, coffee marked "For All Coffeemakers" is acceptable. If using a coffee grinder and whole beans, coffee should be a coarse grind. Finely ground coffee may cause the basket to overflow and result in grounds in the coffee.

*Always keep water and coffee amounts between the minimum and maximum for your urn size.


How to Make Coffee (cont.)




5 Add coffee grounds to basket. Do not spill coffee grounds in stem.




6 Replace lid.




7 **NOTICE:** To avoid damage, do not plug in when there is no liquid inside.



8 The coffee urn will stop automatically when the coffee has finished brewing, and the ready light will glow. Allow about 1 minute per cup for brewing time.



9 Place cup under serving spout. Push down and hold lever until cup is filled.



10 Unplug.

NOTES:

- Urn will remain at serving temperature until unplugged. If keeping coffee warm for a long period, remove coffee basket and stem when cycle is complete. This will prevent bitter oils in the grounds from affecting the flavor of the coffee.

⚠ WARNING Burn Hazard. The metal urn parts will be hot. Use a pot holder or oven mitt to remove the cover, coffee basket, and stem.

- To make additional coffee, rinse cover, coffee basket, stem, and tank with cold water and repeat Steps 1 through 9.

- To reheat coffee, remove coffee basket and stem. Lock cover in place and plug in unit; then turn on for 20 to 60 minutes, depending on amount of coffee remaining. Do not reheat if less than 20 cups are left in the urn.

TO HEAT WATER:

(for instant coffee, hot cocoa, or tea)

1. Remove cover, coffee basket, and stem. Fill urn with cold water to desired level.
2. Do not replace coffee basket or stem. Water will heat best without these parts.
3. Place cover onto coffee urn and turn to lock. Plug in urn and let it complete a perk cycle. Water is hot when the ready light glows.


5

How to Clean


⚠ WARNING Electrical Shock Hazard.

Do not immerse the base or tank in water.

Periodically clean coffee urn with water and white vinegar solution. See "How to Clean Mineral Deposits and Buildup."



1 Unplug unit.



2 Remove lid, coffee basket, and stem. **⚠ WARNING Burn Hazard.** The metal urn parts will be hot. Use a pot holder or oven mitt to remove the cover.



3 Clean inside of coffee urn with warm, soapy water.



4 Wipe exterior of urn with a damp cloth. **NOTICE:** To avoid damage to the urn, do not use abrasive cleaners or pads on any part of the coffee urn.