



PriorityOne<sup>®</sup>  
UNLIMITED

844.210.5549  
www.AlphaWarranty.com

# THE BEST COVERAGE

WITH OUR HIGHEST LEVEL OF PROTECTION

- ELIGIBILITY UP TO 10 MODEL YEARS AND 125,000 MILES
- UNLIMITED MILEAGE TERM LENGTH
- DEDICATED PRIORITYONE SUPPORT LINES
- ENHANCED COMMERCIAL ELIGIBILITY

This brochure is not a contract and provides general information only. For contract terms, conditions and eligibility, please refer to the vehicle service contract from Alpha Warranty Services, Inc. The vehicle service contract obligor is either Alpha Warranty Services, Inc. or United Service Protection, Inc. (PO Box 20949 St. Petersburg, FL 33742, Florida License #6001600) depending on your state. Please refer to the vehicle service contract for additional details.

Alpha Warranty Services, Inc.  
PO Box 580 Riverton, UT 84065  
Version AWSP1 09262017



VEHICLE SERVICE CONTRACT PROGRAM

# OVER 750 COVERED PARTS

## ENGINE

Balance Shaft, Balance Shaft Bearing, Balance Shaft Bushing, Cam Followers, Camshaft, Camshaft Adjuster Seal, Camshaft Bearings, Camshaft Drive Sprocket, Camshaft Pulley, Camshaft Solenoid, Case Half Seals, Chain Tensioner, Connecting Rod, Connecting Rod Bearings, Crankshaft, Crankshaft Main Bearings, Crankshaft Pulley, Crankshaft Seal, Cylinder Barrel, Cylinder Head, Cylinder Head Gasket, Cylinder Head Valve, Dip Stick Tube, Distributor, Eccentric Shaft, Engine, Internal Lubricated Parts, Engine Mount, Seals and Gaskets, Engine Torque Strut, Exhaust Manifold, Exhaust Manifold Gasket, Exhaust Valve, Harmonic Balancer, Idler Pulley, Intake Manifold, Intake Manifold Gasket, Intake Plenum, Intake Runner Solenoids, Intake Valve, Knock Sensor, Oil Cooler, Oil Filler Neck, Oil Filter Bypass Valve, Oil Filter Housing, Oil Filter Housing O-Ring, Oil Level Sensor, Oil Pan, Oil Pan Gasket, Oil Pressure Sending Unit, Oil Pump, Oil Pump Gear, Oil Pump Housing, Pickup Screen, Piston, Piston Pin, Piston Ring, Push Rod, Rocker Arm, Rocker Bushing, Rocker Shaft, Serpentine Belt Tensioner, Timing Belt, Timing Belt / Chain Guide, Timing Belt / Chain Tensioner, Timing Chain, Timing Cover, Timing Gears, Valley Pan, Valley Pan Gasket, Valve Cover, Valve Cover Gasket, Valve Guide, Valve Guide Seal, Valve Lifter, Valve Lock, Valve Retainer, Valve Seat, Valve Spring, Valve Stem Seal, Variable Valve Timing Actuator, and Wrist Pin.

## ELECTRICAL

4x4 Switch, Alternator, Ambient Temperature Sensor, Antenna Control Module, Back Up Lamp Switch, Body Control Module, Brake / Stop Lamp Switch, Bulkhead Connector, Cabin Temperature Sensor, Camshaft Sensor, Clutch Interlock Switch, Crankshaft Sensor, Cruise Control Amplifier, Cruise Control Module, Cruise Control Servo, Cruise Control Servo Cable, Cruise Control Switch, Cruise Control Transducer, Day Time Running Lights Relay, Defrost Module, Diagnostic Connector, Digital Instrument Cluster, Dimmer Switch, Direct Ignition Cassette, Direct Ignition System, Dome Light Relay, Dome Light Switch, Door Ajar Switch, Door Pin Switch, Seals and Gaskets, Switches, Electronic Combination Entry, System / Key-less Entry System, Electronic Instrumentation Cluster, Control Module, Flasher, Hazard Switch, Headlamp Control Module, Headlamp Switch, Headlamp Washer Motor, Headlamp Washer Motor Relay, Heater / A/C Blower Motor Speed Switch, Horn, Horn Relay, Horn Switch, Idle Speed Control Motor, Ignition Cable, Ignition Coil, Ignition Cover, Ignition Distributor, Ignition Lock Cylinder, Ignition Module, Ignition Switch, Inertia Fuel Cut-Off Switch, Instrument Panel Printed Circuit Board, Instrument Panel / Gauge / Cluster, Interior Lighting Module, Knock Sensor, Mileage Computer, Multi-Function Switch, Neutral Safety Switch, Oxygen Sensor, Oxygen Sensor Relay, Pick Up Coil, Pigtail Plug, Power Antenna Motor, Power Door Lock Actuator, Power Door Lock Switch, Power Mirror Motor, Power Mirror Switch, Power Seat Module, Power Seat Motor, Power Seat Switch, Power Window Control Module, Power Window Motor & Regulator, Power Window Motor, Power Window Regulator, Power Window Relay, Power Window Switch, Powertrain Control Module, PROM, Rain Sensor, Rear Defroster Switch, Reverse Indicator Switch, Seat Adjuster, Seat Heater Element, Seat Heater Switch, Seat Memory Switch, Seat Track, Solar Sensor, Starter, Starter Drive, Starter Solenoid, Sunroof Control Module, Sunroof Power Motor, Sunroof Track Assembly, Tape Players, Trunk Lamp Switch, Trunk Release Actuator, Trunk / Liftgate Solenoid, Turn Signal

Switch, Underhood Lamp Switch, Valet Switch, Voltage Regulator, Window Regulator, Windshield Washer Fluid Level Sensor, Windshield Washer Pump, Windshield Washer Pump Switch, Windshield Wiper Motor, Wiper Arm, Wiper Module, Wiper Motor, Wiper Relay, Wiper Transmission, Wiring Harness, Wiring Repair, and Yaw Rate Sensor.

## TRANSMISSION TRANSFER CASE

Adapter Plate, Axle Bearing, Axle Seal, Axle Shaft, Axle Tube, Bell Housing, Carrier Bearing Front Differential, Center Support Bearing, Companion Flange, Constant Velocity Joint, Differential, Differential / Drive Axle Housing, Differential Bushing, Differential Carrier, Differential Internal Lubricated Parts, Differential Pilot Bearing, Differential Pinion Bearing, Differential Pinion Gear, Differential Pinion Seal, Differential Pinion Shaft, Differential Ring Gear, Differential Seal, Differential Seals and Gaskets, Differential Washer, Drive Chain, Drive Shaft, Drive Shaft Gear, Drive Shaft Seal, Drive Shaft Yoke, Seals and Gaskets, Drum, Flex Disc, Flywheel / Flexplate, Input Speed Sensor, Locking Hub, Main Shaft Washer, Output Shaft, Output Speed Sensor, Parking Pawl, Planetaries, Propeller Shaft, Ring and Pinion, Shell, Shift Bushing, Shift Cables, Shift Forks, Shift Interlock Solenoid, Shift Rails, Shift Solenoid, Shifter Assembly, Shifter Linkage, Slave Cylinder, Slip Yoke, Speedometer Cable, Sun Gear, Synchronizers, Torque Converter, Torque Converter Clutch Solenoid, Transmission, Transmission Case / Housing, Transmission Control Module, Transmission Electronic Shift Control Unit, Transmission Extension Housing, Transmission Internal Lubricated Parts, Transmission Mount, Transmission Oil Cooler, Transmission Oil, Transmission Oil Pan, Transmission Oil Pan Gasket, Transmission Output Shaft Seal, Transmission Pressure Regulating Solenoid, Transmission Range Sensor, Transmission Seals and Gaskets, Universal Joint, Vacuum Modulator, Valve Body, Valve Body Separator Plate, Viscous Coupling, Wheel Bearing and Hub Assembly, Wheel Bearing, and Wheel Hub.

## FUEL SYSTEM

Accelerator Pedal / Gas Pedal, Accelerator Pump, Boost Control Valve, Carburetor, Cold Start Injector, Fuel Control Valve, Fuel Door Actuator, Fuel Gauge, Fuel Gauge Sender, Fuel Injection Control Module, Fuel Injection Pump, Fuel Injector, Fuel Injector Nozzles, Fuel Level Sensor, Fuel Pressure Regulator, Fuel Pump, Fuel Pump Resistor, Fuel Rail, Fuel Seals and Gaskets, Fuel Selector Valve, Fuel Tank, Fuel Tank Pressure Sensor, Fuel Tank Sending Unit, Idle Air Control Motor / Actuator, Manifold Pressure Sensor, Mass Air Flow Sensor, Metal Fuel Delivery Lines, Poppet Valve, Stepper Motor, Throttle Body, Throttle Position Sensor, Vacuum Pump, and Waste Gate.

## COOLING

Belt Tensioner, Block Heater, Coolant Flange, Coolant Level Sensor, Coolant Nipple, Coolant Recovery Container Expansion Tank, Coolant Temperature Sensor, Fan Clutch, Fan Module, Fan Motor, Fan Relay, Fan Shroud, System Seals and Gaskets, Heater Control Valve / Hot Water Valve, Heater Core, Radiator, Radiator Cap, Thermostat, Thermostat Gasket, Thermostat Housing, Water Pump, Water Pump Housing, and Water Pump Seal and Gaskets.

## SUSPENSION

A-Frame, Automatic Ride Control, Ball Joint, Coil Spring, Coil Spring Seat, Control Arm, Control Arm Bearing, Control Arm Bushing, Control Arm Bushing Bracket, Control Arm Shaft, Electronic Compressor, Lateral Arm, Lateral Link, Leaf Spring, Radius Arm, Radius Arm Bushing, Solenoid Height Sensor, Spindle, Spindle Supports, Stabilizer Bar, Stabilizer Bar Bushing, Stabilizer Bar Link, Strut Bearing, Strut

Mount, Compressor Relay, Seals and Gaskets, Thrust Arm, Thrust Arm Bushing, Torsion Bar, Torsion Bar Bushing, Torsion Bar Mount, Track Bar, Trailing Arm, Trailing Arm Bushing, Variable Dampening, VDS Actuator, VDS Compressor, VDS Control Module, VDS Mode Selector Switch, VDS Seals and Gaskets, and VDS Solenoid Height Sensor.

## HEATING & A/C

A/C Accumulator and Receiver Dryer, A/C Check Valve, A/C Compressor, A/C Compressor Clutch, A/C Compressor Clutch Bearing, A/C Compressor Pulley, A/C Compressor Relay, A/C Compressor Shaft Seal, A/C Condenser, A/C Evaporator Core, A/C Field Coil, A/C Fittings, A/C Idler Pulley, A/C Idler Pulley Bearing, A/C Seals and Gaskets, Air Door Actuator / Motor, Automatic Climate Control Programmer, Blower Motor, Blower Motor Resistor, Blower Speed Switch, Climate Control Module / Unit, Compressor Cut-Off Switch, Condenser Fan, Expansion Valve, Heater / A/C Control Assembly, Orifice Tube, and Pressure Cycling Switch.

## STEERING

Center Link, Drag Link, Idler Arm, Pitman Arm, Power Steering Pump Seal, Rack and Pinion Gear, Rack and Pinion Housing, Rack and Pinion Internal Lubricated Parts, Rack and Pinion Seals and Gaskets, Rear Wheel Steering, RWS Control Valve, RWS Electronic Control Unit / Solenoid Phase Control Unit, RWS Power Cylinder Pump, RWS Shafts and Couplings, RWS Steering Box, Steering Angle Sensor, Steering Box / Gear, Steering Box / Gear Housing, Steering Box / Gear Internal Lubricated Parts, Steering Box / Gear Seals and Gaskets, Steering Column, Steering Column Shaft and Coupling, Steering Column Tilt Lever, Steering Internal Tilt Mechanism, Steering Knuckle, Steering Position Sensor, Steering Relays, Steering Seals and Gaskets, Steering Sensors, Steering Shaft, Steering Wheel Lock, Telescoping Steering Wheel, Tie Rod, and Tie Rod Sleeve.

## BRAKES

ABS Accumulator, ABS Control Module, ABS Electronic Control Processor, ABS Isolation Dump Valve, ABS Main Relay, ABS Master Cylinder, ABS Override Button, ABS Pressure Modulator Valve, ABS Pump / Motor, ABS Relay Valve, ABS Reluctor Rings, ABS Reservoir, ABS Seals and Gaskets, ABS Wheel Speed Sensors, ABS Wheel Speed Sensor Harnesses, Brake Adjusters, Brake Drum Backing Plate, Brake Fluid Pump, Brake Line (metal), Brake Pressure Modulator Valve, Brake Proportioning / Combination Valve, Brake Seals and Gaskets, Brake / Stop Lamp Switch, Compensating / Proportioning Valve, Disc Brake Caliper, Electronic Brake Control Module, Hydraulic Control Unit, Hydro Boost, Master Cylinder, Metering Valve, Parking Brake Cable, Parking Brake Control, Parking Brake Equalizer, Parking Brake Release Motor, Parking Brake Warning Switch, Power Brake Booster, Power Brake Booster Check Valve, Power Brake Cylinder, Pressure Modulator Valve, Traction Control Module, Traction Control Switch, and Wheel Cylinders.

## AND MORE!

HI-TECH COVERAGE  
OPTION AVAILABLE

RENTAL COVERAGE  
ASSISTANCE

24/7 ROADSIDE  
ASSISTANCE

