

Coverage Options

ENHANCED SEALS & GASKETS

Covers seals and gaskets for all covered components independently or in conjunction with a covered repair.

COMMERCIAL USAGE

Allows coverage for vehicles used for, but not limited to, fleet and multiple driver vehicles, vehicles used for delivery, service and repair work, trade work, mobile businesses, route delivery, and vehicles used to pull commercial trailers. Privately or company owned vehicles that are used by a primary driver for the purposes of, but not limited to, non-delivery route/sales work and light duty route work are eligible for coverage without a surcharge.

SNOWPLOW OPTION

Allows coverage for vehicles used for plowing snow if the blade length does not exceed 8 feet.

LIFTED BODY/SUSPENSION/OVERSIZED TIRES

Allows coverage for vehicles that have a lifted body or suspension (maximum of 12 inches lifted) and/or has oversized tires (no more than 40 inches in diameter). Lifted body/suspension up to 6 inches, lowered body/suspension up to 4 inches, and oversized tires up to 35 inches in diameter are covered under this contract without a surcharge.

MODIFIED VEHICLE

Allows coverage for vehicles equipped with the following modifications as long as they do not render your vehicle illegal for on-road use: performance/cold air intake modifications, enlarged throttle body/spacers, headers, exhaust modifications, high flow catalytic converter, high flow cat-back exhaust, performance chips/tuners, aftermarket forced induction systems (turbo/supercharger), aftermarket electronic ignition systems and aftermarket mufflers/pipes.

Coverage Benefits

RENTAL EXPENSE

Limited to \$30 for every 8 hours of labor time, up to \$150 per occurrence (except where prohibited by law)

TRIP INTERRUPTION EXPENSES

Up to \$75 per day for up to 3 days (except where prohibited by law)

- Meals (restaurants only)
- Lodging (hotel/motel only)

ROADSIDE ASSISTANCE

Up to \$50 per occurrence for:

- Towing assistance
- Flat tire assistance
- Fuel, oil, fluid, and water delivery service
- Lock-out service
- Battery assistance



Obligor:

CornerStone United, Inc., 1020 Main Ave. NW, Hickory, North Carolina 28601, 1-866-912-2770, except in AL, AZ, CA (License # 0E40854), CT, IL, IA, LA, NM, OK (License # 44202930), OR, WA, WI, and WY, where it is Dealers Alliance Corporation, 15920 Addison Road, Addison, TX, 75001, 1-800-282-8913 and in FL (License # 14-461107047), where it is CornerStone United Administrative Services, Inc., 1020 Main Ave. NW, Hickory, NC 28601, 1-877-434-4382


See service contract terms and conditions for full details of coverages, limits of liability and exclusions.



Xpanded Series

Now offering some of the most flexible plans in the industry

The
Xtended Auto
Advantage



FOR MORE INFORMATION CALL:
1-866-912-2770

bro.xpanded.1.2019

Xtend the life of your auto and avoid unexpected repair costs

AVERAGE REPAIR COSTS*

Component	Average Repair Cost
Engine Overhaul	\$ 4,700
Transmission Overhaul	\$ 3,200
Front Suspension	\$ 700
Air Conditioner	\$ 1,100
Power Steering	\$ 900
Electrical	\$ 700
Anit-lock Brakes	\$ 800
Fuel Pump	\$ 500
Cooling System	\$ 600
Power Window Motor	\$ 300
Electronic Control Module	\$ 1,200

*Coverage subject to deductible, exclusions, and limitations.

FIVE COVERAGE LEVELS

LEVEL	COMPONENT GROUPS
XP-1	1 - 4
XP-2	1 - 9
XP-3	1 - 18
XP-4	1 - 31
Ultimate XP	1 - 31+

XP-1 COVERAGE (1-4)

1. ENGINE (internal)

Pistons • Piston rings • Piston pins • Crankshaft • Main bearings • Thrust bearings/shims • Connecting rods • Connecting rod bearings • Camshaft • Camshaft bearings • Balance shaft • Balance shaft bearings • Timing chain or belt • Timing gears • Tensioners/guides • Intake and exhaust valves • Valve springs • Replaceable valve guides • Push rods • Rocker arms • Rocker arm shafts • Cam followers • Lash adjusters • Lifters • Oil pump • Oil pump housing • Oil pump pressure relief valve and spring • Water pump • Harmonic balancer • Crankshaft pulley • Flexplate • Valve covers • Timing gear cover • Oil pan • Oil dipstick • Engine block and heads (if damaged by the failure of an internally lubricated moving part) • Diesel injection pump, injectors, and vacuum pump • Rotary chamber, rotor, and main bearings • Hybrid control unit(s) including inverter, stator and rotor, battery sensors, cooling fan, cooling duct(s), high voltage harness and junction box, electric drive motor(s)

2. TURBO/SUPERCHARGER (internal)

Bearings • Turbine and turbine shaft • Housing (if damaged by the failure of an internally lubricated moving part)

3. TRANSMISSION (internal)

Torque converter • Front pump • Planetary gear set • Direct clutch • Forward clutch • Low and reverse clutch • Clutch apply piston • Internal sealing rings • Input and output shafts • Roller clutches • Bands • Check balls • Band apply servo • Drums • Center support • Governor assembly • Vacuum modulator • Valve body • Stator and stator shaft • Bushings • Pressure regulator valve and bearings • Pans and cases (if damaged by the failure of an internally lubricated moving part) • Hybrid transaxle assembly; transmission damper assembly, case, and all internal parts; transaxle mounts • Manual – internal gears; shafts; bearings; bushings; input and output shafts; counter shaft; synchronizers and sleeves; detent balls; thrust washers; shift forks; levers; collars and springs

4. SEALS & GASKETS

Seals and gaskets are only covered as required in the repair or replacement of a listed component above

XP-2 COVERAGE (1-9)

5. TRANSFER UNIT (4X4)

Internal gears • Shafts • Bearings • Bushings • Input and output shafts • Counter shaft • Synchronizers and sleeves • Springs and viscous couplings • Transfer case (if damaged by the failure of an internally lubricated moving part)

6. DRIVE AXLE(S)

Axle shafts • Axle bearings • Drive shafts • “U” joints • CV joints • Tripod joints • Ring and pinion gears • Carrier assembly • Bearings and shims • Center support bearings • Locking hubs • 4-wheel drive actuator • Differential case (if damaged by the failure of an internally lubricated moving part)

7. STEERING (manual or power)

Power steering pump • Steering gearbox • All internal parts in rack and pinion

8. ELECTRICAL

Alternator • Starter motor, drive, and solenoid • Voltage regulator • Turn signal switch and stop lamp switch

9. SEALS & GASKETS

Seals and gaskets are only covered as required in the repair or replacement of a listed component above

XP-3 COVERAGE (1-18)

10. XP-3 ENGINE

Intake manifold(s) • Exhaust manifold(s) • Air filter housing • Vacuum pump

11. XP-3 STEERING (manual or power)

Couplings • Steering main and intermediate shafts • Power cylinder assembly • Power steering cooler • Control valve • Pitman arm • Idler arm • Tie rod ends • Drag link/center link

12. XP-3 ELECTRICAL

Engine Control Module (ECM) • Power seat motors • Power seat switch • Power window motor • Power door lock actuators • Power door lock switches • Distributor • Windshield washer pump and switch • Horn(s) and horn button • Cruise control engagement switch • Power mirror switch

13. SUSPENSION

Upper and lower control arms • Control arm shafts and bushings • Upper and lower ball joints • Steering knuckles • Stabilizer shaft, link, and bushings • Kingpins and kingpin bushings/bearings

14. BRAKES

Master cylinder • Wheel cylinders • Disc brake calipers • Proportioning valve • Metal hydraulic lines and fittings • Vacuum assist booster

15. AIR CONDITIONING

Compressor • Clutch • Coil and pulley • Condenser • Evaporator • Accumulator/drier and orifice tubes are only covered in connection with replacement of an above listed component AND only if they have failed

16. COOLING

Fan clutch and fan • Electric fan motors • Heater control valve

17. FUEL DELIVERY

Electric and mechanical fuel pumps • Fuel pressure regulator • Fuel pump driver module • Fuel tank sending unit • Fuel tank • Metal fuel lines

18. SEALS & GASKETS

Seals and gaskets are only covered as required in the repair or replacement of a listed component above

XP-4 COVERAGE (1-31)

19. XP-4 ELECTRICAL

Power window regulators and drives • Front wiper motor including circuit board, relay and delay switch • Manually operated switches for power windows, power seat(s), headlamps, wipers (front and rear) emergency warning flashers • Trunk actuator and motor • Hybrid power inverter assembly • Hybrid system stator and rotor • Hybrid system control units and sensors • Fuel gauge sending unit • Heated back glass elements (glass is not covered) • Rear wiper motor • Heater blower motor • Horn • Factory installed sun/moon roof motor and its wiring harness and switches • Convertible top motor and switches • Radio and CD player (factory or dealer installed with factory approved parts only) • Power antenna motor, mast, and switches

20. XP-4 SUSPENSION

Strut bar and bushings • Spindles and spindle supports • Shackles and eye bushings • Springs, torsion bars, and bushings • Macpherson struts • Stabilizer linkage and bushings • Wheel bearings and seals • Automatic leveling unit compressor, sensor, and limiter valve

21. XP-4 BRAKES

Power assist booster and valve • Combination valve • Backing plates • Springs, clip, and retainers • Self-adjusters • Rear activators • Parking brake linkage and cables

22. XP-4 AIR CONDITIONING

Manual switches • Expansion valve • Dryer fan • Accumulator • POA valve • H block • Hi/low pressure cut-off switch • Ducts and outlet hoses • Automatic temperature control unit

23. XP-4 COOLING

Radiator • Thermostat • Heater core • Hybrid cooling system blower motor and pumps

24. XP-4 FUEL DELIVERY

Fuel pressure regulator • Fuel injectors • Fuel distributor • Diesel injection pump

25. ELECTRONICS

Anti-detonation/knock sensor • Electronic Spark Control (ESC) module • Electronic Engine Control (EEC) module • Oxygen sensor • Electronic module retard vacuum switch • Electronic ignition module • Igniter • Electronic digital instrument cluster • Thermometer • Digital driver information display and module • Instrument panel printed circuit board • Failure of remote keyless entry transmitter and receiver (loss is not covered) • Heated side view mirror element • Cruise control servo, module, and transducer • Compass • Speed sensor

26. SPORT UTILITY

Bumper step motor and mounting brackets • Power tailgate actuator and motor • Power winch motor, controller, wire harness, and roller • Spare tire carrier, swing arm, pivots, latches, and locks • Power running board actuator and motor • Cargo lamp • Tie downs • Swing out mirror arms, mounts, actuator, and motor • Pop-out or sliding side/rear window latches and hinges • Convenience bed liner • Tailgate handle, lock cables, hinges, and latches • Edge protectors • Trailer hitch receiver, insert, and plug receptacle • Auxiliary fuel tank and switch over valve

27. 4-WHEEL STEERING

Control unit • Actuator • Mode selector • Position sensor • Rear tie rod assembly • Rear gear assembly • Cylinder barrel • Center joint • Pinion • Power steering housing (if damaged by the failure of an internal part)

28. ANTI-LOCK BRAKES (ABS)

Electronic control unit • Anti-lock computer module • Wheel speed sensors/exciters • Proportioning valves • High pressure hydraulic pump • ABS modulator assembly • Accumulator

29. INTERIOR/EXTERIOR

Glove box door and hinge • Manually operated seat tracks • Adjustable pedals • Interior and exterior door handles • Door hinges • Map/courtesy light assembly • Hood, trunk, and hatch gas cylinders • Hood, trunk, and hatch hinges • Speedometer head

30. EMISSIONS

Air fuel ratio sensor • Fuel pressure sensor • Idle air control valve • Intake air temperature sensor • Manifold Air Pressure (MAP) sensor • Mass Air Flow (MAF) sensor • Oxygen sensor • Exhaust Gas Recirculation (EGR) valve • Delta Pressure Feedback EGR (DPFE) sensor • Powertrain Control Module (PCM) • Thermostatically controlled air intake • Secondary air injection system • Knock sensor • Throttle body assembly

31. SEALS & GASKETS

Seals and gaskets are only covered as required in the repair or replacement of a listed component above

ULTIMATE XP

THE ULTIMATE IN COVERAGE

Provides coverage for virtually every mechanical and electrical component of your new or pre-owned vehicle. This coverage is so comprehensive that if it's not on the short list of exclusions, it is covered. Ultimate XP coverage includes all components covered under XP-1, XP-2, XP-3, and XP-4 plus hundreds more, such as:

- Heated seat elements
- Anti-theft devices
- Hood and trunk lift supports
- Window washer pumps
- Seat memory modules
- Seat recliners
- Navigation system
- Driver assist sensors
- Tire pressure sensors
- Front, rear and side cameras
- Bluetooth control unit
- DVD player
- Sunroof guides, tracks and cable
- Rain sensing wiper system
- LED signal mirrors
- Fuel pressure regulators
- Audio system amplifier and graphic equalizer
- Lumbar pad air pump

COMMON EXCLUSIONS AND LIMITATIONS:

- Maintenance items (i.e. tune-ups, spark plugs, air filters, brake pads, rotors, wiper blades, belts, hoses)
- Exhaust system (except manifold)
- Manual/Hydraulic clutches
- Trim, molding, carpeting, flooring, paint, upholstery, glass
- Tires, wheels, and rims
- Batteries, battery cables
- Breakdown caused by contaminants, foreign objects, improper use, lack of fluids and/or required maintenance

See service contract terms and conditions for full details of coverages, limits of liability and exclusions.