



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
*Accessories & Option Codes, (4 pages) 0-15.1 Thru 0-15.4	0-15.1
Air Condition Pulleys and Belts - Identification Code & Usage Chart	6-12.1
Air Condition Control Cables - Usage Chart-Color Code and Part No.	1-1.4
Air Condition Procedure Chart. General Precautions and Test Procedure	1-1.2
Air Condition Refrigerant Lines Usage - Chart	1-1.3
Air Condition Modification, Installations, Radiator Upper Panel Radiator Inlet and Outlet Hose-Fan Shroud-Radiator Usage - Delcotron & Airator Assembly to Carburetor. Water pump Cover Pulley-Spacer and Fan	1-11.0
Air Condition Installations - Center Duct and Outlet-Rt. and Lt. Outlet-Aluminum Insulator - Instruction Tag and Cement Requirements	1-11.1
Air Condition Sequence Installations - Evaporator - Front Duct - Rear Duct Plenum Blower-Resistor	1-11.2
Air Condition Installations - Retainer to Evaporator - Heater Assembly - Gasket-Seal-Cement Requirements - Heater Distributor Duct and Hoses	1-11.3
Air Condition Control Wire Assembly and Adjustment - and Instruction Tag	1-11.4
Air Condition Installations Vacuum Switch and Vacuum Hose Assembly	1-11.5

*8-9-66

PART NUMBER-1379480

A Index Page 1



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES

ALPHABETIC INDEX

	<u>PAGE NO.</u>
Air Injection Reactor Installation and Information-- 225 - 300 - 340 Cu. In. Engine	6-10.1 6-10.2
Air Injection Reactor Installations and Information 446 GS-400 Cu. In. Engine	6-11.1
Antenna Installations and Instructions	12-10.1
Appearance Dimension - Chart-Molding Clearance-Bumper Clearance Fender to Body Clearance and Door Alignment	0-4.1 Thru 0-4.4
Ash Tray Installation	1-8.2
Ash Tray Color Usage	0-3.1
Axle Information Assembly Dwg	4-2.1
Axle Marking Identification - Assembly Plant and Field (Color Code for Mfg only)	4-8.1
Axle Gear & Speedometer - Chart	4-7.1
Backup Lamp Installations (Except Wagons)	14-3.1
Backup Lamp Installations - (Wagons)	14-4.1
Backup Lamp Wire Terminals to Neutral Safety Switch	12-6.2
Backup Lamp Switch - Manual Transmission 3 Speed - 4 Speed	7-4.1 7-5.1

8-9-66

PART NUMBER-1379480

A Index Page 2



1967 BUICK ASSEMBLY INSTRUCTION MANUAL
SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Backup Lamp Wire Terminals to Neutral Safety Switch	12-6.2
Backup Lamp Switch - 3 Sp Manual Trans.	7-4.1
4 Sp Man	7-5.1
Battery Cable Identification - Code	12-1.3
Battery Cable Installations (Except 446 GS)	12-6.6
Battery Cable Installations 446 GS	12-6.7
Battery Specific Gravity Requirements when cars are shipped from the Assembly Plants	12-6.6 12-6.7
Black Light Inspection Requirements for Leaks	0-13.1 0-13.2
Body Styles and Model Chart (See 0-15.1 Thru 0-15.4 for Options)	0-1.1
Body Mounting Installations - Mounts - Insulators - Bolts and Chassis Information for Body Builders (Except Sportwagon)	2-3.1
Body Mounting Installations - Mounts - Insulators - Bolts & Chassis Information for Body Builders - Sportwagon	2-4.1
Booklets to be placed in the Instrument Panel Compartment prior to Final Car Shipment	0-11.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 3



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Brakes - General Information	5-1.1
Brake Master Cylinder Identification Code	5-1.2
Brake Pipes - Hose and Clip Installation	5-5.1
Brake Pedal and Master Cylinder Installation - (Manual)	5-6.1
Brake Pedal and Master Cylinder Installation - (Power)	5-7.1
Brake and Wheel Information - Front	5-2.1
Brake and Wheel Information - Rear	5-3.1
Brake-Disc Brake Option J52-Pipes and Master Cylinder Installation	5-4.1
Brake Fluid Initial Filling, Bleeding and Test Procedure	5-8.1
Brake - Parking Brake Cable - Pedal Installation and Adjustment	5-9.1
Bumper - Front - Supports and Brackets to Frame - Installation	14-2.1
Bumper - Rear - Support and Brackets - Filler Cap	14-3.1
License Plate Door - Lamp and Back Up Lamp Installation See 0-4.1 for Dimension Clearance	
Bumper - Rear - Bracer - Supports - License Lamp - Filler and Back Up Lamp Installations (Wagons)	14-4.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 4



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES

ALPHABETIC INDEX

	<u>PAGE NO.</u>
Car Body and Sheet Metal Installations (Fuel Filler Baffle Taillamp - Inside Rear View Mirror - Rocker Molding and Paint Stripe - Installations (2 Pages)	1-19.1 1-19.2
Car Keys Information	0-11.1
Car Loading Dimension Chart	0-7.1
Carburetor - Identification - Tags and Color Code	6-1.5
Cluster Assembly - Installation - (See 12-1.4 for Identification)	1-8.3
Clutch Pedal and Controls - Installation and Lash Adjustment (Except 446 GS)	7-8.1
Clutch Pedal and Controls - Installation and Lash Adjustment (446 GS)	7-9.1
Clutch Information Assembly (Except 446 GS)	7-10.1
Clutch Information Assembly (446 GS)	7-11.1
Control Arms - Installation (Front)	3-2.1
Control Arms - Identifications	4-1.1
Control Arms - Installations (Rear)	4-3.1
Console Installation and Wire Routing	1-5.1
Automatic Transmission Only (2 Pages)	1-5.2

*8-17-66

PART NUMBER-1379480

A-INDEX PAGE 5



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Console Installation and Wire Routing	1-6.1
3-Speed & 4-Speed Manual Transmission (Consolette) (2 Pages)	1-6.2
Console Short Installation with Column Shift Transmission (Front Seat Center Compartment)	1-7.1
Cruise Control Hydraulic Opt K33 (For Wiring See 12-8.1 and 12-16.1)	6-8.1
Dash Units Installations (Non-Heater Jobs)	1-2.1
Dash Units and Front Floor Installations (3 Pages) 1-3.1 thru 1-3.3	1-3.1
Dash Hole Drilling Requirements (All Series Heater Jobs)	1-4.1
Dash Hole Drilling Requirements (All Series Air Cond. Jobs)	1-4.2
Defroster Installations (Non-Heater Jobs)	1-2.1
Defroster Installations (Heater Jobs)	1-9.1
Defroster Installation (Rear Window)	1-10.1
Delcotron Identification - Chart	12-1.2
Disc Brake Installations - Opt. J52	5-4.1
Engine Compartment Wiring (4 Pages) 12-6.4 thru 12-6.7	12-6.4

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 6



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Engine - Mfg. Code Identification, etc. (6 Pages) 6-2.1 thru 6-2.6	6-2.1
Engine and Transmission Mounts - Usage and Identification	6-3.0
Engine and Transmission Mounting Installations (Automatic and Manual Transmission)	6-3.1
Engine Information Assembly - 225 Cu. In. (V-6)	6-15.1
(2 Pages)	6-15.2
Engine Information Assembly - 300 Cu. In. (V-8)	6-16.1
(2 Pages)	6-16.2
Engine Information Assembly - 340 Cu. In. (V-8)	6-17.1
(2 Barrel Carburetor)	6-17.2
Engine - Fast Idle Cable Installation	6-5.1
*Engine Information Assembly - 340 Cu. In. (V-8)	6-18.1
(4 Barrel Carburetor) - Rocker Arm Cover Label	6-18.2
*Engine Information Assembly - 400 Cu. In. (V-8) - Rocker Arm Cover Label	6-19.1
(2 Pages)	6-19.2
Exhaust Pipe Identification Color Code and Usage	8-2.1
Exhaust System Installations - Single with 225 Cu. In. V-6 Engine	8-3.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 7



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
*Exhaust System Installations - Single with 300 & 340 Cu. In. Engine (V-8) (Except Sportwagons)	8-4.1
Exhaust System Installations - Single with 340 Cu. In. V-8 Engine (Sportwagons)	8-5.1
Exhaust System Installations (Dual) 400 Cu. In. Engine - 446 GS	8-6.1
*Fan Pulleys and Belts Detail Assembly Tension Requirements and Identification Code.	6-12.1 6-13.1 6-13.2
*Fast Idle Cable Option - Installations & Hole Drilling Requirements.	6-5.1
Fender and Wheel House Assembly (Skirt) Installation Includes Special Paint Requirements	11-2.1 11-2.2
Fender to Body Installation	11-2.3
Fender Ornament and Molding Installations (3 Pages) 11-2.4 thru 11-2.6	11-2.4
Fender Piercing Requirements	11-5.1
Frame - Identification - Code	2-1.2
Fuel System Installations - Special Wagons - 44335-43435-43535-43635 Models	8-7.1
Fuel System Installations - Sportwagons - 44455-44465-44855-44865 Models	8-8.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 8



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Fuel System Installation - All Models Except Wagons	8-9.1
Fuse Block - Is Part of the I.P. Wire Harness	12-6.3
Ground Clearances - Chart	2-5.1
Inst. Pan. Compt. Installation (Door - Hinge and Stop Installed by Fisher)	1-8.2
Head Lamp Aim - Chart	12-3.1
Heater Hose Usage - Chart	0-9.1
Heater and Defroster Installations - Controls - Blower Hoses & Clamps (3 Pages) 1-9.1 thru 1-9.3	1-9.1
Hood Bumper Assembly	11-2.1
Hood Installation - Ornaments - Moldings and Letters	11-3.1
Hood Hinge - Spring and Insulator Installation	11-3.2
Hood Latch Assembly Installation	11-4.1
Instrument Cluster Identification	12-1.4
Instrument Panel Installations and Information (4 Pages) 1-8.1 thru 1-8.4	1-8.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 9



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Instrument Panel Wiring (3 Pages) 12-6.1 thru 12-6.3	12-6.1
Jack Installation and Instruction Label (Except Wagons) (Tire Covers)	10-3.1
Jack Installation and Instruction Label (Wagons) (Tire Covers)	10-3.2
Lamp & Fuse Chart	12-2.1
Lamp (Rear) Wiring (Regular Jobs)	12-6.8
Lamp (Rear) Wiring (Wagons)	12-6.9
Luggage Carriers (2 Pages)	1-20.1
Levelizer Control Installation (Option)	4-4.1
Optional Equipment Factory Installed (Four Page List)	0-15.1
Oil Fill Transmissions	0-12.1
Parking Brake Installation	5-9.1
Paint - Exterior Colors	0-2.1
Paint Stripe Requirements - Color & Code	1-19.3
Paint - Interior Colors and Combinations	0-3.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 10



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Paint - Chassis Black	2-2.1
Paint - Acid Proof 9985019 to be Applied as shown on fender front wheelhouse Assembly.	11-2.1
Paint Requirements - Brake Drums - When Chrome Wheel <u>Option</u> is Specified	5-2.1 5-3.1
Protect-O-Plate Installation	1-16.1
Propeller Shaft Installations	4-5.1
Propeller Shaft Information	4-6.1
Radiator - Grille - Headlamp and Front End Sheet Metal Installation (4 Pages) - 11-4.1 - 11-4.4	11-4.1
Radio Receiver Installation and Antenna Trim Adjustment	12-11.1
Radio - Rear Speaker - Installations	12-12.1
Repairable Items at the Assembly Plants	0-14.1
Spare Wheel and Jack Installation	10-3.1
Spare Wheel and Jack Installation (Wagons)	10-3.2
Suspension - Front Wheel - Installations - Caster Camber Adjustment - Control Arms - Stabilizer and Springs	3-2.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 11



1967 BUICK ASSEMBLY INSTRUCTION MANUAL


SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Suspension - Rear Wheel - Installations - Springs - Spacers - Insulators and Shock Absorbers	4-3.1
Springs - Rear - Data	4-9.1
Springs - Front Tabulated - Chart	3-4.1
Shock Absorber & Spring Data-Chart (Front and Rear)	3-5.1
Shock Absorber & Spring Data - Chart (Heavy Duty)	3-6.1
Speedometer Cable Identification	12-1.5
Speedometer Cable Installation	12-4.1
Speedometer Cable Installation (GS only)	12-5.1
Speedometer and Axle Gears	4-7.1
Stop Light Switch Installation	5-7.1
Steering Column Usage - Chart	9-1.2
Steering Gear and Linkage Installation (Power and Manual) Power Reservoir Fill	9-2.1
Steering Column and Manual Transmission Upper Controls	9-3.1
Steering Column and Automatic Transmission Upper Controls	9-4.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 12



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES

ALPHABETIC INDEX

	<u>PAGE NO.</u>
Steering Column - Tilt Wheel (Floor Shift)	9-5.1
Steering Column Non Tilt Wheel (Floor Shift)	9-6.1
Steering - Wheel and Horn Button Installation	9-7.1
Tire Size and Source (Tire size shown on 2-4.1 and 2-5.1)	10-1.2
Tire and Wheel Balancing	10-2.1
Transmission Oil Fill	0-12.1
Transmission Identification and Usage	7-1.2
Transmission Lower Controls - 3 Sp. Manual	7-1.3
Transmission Upper Controls - 3 Sp. Manual (Column Controls)	9-3.1
Transmission Controls - 3 Sp. Floor Shift	7-4.1
Transmission Controls - 4 Sp. Floor Shift	7-5.1
Transmission Lower Controls - (Automatic)	7-3.1
Transmission Upper Controls	9-4.1
Transmission Upper Controls - Floor Shift with Tilt Wheel	9-5.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 13



1967 BUICK ASSEMBLY INSTRUCTION MANUAL

SPECIAL - SKYLARK 43000 - 44000 SERIES
ALPHABETIC INDEX

	<u>PAGE NO.</u>
Transmission - Floor Shift Controls (Non Tilt Wheel)	9-6.1
Vacuum Connections - Chart - All Engines	6-9.1
Vehicle Identification Plate Embossed and Pre-embossed requirements	1-18.1
Vehicle Identification Plate Installation to Body Pillar	1-19.1
Wheel Balance	10-2.1
Wiring Information and Routing Instrument Panel - Engine Compartment - Front Lamps	12-6.1
<u>Rear Lamps - and Fuel Fage - 9 Pages 12-6.1 thru 12-6.9</u>	
Wiring Information - Air Condition	12-7.1
Wiring Information - Hydraulic Operated Cruise Control	12-8.1
Wiring Information - Power Top	12-9.1
Wiring Information - Power Tail Gate Window	12-9.2
Wire Circuit Diagram - Hydraulic Cruise Control	12-14.2
Wire Circuit Diagram - Heater and Air Condition	12-15.1

*8-17-66

PART NUMBER-1379480

A INDEX PAGE 14