



# New Era Tech Quick Start Guide





The Digiwrist Kit allows you to  
instantly call plays  
Securely, Wirelessly, and OFF GRID.

***Your system arrives:***

- Pre Paired
- Locked to your team
- Ready to use out of the box

***No setup required.***

# HOW TO USE

## ***Step 1 - Power On***

1. Power on tablet
2. Power on receivers
3. Power on DWT Booster (if included)

## ***Step 2 - Launch App***

1. Tap Digiwrist icon
2. Log in if required (WiFi needed first time only)

## ***Step 3 - Connect Transmitter***

1. Plug into tablet
2. Tap "OK" when prompted

## ***Step 4 - Load Plays***

1. Select Offense or Defense.
2. Tap SYNC (WiFi required) OR Enter plays manually and tap Save




## ***Step 5 - Call Play***

1. Select play.
2. Tap SEND.

Receivers vibrate: 2 times standard; 3 times with Booster.













***No WiFi required during game play.***

# DIGIWRIST POWER GUIDE

		
<b>Receivers</b>	<b>Tablet</b>	<b>DWT Booster</b>
15+ hours battery	8+ hours play time	20-hour full charge
Full Charge 45min	Charge after each use	Lasts several days
Charge after each use		Turn off after use

 Maximize Performance. Charge Regularly.

# DIGIWRIST WATER RESISTANCE

 <b>Receivers</b>	 	
 <b>Tablet</b>	 	
 <b>Transmitter/Booster</b>	 	

Cloth OK to wash... in fact, we recommend it!