


INTERNAL DEBEADING TOOLS



Type	Description	Pipe Diameter		Part #
Debeader	90-110 Debeader Head Only	4"		DH4
Debeader	125-160 Debeader Head Only	6"		DH6
Debeader	160-200 Debeader Head Only	8"		DH68
Debeader	225-315 Debeader Head Only	10" - 12"		DH1012
Debeader	355-500 Debeader Head Only	14" - 20"		DH1420
Debeader	560-630 Debeader Head Only	22" - 24"		DH2224
Debeader	710-800 Debeader Head Only	28" - 32"		DH2832
Debeader	Support Wheel Kit	*Specify Size When Ordering*		DSWK
Debeader	4" - 8" Rod and Handle Kit	4" - 8"		DRHK48
Debeader	10" - 32" Rod and Handle Kit	10" - 32"		DRHK1032

PARTS DESCRIPTION:

- 1 internal debeader body
- 2 connecting shaft
- 3 hexwrench
- 4 support roller
- 5 screw to fix connecting shaft
- 6 steel pipe connecting rod
- 7 support wheel
- 8 rotating lever
- 9 adjusting wrench
- 10 spare blade

