Pre-Launch Checklist

СОМ	TIME	PROCEDURE	Mission Control Notes
1	T-00:05:00	Launch HOLD	
		CABIN DOOR to LATCH	
		ENVIRONMENTAL SYSTEM O2 SYS to OPEN	
		ENVIRONMENTAL SYSTEM N2 SYS to OPEN	
		ENVIRONMENTAL SYSTEM H ₂ O LOOP to OPEN	Advise: Go for Load OPS 1 and Execute
		Key in ITEM Select A Key in DPS Select 1 (OPS 1) Key in EXEC	
		BOILER CNTRL POWER (1/2/3) to ON	
		BOILER CNTRL HEATER (1/2/3) to ON	
		BOILER N ₂ SUPPLY (1/2/3) to OPEN	
			Announce: Confirm Water Spray Boiler On
			Advise: Check Boiler Temp
		Key in DPS Select 2 (OPS 2) Key in EXEC	Advise: Go for Load OPS 2 and Execute
			Advise: Go for Cabin Leak Check
			Announce: Go for Helium (He) Pressurization

_		
1 cont.	PNEUMATIC He ISOL (LEFT/CENTER/RIGHT) to OPEN	Announce: APU Pre-Start Check Is Underway
	APU FUEL TNK VLV (1/2/3) to CLOSE	·
	APU SHUTDWN to ENABLE	
	HYD MAIN PUMP PRESSURE (1/2/3) to LOW	
	APU SPEED SELECT (1/2/3) to NORMAL	
	HYD CIRC PUMP (1/2/3) to GPC	
		Advise: Check Vent Temp
	APU MAIN POWER to ON	
	APU CNTRL POWER (1/2/3) to ON	
	APU MSTR VLV to OPEN	
	APU FUEL TNK VLV (1/2/3) to OPEN	
	APU/HYDRAULICS (1/2/3) to RUN	
	HYD MAIN PUMP PRESSURE (1/2/3) to NORMAL	Announce: Nominal APU Start
	HYD CIRC PUMP (1/2/3) to OFF	
	Confirm central HUD is on and in Orbit Earth Mode.	
	If needed Select 0 (toggle until Orbit Earth HUD is visible)	
	STAR TRACKER to ON	
	C - Request Go/No Go for launch	
		Advise: Mission Control confirms all systems are nominal. You are <u>Go</u> for launch.

1 cont.		Initiate Launch Clock Restart when Go order received MAIN ENGINE POWER (LEFT/CENTER/RIGHT) to ENABLE N ₂ CNTRL VLV LEFT (1/2) to ENABLE N ₂ CNTRL VLV RIGHT (1/2) to ENABLE	Mission Control confirms some systems are Off-Nominal. You are No Go for launch until these systems are corrected. Advise: Go for Main Propulsion System (MPS) initialization Advise: Go for OMS Engines Initialization Announce: Stand by to Initiate radar at T-4:00
3	T-00:04:00 T-00:03:00	PRIMARY SYSTEM RADAR to ON RATE GYRO ASSEMBLY (RG1/RG2-3/RG4) to ON INTERNAL SHUTTLE SYSTEM PWR (BAT A/BAT B) to ON INTERNAL SHUTTLE SYSTEM POWER - INT PWR TRANSFER to ON Key in DPS Select 3 (OPS 3)	Annouce: Synchronization of Fuel Cells Underway Announce: Confirming Shuttle Is On Internal Power Advise: Go for Load OPS 3 Announce: External Tank Cap is retracted

		GLOBAL POSITIONING SYSTEM (GPS-1/GPS-2/GPS-3) to ON	Advise: Check Hydraulic (APU) Pressure
4	T-00:02:00	APU SHUTDWN to INHIBIT Verify SRB JETTISON is GPC	Announce: Confirm APU Power Shutdown is inhibited
		Verify EXT TANK JETTISON is GPC	Announce: External Tank Liquid Hydrogen vents are closed.
5	T-00:01:00	AC BUS SENSOR to AUTO INTERNAL SHUTTLE SYSTEM POWER - EXT PWR DISCONNECT to ON	Announce: Confirm ground power disconnect complete. Advise: Mission Commander - You are Go for Executing OPS 3 at T-4 seconds
6	T-00:00:04	Key in EXEC	Advise: Go for Execute OPS 3
7	T-00:00:00		Initiate Mission Elapsed Time Clock Announce: Shuttle liftoff, the clock is running

Ascent Checklist

COM	MET	PROCEDURE	Mission Control Notes
8	T+00:00:20	Switch Left MFD back to Surface Mode Key in 9	
9	T+00:00:44		Announce: Automatic Main Engines Throttle Down to 65%
10	T+00:01:10		Announce: Automatic Main Engines Throttle Up to 104%
11	T+00:02:05	SRB Separation	Announce: OMS assist burn start
		FREON LOOP to OPEN	
		H ₂ O HX to OPEN	
		AIR HX to OPEN	
12	T+00:03:00		Advise: Check Flash Evaporator Is Operational
13	T+00:04:20		Advise: Negative Return
14	T+00:05:00	INTERNAL CHUTTUE CAYOTEM DAVID	Advise: Confirm Status of Fuel Cells
		INTERNAL SHUTTLE SYSTEM PWR (BAT A / BAT B) to STANDBY	
15	T+00:08:00		Advise: Go for Engines Automatic Throttle Down in Preparation for Main Engine Cutoff (MECO)
16	T+00:08:55	Main Engine Cutoff (MECO)	Advise: Confirm Main Engine Shutdown and Engine Cutoff (MECO)

Orbit Insertion Checklist (Post MECO)

COM	MET	Procedure	Mission Control Notes
17	T+00:09:00	FWD RCS He TANK ISOL (A/B) to OPEN AFT RCS LEFT He TANK ISOL (A/B) to	
		OPEN AFT RCS RIGHT He TANK ISOL (A/B) to	
		OPEN THE THE THE RESERVED TO	Announce: Initialize External Tank
			Separation system
18	T+00:09:20	Confirm N ₂ CNTRL VLV LEFT (1/2) are	Announce: Standing by for Auto OMS1 Burn
		ENABLEd Confirm N ₂ CNTRL VLV RIGHT (1/2) are	
		ENABLEd	
19	T+00:09:30	FLT CNTRL PWR to INHIBIT ENGINE DAP to AUTO	
		ENGINE DAI 10 ACTO	
20	T+00:09:45	MAIN ENGINE POWER (LEFT/CENTER/RIGHT) to OFF	
21	T+00:10:00	HYD MAIN PUMP PRESSURE (1/2/3) to LOW	
		APU/HYDRAULICS (1/2/3) to OFF	
		APU SHUTDWN to ENABLE	
		APU FUEL TNK VLV (1/2/3) to CLOSE	
		APU MSTR VLV to CLOSE	
		APU CNTRL POWER (1/2/3) to OFF	
		APU MAIN POWER to OFF	

21		HYD CIRC PUMP (1/2/3) to GPC	
Cont.		111D CIRC I OWN (1/2/3) to GI C	Announce: APU Shutdown complete
			Announce: Confirm External Tank
			Separation
22	T+00:10:30	DUMP ISOL VLV to OPEN	
		H ₂ RECIRC VLV to OPEN	
		H ₂ INBOARD VLV to OPEN	
		H ₂ OUTBOARD VLV to OPEN	
		PNEUMATIC He ISOL	
		(LEFT/CENTER/RIGHT) to GPC	
		O ₂ VENT LINE to OPEN	
		O2 INBOARD VLV to OPEN	
		O2 OUTBOARD VLV to OPEN	
			Announce: MPS Propellants Automatic Dump initiated.
23	T+00:11:00	Advise Mission Control when OMS Burn	
	<u>approximate</u>	Initiated	Advise: Confirm OMS Burn Initiated
			Advise. Commin Oivis Burn initiated
		BOILER N ₂ SUPPLY (1/2/3) to CLOSE	
		BOILER CNTRL HEATER (1/2/3) to OFF	
		BOILER CNTRL POWER (1/2/3) to OFF	
24	T+00:12:00	H ₂ RECIRC VLV to CLOSE	
	approximate		
		H ₂ INBOARD VLV to CLOSE	
		H ₂ OUTBOARD VLV to CLOSE	
		O2 VENT LINE to CLOSE	
		O ₂ INBOARD VLV to CLOSE	

24		O ₂ OUTBOARD VLV to CLOSE	
Cont.		DUMP ISOL VLV to CLOSE	Announce: Auto Propellant Dump Complete
25	T+00:14:00 approximate	AIR HX to GPC H ₂ O HX to GPC FREON LOOP to GPC	
26	T+00:15:10 approximate	Advise Mission Control when OMS Burn Complete	Advise: OMS Burn complete
		N ₂ CNTRL VLV LEFT (1/2) to DISABLE N ₂ CNTRL VLV RIGHT (1/2) to DISABLE AC BUS SENSOR to MONITOR	
27	Mission Dependent	Confirm central HUD is on and set to Orbit Earth mode. • If needed Select 0 (toggle until Orbit Earth HUD is visible) H2 RECIRC VLV to GPC H2 OUTBOARD VLV to GPC H2 INBOARD VLV to GPC O2 VENT LINE to GPC O2 OUTBOARD VLV to GPC O2 INBOARD VLV to GPC	Announce: Liquid H ₂ Outboard Fill & Drain Valves are set to Computer Control Announce: Liquid O ₂ Outboard Fill &
		ENGINE DAP to MANUAL	Drain Valves are set to Computer Control

27 Cont.		FLT CNTRL POWER to ENABLE RATE GYRO ASSEMBLY (RG1/RG2-3/RG4) to OFF	Announce: Go for Initiating Manual Zero Attitude Correction
		Orient the shuttle to a zero attitude while using the <u>Kill Rotation</u> command (blue key 4) to stabilize the maneuver.	
			Announce: Confirm Shuttle in zero attitude (manual prograde)
28	Mission Dependent	PAYLOAD BAY POWER to ON	Advise: Go for payload bay door open program
		PAYLOAD BAY DOOR to OPEN RADIATORS to DEPLOY	Announce: Confirm Payload Bay Doors are open
			Announce: Confirm Radiator Deployment
		Ku ANTENNA to DEPLOY	Announce: Confirm KU Antenna Deployment
			Announce: Shuttle is correctly configured for the mission

De-Orbit Checklist

COM	MET	Procedure	Mission Control Notes
29	Mission Dependent	STAR TRACKER to OFF	Advise: Go for Payload Bay Door Close program.
		Ku ANTENNA to STOW	Announce: Confirm KU Antenna is stowed
		RADIATORS to STOW	Announce: Confirm Radiators are stowed
		PAYLOAD BAY DOOR to CLOSE	Announce: Confirm Payload Bay Doors are
		PAYLOAD BAY POWER to OFF	closed
30	Mission	BOILER CNTRL POWER (1/2/3) to ON	
	Dependent	BOILER CNTRL HEATER (1/2/3) to ON	
		BOILER N ₂ SUPPLY (1/2/3) to OPEN	
31	Mission Dependent	Position the Shuttle to The Correct Attitude – Retrograde	
		Key in 6 – Retrograde	Announce: Confirm Shuttle in retrograde attitude
32	Mission Dependent	DUMP ISOL VLV to OPEN	
		PNEUMATIC He ISOL (LEFT/CENTER/RIGHT) to OPEN	Announce: Main Propulsion System Helium Release Initiated

33	Mission	APU MAIN POWER to ON	
	Dependent	APU CNTRL POWER (1/2/3) to ON	
		APU MSTR VLV to OPEN	
		APU FUEL TNK VLV (1/2/3) to OPEN	
		APU SHUTDWN to INHIBIT	
		APU/HYDRAULICS (1/2/3) to RUN	
		HYD MAIN PUMP PRESSURE (1/2/3) to LOW	
		APU SPEED SELECT (1/2/3) to NORMAL	
		HYD CIRC PUMP (1/2/3) to OFF	
34	Mission Dependent	PNEUMATIC He ISOL (LEFT/CENTER/RIGHT) to CLOSE	
		DUMP ISOL VLV to CLOSE	Announce: Main Propulsion System Helium Release Completed
		N ₂ CNTRL VLV LEFT (1/2) to ENABLE	
		N ₂ CNTRL VLV RIGHT (1/2) to ENABLE	
			Advise: Go for Perform De-orbit Burn
		Engine Throttle to Maximum	
35	Mission Dependent	Engine Throttle to OFF	Advise: Confirm De-orbit Burn Complete
		N ₂ CNTRL VLV LEFT (1/2) to DISABLE	
		N ₂ CNTRL VLV RIGHT (1/2) to DISABLE	

Simulator Version 220203.01

36	Mission Dependent	Position The Shuttle to The Correct Attitude – Prograde	
		Key in 7 – Prograde	Announce: Confirm Shuttle in prograde
			attitude
37	Mission Dependent	RE-ENTRY SYS CHECK to ON HYD MAIN PUMP PRESSURE (1/2/3) to NORMAL	
			Announce: Confirmation of Auto Dump RCS Propellant
38	Mission Dependent	FWD RCS He TANK ISOL (A/B) to CLOSE	
		AFT RCS LEFT He TANK ISOL (A/B) to CLOSE	
		AFT RCS RIGHT He TANK ISOL (A/B) to CLOSE	
			Announce: Pressure cycle complete
39	Mission Dependent		Advise: De-Orbit Procedure is Complete

Landing Checklist

COM	Altitude	Procedure	Mission Control Notes
40	35 k	Disengage RCS mode Key in D LANDING SYS to ARM LANDING SYS CHECK to ON LANDING SYSTEM RADAR to ON	
41	28 k	(Lift takes affect)	Announce: Current altitude and speed
42	25 k	P – <u>Announce: Kennedy VOR is Acquired</u> P – <u>Announce Runway 15/33 ILS is</u> <u>Acquired</u>	Advise: Hydraulics/Brake Heater auto-activated Announce: Current altitude and speed
43	2.5 k	GEAR to DEPLOY	Announce: Gear deployed
44	0.5 k (500 m)	SPEED BRAKE to DEPLOY	Announce: Speed Brake deployed
45	Touchdown	DROGUE CHUTE to DEPLOY	Announce: Touchdown
46			Announce: Wheels Stop
47		End of Mission	