

Work Truck Incyte

Follow Us



[LinkedIn](#)



[Facebook](#)



[Website](#)




CUBIC YARDAGE CALCULATOR

SIDE WALL HEIGHT

CONTAINER / BODY LENGTH

	2'	3'	3.5'	4'	5'	6'	7'	8'
10'	5.40	8.10	9.45	10.80	13.50	16.20	18.90	21.60
12'	6.48	9.72	11.34	12.96	16.20	19.44	22.69	25.93
14'	7.56	11.34	13.23	15.12	18.90	22.69	26.47	30.25
16'	8.64	12.96	15.12	17.28	21.60	25.93	30.25	34.57
18'	9.72	14.58	17.01	19.44	24.31	29.17	34.03	38.98
20'		16.20	18.90	21.60	27.01	32.41	37.81	43.21
22'		17.82	20.79	23.77	29.71	35.65	41.59	47.53
24'		19.44	22.69	25.93	32.41	38.89	45.37	51.85
26'			24.58	28.09	35.11	42.13	49.15	56.17
28'			26.47	30.25	37.81	45.37	52.93	60.49
30'			28.36	32.41	40.51	48.61	56.71	64.81
32'				34.57	43.21	51.85	60.49	69.14
34'				36.73	45.91	55.09	64.27	73.46
36'				38.89	48.61	58.33	68.06	77.78
38'				41.05	51.31	61.57	71.84	82.10
40'				43.21	54.01	64.81	75.62	86.42
42'					56.71	68.06	79.40	90.74


Assumes an inside width of 87.5"



3,600 Equipment Distributor/Upfitter Locations

Mapping the U.S. & Canada

Contact us today and
begin exploring **The Map**
(over 6,600 locations).
Discover how clear
industry visibility can
drive smarter decisions.



3,000 Truck/Chassis Dealer Locations

info@worktruckincyte.com • 515-564-9774
www.worktruckincyte.com