



# HD Tackpad Guide v1

## How it works

### TURN ON

Press the power button once and wait to see the screen to turn on, it will go black and after a minute you will see the screen load into the interface.

### TURN OFF

On the main screen, click the **Gear** button to go to the options page and you will see the shutdown button. Press that and a window will ask "Are you sure?" click yes to power down.

This will NOT turn the battery off, to turn the battery off. Slow press the power button twice on the battery.

- press once and wait about half a second and press again.

### CHARGE THE BATTERY

There is a usb A port that can be used with the cable that comes with the device to charge it.

### CHANGE STRATAGEMS

Select any of the options on the right to be taken to the list of stratagems to add.

Select the Stratagem you wish to add

The next screen will ask you which section out of 4 to add it to.

This will then bring you back to the main screen with the newly added stratagem.



Check for Update notes on  
[HD.C3DPRINTS.COM](http://HD.C3DPRINTS.COM)