ASSEMBLY INSTRUCTIONS





Tahiti 4 pc Outdoor Corner Set


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.


PARTS LIST				
ITEM	DESCRIPTION	SKETCH	QUANTITY	
HW1	Bolt and Washer M6*35		38 PCS	
HW2	Bolt&Washer M6*40		11 PCS	
HW3	Bolt M6*20		32 PCS	
HW4	Allen Key		1 PC	
А	Right Armrest		1 PC	
В	Left Armrest		2 PCS	
С	Right Sofa Backrest		1 PC	
D	Left Sofa Backrest		1 PC	
E	Right Sofa Seat		1 PC	
F	Left Sofa Seat		1 PC	
G	Corner Backrest		1 PC	
Н	Right Front Panel		1 PC	
J	Corner Seat		1 PC	
К	Sofa Side Panel		3 PCS	
L	Table Top		1 PC	
М	Table Middle Frame		1 PC	
N	Table Leg		2 PCS	
0	Table Side panel		2 PCS	
Р	Left Front Panel		1 PC	


Q	Table Glass		1 PC
R	Seat Cushion		5 PCS
S	Back Cushion		6 PCS
U	Sofa Foot-Corner		9 PCS
V	Sofa Foot-Straight		7 PCS
W	Connector Clips	D	4 PCS











CLEANING INSTRUCTIONS: clean with a soft cloth, brush or lightly vacuum.

ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.



Customer Service

1-877-864-5752

8:30 AM PST - 4:00 PM PST (Monday-Friday)

Website: www.dwellhom.com Missing Parts: parts@dwellhom.com

Warranty Information: www.dwellhom.com/warranty