




- 3** Stand the chair upright and ensure it is level before tightening all bolts.



- 4** Fully tighten all bolts using Allen Key (E).




- 5** Secure Velco under Seat Deck (G).



# dh

Model: \_\_\_\_\_  
Lot No: \_\_\_\_\_  
Date of Purchase: \_\_\_\_\_

## TURIN DINING CHAIR, 2 PACK



### ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.

Customer Service

**1-877-864-5752**

8:30 AM PST - 4:00 PM PST (Monday-Friday)

Website: [www.dwellhom.com](http://www.dwellhom.com)

Missing Parts: [parts@dwellhom.com](mailto:parts@dwellhom.com)


Warranty Information: [www.dwellhom.com/warranty](http://www.dwellhom.com/warranty)




**WARNING:** This product may contain small components, please ensure they are kept away from small children.

## PARTS AND HARDWARE


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




A. Bolt M8x50mm  
10x



B. Bolt M8x80mm  
8x




C. Washer  
18x




D. Spring Washer  
18x




E. Allen Key  
1x



F. Backrest with Rear Legs  
2x



G. Seat Deck  
2x




H. Front Legs  
4x

## ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.

- 1 Attach Front Legs (H) to Seat Deck (G) using Bolt (A), Spring Washer (D) and Washer (C). Partially tighten using provided Allen Key (E).

**NOTE: Do not fully tighten bolts at this point.**



- 2 Attach Backrest with Rear Legs (F) to Seat Deck (G) using Bolt (B), Spring Washer (D) and Washer (C). Partially tighten using provided Allen Key (E).

**NOTE: Do not fully tighten bolts at this point.**

