

Solvent Printer Settings

Roland Versaworks

<u>PG Number</u>	<u>Profile Setting</u>	<u>PG Number</u>	<u>Profile Setting</u>
PG-SOLPHOTOPAPG	SGP3	PG-SOLDISPLAYPPPETWB	PBF
PG-SOLPHOTOPAPSG	PMP4	PG-SOLDISPLAYPPPETWB	PBF
PG-SOLDISPLAYPPPETWB	MBF	PG-SOLDISPLAYPPMW	LBV
PG-SOLDISPLAYPPPETWB	MPP-SG	PG-SOLDISPLAYPPPETWB	LBV
PG-SOLBACKLITG	GBF	PG-SOLBACKLITM	MBF
PG-SOLCANM2X1	SSC	PG-SOLBACKLITG	GBF
PG-SOLPHOTOPAPG	SGP3	PG-SOLCLRPET	ESP-CL
PG-SOLDISPLAYPPPETWB	PBF	PG-SOLWALLPSA	ESP-CLT
PG-SOLDISPLAYPPPETWB	RPBF		

Mimaki JV300

<u>PG Number</u>	<u>Profile Setting</u>	<u>PG Number</u>	<u>Profile Setting</u>
PG-SOLBACKLITG	Ecosol Backlit Glossy	PG-SOLDISPLAYPPPETWB	Blockout Banner Matte
PG-SOLBACKLITM	Green Backlit	PG-SOLBACKLITM	Solvent Backlit Matte
PG-SOLPHOTOPAPSG	Photopaper Satin		