Operating the Display for SMLRO Model S9 S11 and G6 Bikes



To change display settings hold the Up and Down arrows simultaneously to enter the advanced settings menu. In this menu clicking the "M" (mode) button will toggle between each Parameter setting. To adjust the value of each setting click the up and down arrows accordingly.

Please visit Tryxpro.com often for more updated version of the display instruction under Product Support menu.

Setting	Function	Default	Description
P01	Display Brightness	1	Backlight display brightness. Level 1-3 (3 is
			brightest)
P02	Distance Units	1	Speed: KM or MPH
P04	Sleep	1	LCD Display sleep timer. With the default
			setting, the display will
			turn off after it has not been used
P08	Speed Limit	100	Speed limit in km/h. Range is 0-100. The
			input data here represents the
			maximum operating speed of the bike. The
			max value allowed is 100. Anything above this
			will not be recognized. Error: ± 1km/h. 100
			means no speed limit.
P09	Throttle Toggle	0	0: Throttle is active
			1: Throttle is inactive
P11	PAS Sensitivity	3	Sensitivity of PAS sensor. When set to higher
			numbers, it will take more crank rotations for
			the motor to turn on. On lower numbers, it
			will take little crank rotation to turn on the
			motor.
P12	PAS Strength	1	Strength of PAS mode. When set to
			higher numbers, motor will come on
	I AS Strength		stronger. On lower numbers, it will be more
			gentle.