

After the display is turned on, press the + button and - button at the same time for five seconds to enter into the 01 interface.



Then press M button to switch to 02 interface.



Press the + button at the 02 interface to switch between Km/h and MPH.





According to the above method, first press the + and - button at the same time for five seconds , and then press the M button to switch to the 07 interface.

07 interface is where we set and cancel speed limit .



Press + or - button to change the number in the lower column of the 07 interface.

The larger the number in the lower column of the 07 interface is , the slower the speed will be .

If you don't want speed limit, you just reduce the number in the lower column of the 07 interface.

When the number is around 016 or smaller , the speed is near its max speed.