


Spreading System

No.	Material Number	Material Name
1	YC.JG.ZS003497	Baffle
2	YC.WJ.L00868	Screw M30-HC080080-55-85
3	YC.JG.ZS003512	Sensing Part
4	YC.JG.MY000387	Reduction Gearbox Motor Dustproof Cover
5	YC.WJ.L00006	Screw M25-HC01200120-045025-5103-Y
6	YC.JG.BJ000776	Spinner Disk Gasket
7	YC.JG.QX003398	R-Type Thumb Nut
8	YC.JG.QX003398	R-Type Thumb Nut
9	YC.JG.ZS003426	Spinner Disk
10	YC.JG.ZS003513	Spinner Disk Upper Disk Buckle
11	YC.WJ.L00868	Screw M30-HC080080-55-85
12	YC.JG.ZS003480	Spinner Disk Upper Disk
13	BC.AG.SS000715	Agitator
14	YC.JG.ZS003515	Large Gear
15	YC.JG.QX003086	Short Shaft
16	YC.JG.QX003085	Spreading Flange
17	YC.WJ.L00005	Upper Thread 3*3
18	YC.JG.QX002222	Sealing Sleeve
19	YC.JG.MY000731	Dustproof Cover 1
20	YC.JG.MY000733	Dustproof Cover 3
21	BC.AG.SS000714	Hopper Gate
22	YC.JG.BJ000694	Axis Clip
23	YC.JG.MY000732	Dustproof Hood 2
24	BC.AG.SS000716	Reduction Gearbox
25	YC.WJ.LL000096	Screw M30-HB050045-55-05
26	YC.JG.QX001324	Lubricating Ring
27	YC.WJ.LL000096	Screw M30-HB050045-55-05
28	YC.JG.MQ001943	Hopper Gate Foam Pad
29	YC.WJ.L00868	Screw M30-HC080080-55-85
30	YC.JG.MY001031	Heat Sink Sealing Ring
31	YC.XC.XX001005	Spreading Signal Cable
32	BC.AG.SS000713	Control Module
33	YC.JG.MY001030	Cable Board Sealing Ring
34	YC.ST.LL000112	Screw M40-HC00450039-076020-0003-Y
35	YC.JG.MY000314	Drain Hole Waterproof Ring
36	YC.WJ.LL000074	T30-HC080065-60-15
37	YC.JG.MY000341	Servo Sealing Ring
38	BC.AG.SS000718	Spinner Disk
39	BC.AG.SS000717	Servo Module
40	YC.WJ.L00870	Screw M30-HC060060-55-85
41	YC.JG.TT000163	Lock Button Spring
42	YC.JG.QX003018	Spread Tank Lock Button
43	YC.SJ.WS001064	Fixing Knob
44	YC.WJ.L00868	Screw M30-HC080080-55-85
45	YC.BZ.XX000417	Spray System Locking Device EVA Foam



Spreading Tank

No.	Material Number	Material Name
1	YC.JG.ZS002281	Unloading Cover
2	YC.JG.CS000021	Spread Tank (75L)
3	YC.JG.ZS003495	Spread Tank Cover

