






T10 Intelligent Flight Battery Pt - 1





No.	Material Number	Material Name
1	YC.JG.JS000006	Battery Handle
2	YC.JG.YZ000193	Battery Handle Upper Cover
3	YC.JG.BJ000581	Battery Handle Inner Liner
4	YC.JG.MY000281	Battery Handle Upper Cover Rubber Stopper
5	YC.WJ.LL000227	M40-PBW00900060-080030-5103-Y01
6	YC.JG.ZS000942	Battery Button
7	YC.JG.MY000284	Battery Upper Cover Corner Pad
8	YC.JG.MY000314	Drain Hole Waterproof Ring
9	YC.ST.LL000112	M40-HC00450039-076020-0003-Y
10	YC.JG.MY000282	Battery Lower Rubber Pad
11	YC.JG.JS000006	Battery Handle
12	YC.JG.YZ000193	Battery Handle Upper Cover
13	YC.XJ.JZ000012	Battery Upper Cover Forward Rubber Pad
14	YC.JG.MY000289	Battery Connector Sealing Ring
15	YC.JG.MQ000572	Battery Level Indication Sticker
16	YC.ST.LL000113	M30-HPW01600100-095023-0003-Y
17	YC.WJ.LL000228	M30-HBW01500070-055030-3123
18	YC.ST.LL000112	M40-HC00450039-076020-0003-Y
19	BC.AG.SS000460	T30 Intelligent Flight Battery Upper Cover Module
20	BC.AG.SS000462	T30 Intelligent Flight Battery Cell Module
21	YC.JG.MQ000576	Battery Lower Cover Waterproof Gasket
22	YC.JG.TT000051	Battery Locking Piece Spring </td
23	YC.WJ.CC000139	Front Battery Front Buckle Axis
24	YC.JG.ZS000944	Button Rubber Support



T10 Intelligent Flight Battery Pt - 2




No.	Material Number	Material Name
1	YC.JG.YZ000194	Battery Upper Cover
2	YC.JG.ZS000943	Battery Upper Bracket
3	BC.AG.PP000231	Battery Main Board
4	YC.WJ.CC000139	Front Battery Front Buckle Axis
5	YC.JG.TT000051	Battery Locking Piece Spring
6	YC.JG.YZ000311	Front Battery Front Buckle
7	YC.JG.MY000283	Button Rubber
8	YC.JG.ZS000944	Button Rubber Support
9	YC.DZ.FB000014	Fuse







T30 Intelligent Flight Battery Pt - 3

No.	Material Number	Material Name
1	YC.JG.JS000006	Battery Handle
2	YC.JG.YZ000193	Battery Handle Upper Cover
3	YC.JG.BJ000581	Battery Handle Inner Liner
4	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
5	YC.JG.MY000281	Battery Handle Upper Cover Rubber Stopper
6	YC.JG.MY000284	Battery Upper Cover Corner Pad
7	YC.XJ.JZ000012	Battery Upper Cover Forward Rubber Pad
8	YC.ST.LL000113	M30-HPW01600100-095023-0003-Y
9	YC.ST.LL000112	M40-HC00450039-076020-0003-Y
10	YC.JG.MQ000576	Battery Lower Cover Waterproof Gasket
11	BC.AG.SS000460	T30 Intelligent Flight Battery Upper Cover Module
12	YC.JG.MY000314	Drain Hole Waterproof Ring
13	YC.ST.LL000112	M40-HC00450039-076020-0003-Y
14	YC.JG.MY000282	Battery Lower Rubber Pad
15	YC.JG.MQ000572	Battery Level Indication Sticker
16	YC.JG.ZS000942	Battery Button
17	YC.JG.MY000289	Battery Connector Sealing Ring
18	YC.WJ.LL000228	M30-HBW01500070-055030-3123
19	BC.AG.SS000462	T30 Intelligent Flight Battery Cell Module
20	BC.AG.SS000462	T30 Intelligent Flight Battery Cell Module



T30 Intelligent Flight Battery Pt - 4

No.	Material Number	Material Name
1	YC.JG.YZ000203	Battery Upper Cover
2	YC.JG.ZS000940	Battery Upper Bracket
3	BC.AG.PP000161	Battery Main Board
4	YC.WJ.CC000139	Front Battery Front Buckle Axis
5	YC.JG.TT000051	Battery Locking Piece Spring
6	YC.JG.YZ000311	Front Battery Front Buckle
7	YC.JG.MY000283	Button Rubber
8	YC.JG.ZS000944	Button Rubber Support
9	YC.DZ.UH000022	Fuse



T30 & T10 Intelligent Flight Battery

- Final Product

