<u>DEUTSCH 12 PIN CONNECTOR</u> <u>WIRE COLOR</u> <u>DEUTSCH PIN #</u>

12v BATTERY INPUT TO HEAD LIGHTS SWITCH - (NEEDS BATTERY 12v)	DARK BLUE	12 PIN - 1
PARKING LIGHTS SWITCH OUTPUT - (CONNECT AT RELAY)	PURPLE	12 PIN - 2
HEADLIGHTS SWITCH OUTPUT (DIMS) - (CONNECT AT RELAY)	BLACK	12 PIN - 3
HEAD LIGHTS SWITCH OUTPUT (BRIGHTS) - (CONNECT AT RELAY)	WHITE	12 PIN - 4
12v IGNITION INPUT TO TURN SIGNAL SWITCH - (NEEDS 12v IGNITION)	DARK GREEN	12 PIN - 5
RIGHT TURN SIGNAL SWITCH OUTPUT - (CONNECT AT CUSTOMER RELAYS)	RED	12 PIN - 6
LEFT TURN SIGNAL SWITCH OUTPUT - (CONNECT AT CUSTOMER RELAYS)	GRAY	12 PIN - 7
12v BATTERY INPUT TO HORN SWITCH - (NEEDS BATTERY 12V)	BROWN	12 PIN - 8
HORN SWITCH OUTPUT - (CONNECT AT CUSTOMER RELAY)	YELLOW	12 PIN - 9
		12 PIN - 10
		12 PIN - 11
		12 PIN - 12