

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
ENGINE	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
Cylinder block & all internal parts*			
Cylinder heads & all internal parts*			
Engine mounts			
Flywheel			
Intake & exhaust manifolds			
Oil pan (if damaged by the failure of an internal lubricated part)			
Oil pump			
Turbocharger & Intercooler			
Timing belt / chain, balancer belt & tensioner (maintenance required as per Owner's manual)			
Valve train & valve cover (if damaged by the failure of an internal lubricated part)			
ENGINE - Electric			
Alternator			
Engine wiring harnesses			
Ignition coil			
Oil pressure sender unit			
Starter			
Voltage regulator			
ENGINE - Cooling			
Cooling fan			
Cooling fan thermostwitch			
Cooling fan timer			
Radiator			
Radiator cap			
Thermostat housing & gasket			
Thermostat, vacuum & coolant hoses			
Water pump			
ENGINE - Emissions			
Barometric pressure sensor			
Catalytic converter		8 yr / 130,000 km	
Crank angle sensor			
Crankshaft speed sensor			
EFI main relay			
Electric load detector			
Engine control module		8 yr / 130,000 km	
Evaporative emission two-way valve			
Exhaust Gas Recirculation (EGR) system			
Fast idle thermo valve			
Fuel tank pressure sensor			
Idle air control valve			
Injector resistors			
Injectors			
Intake air temperature sensor			
Knock sensor			
Map sensor			
Oxygen sensor			
Spark detection module			
Throttle body			
Throttle position sensor			

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
ABS / VSA	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
High pressure hoses			
Low pressure hoses			
Modulator & accumulator			
Power unit pump			
Pressure switch			
BRAKES			
Booster & check valve			
Calipers – front & rear*			
Master cylinder & wheel cylinder			
Metal lines & fittings			
Parking brake linkage & cables			
Proportioning valves			
Rotors			
CLUTCH			
Hydraulic line & cable			
Master cylinder			
Pressure plate			
Slave cylinder			
CRUISE CONTROL AND ACC			
Actuator & valve			
Adaptive cruise control unit			
Check valve			
Collision mitigation system			
Module			
TRANSAXLE / TRANSMISSION			
Automatic transmission cooler			
Control module			
CV joints			
CV boots & bands			
Differential case & all internal parts			
Drive shafts			
External shift linkage(s)			
Final drive housing & all internal parts			
Gearshift lever for manual transmission			
Lock-up control solenoid			
Paddle shifters			
Pressure control solenoid			
Pressure switch			
Shift control solenoid			
Speed pulser			
Torque converter on automatic transmission			
Transmission assembly & all internal lubricated parts*			
Transmission mounts			
Yaw-rate sensor			

\* Customer maintenance required as per Maintenance Minder

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
SUSPENSION	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
Ball joints			
Coil spring			
Compensator arms & trailing arms			
Control arms			
Front & rear beams			
Knuckles			
Radius rods & bushings			
Rear hub & bearings			
Shafts & bushings			
Shocks, struts & dampers			
Stabilizer bar			
Stabilizer bushings & links			
Strut mounts & bearings			
Wheel bearings			
STEERING			
EPS motor			
Output & return hoses			
Power steering pump / motor			
Steering column			
Steering gear housing & all internal parts			
Steering rack assembly			
Steering shaft			
Steering shaft gearbox connector			
Tie rods & tie rod ends			
4-WHEEL DRIVE SYSTEM / AWD			
4-wheel drive dual pump assembly			
4-wheel drive transfer case & all internal parts			
CV joints			
CV boots & bands			
Propeller shaft U-joints			
Rear differential assembly*			
Rear differential mounts			
Rear differential propeller shaft & centre bearing			
FUEL - SYSTEM			
Complete exhaust system			
Fuel filler neck & cap			
Fuel pressure regulator			
Fuel pump			
Fuel sending unit			
Fuel tank			
Metal fuel lines			
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)			
Airbags (SRS)			
Airbag module			
All SRS sensors			
Seat belts and buckles			
SRS harness			

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
AIR CONDITIONING			
Accumulator			
Air mix control motor & cable			
Blower & function switch			
Blower motor & resistor			
Compressor / Clutch assembly & seal			
Condenser assembly & receiver assembly			
Condenser fan			
Evaporator			
Expansion valve			
Field coil			
Function control motor			
Idler pulley			
Pipes & hoses			
Recirculation control motor			
Thermal protector			
Thermostatic switch			
Wire harness, diodes			
HEATING			
Heater control			
Heater core			
Pipes & hoses			
Water valve cable			
Wire harness, diodes			
DOOR & BODY			
Antenna mast or XM antenna mast			
Door latch			
Door lock cylinders			
External trim, body seals, wheel rims & studs, glass, paint, interior trim, upholstery & seat construction. Surface corrosion of body panels (unlimited distance)			
Hinges			
Mechanical moonroof components			
Power door lock actuator			
Release / Control cables for seats, trunk or hatch release, hood & fuel filler door			
Seat belt chime			
Seat heater			
Sideview power mirror actuators			
Sideview power mirror defrosters			
Window regulators			
SECURITY SYSTEM			
Immobilizer			
Harness			
Security transmitter			

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
ELECTRICAL			
Active Noise Cancellation (ANC)			
Adaptive front lighting system			
All bulletin related software updates			
All cameras			
All genuine Honda electrical accessories			
Audio system, LCD displays, DVD, DVD-A, DVD-ROM, MP3, WMA, tuner, SiriusXM® Canada Satellite Radio, auxiliary input jacks, clock			
Automatic day / night rearview mirror			
Battery Management System (BMS)			
Bulbs – 1 yr / 20 000 km			
Cooling fan motor(s)			
Fuse box – dash & under hood			
HandsFreeLink™ & HomeLink®			
Hard Disk Drive (HDD)			
Honda Satellite-Linked Navigation System™			
Honda Sensing™ Technologies			
Ignition switch, headlight switch, pushbutton starter switch, wiper blade switch			
Illuminated steering wheel-mounted controls			
Keyless entry system			
Main & sub wiring harness			
Meter & displays			
Microphones			
Resistors / transistors			
Solenoids & relays except those related to emissions			
Thermo pressure switches			
Tire Pressure Monitoring System (TPMS)			
Washer level warning sensor			
Washer pump – front & rear			
Windshield washer reservoir front & rear, headlight nozzles			
Wiper linkage			
SENSORS			
All electrical sensors			
CONTROL UNITS			
All control units			
SEALS & GASKETS			
All seals & gaskets on covered parts			
MANUALLY OPERATED SWITCHES			
All manually operated switches			
MOTORS			
All electrical motors			
FLUIDS & OILS			
On all covered repairs			

	INCLUDED WITH YOUR VEHICLE	HONDA PLUS	
	FACTORY WARRANTY 3 YRS / 60,000 KM	POWERTRAIN 8 YR / 160,000 KM	COMPREHENSIVE PROTECTION PLAN
HYBRID / ELECTRIC SYSTEM			
Ambient air temperature sensors			
Battery assembly (including all internal components)			
Battery charger (including battery charger cables)			
Battery charger control module			
Battery condition monitor module (including software upgrades)			
Battery pack coolant pump assembly			
Battery current sensor			
Battery module service connector			
Brake pedal position sensor			
Brake pedal reaction force system			
Busbars			
Drive motor stators and rotors (including all internal components and position sensors)			
Generator position sensor			
Generator rotor			
Generator stator			
Generator temperature sensor			
High speed motor power inverter module fan control relay			
High voltage and bypass contactors, resistor and fuse			
High voltage power cables			
Motor and gear powered brake cylinder / actuator			
Motor commutation sensor			
Motor control module (including all internal components)			
Motor control module / Battery pack coolant radiator			
Motor control module coolant expansion tank			
Motor control module coolant pump assembly			
Motor control module relay			
Motor current sensor			
Motor drive module capacitor			
Motor power inverter module (including all internal components)			
Motor power inverter module / Battery module fan assembly			
Traction motor rotor position sensor			
Voltage converter module			
Water pump assembly			