



THE ORIGINAL  
**roller conveyor**  
SENSOR

## The sensor “sees” the box... but do you see the sensor?

The sensor is there...you just can't see it. It's positioned right between the rollers underneath the box. By mounting the sensor between the rollers instead of on the side of the conveyor, you virtually eliminate the risk of sensor damage by items improperly positioned on the conveyor or next to the conveyor. And eliminating damaged sensors translates into a lot less machine downtime...

The best part? The installation for the Telemecanique Sensors XUY roller conveyor sensor can be summed up in just three short words: Position...click....done! Reliable detection in less time than it takes to read this ad!

Who should you trust for your roller conveyor sensor solutions?



**XUY Roller Conveyor Sensor**  
No foreground or background  
limitations. Detection is effective  
the entire width of the conveyor.  
[www.tesensors.com/XUY](http://www.tesensors.com/XUY)

Simply easy!



**Telemecanique**  
Sensors