



Contents:
1) WOCD



Installation:


1) Locate the prefabricated vent latch location on the left side stile.




2) Insert the WOCD Device at an angle with the Hook Side First and Up and into the Jamb Holder Oval Shaped Hole.



3) Press the Bottom of WOCD Device until it Snaps Securely Into the prefabricated location



Operation:
Raise Sash Until WOCD limits travel.
Depress Red Flipper to Allow Sash to Pass By.
Red Flipper will Reset upon Travel Downward by Sash



To Operate the Window and WOCD:

IMPORTANT: CHECK OPERATION OF WINDOW AND WOCD

- Unlock the window and raise the sash normally. The sash will contact the limit devices to restrict full operation.
- Press Red Tabs inward while lifting the sash to allow full opening.
- Close the sash, the limit devices should automatically reset. Raise the sash to the limit devices. The WOCD should stop window movement.

Warning: If limit device does not automatically reset, close the sash and lock the window.
Contact Lawrence Industries, Inc by telephone: 336-474-6754 or contact your Contractor or Salesperson.

Warning:

- Failure to follow installation and maintenance instructions carefully may allow for accidental falls.
- WOCDs are not a substitute for careful supervision of children.
- Keep the WOCDs engaged unless exit needed for use in an emergency.
- Windows with WOCDs installed will block escape in Fire or Emergency unless released.
- WOCDs are not a security device that provides intrusion protection.
- Maintain and check operation of WOCDs monthly. Replace the WOCDs if not operating correctly.
- Instruct household members age six and older how to operate WOCDs in case of emergency.
- Window Opening Control Devices are designed to restrict the window opening to prevent accidental falls by children. When engaged, WOCDs must limit the sash operation so that a 4" rigid sphere cannot pass through a clear opening.
- Check the WOCD upon receipt to make sure the device is securely attached to the window.