

ROBOJETFLOSS CONNECTING OPTIONS

RoboJetFloss machines are equipped with NEMA L5-20 cable by default. However, it is possible to connect the machine to different power outlet sockets using the following options:

CABLES

NEMA 5-20P — IEC320 C19 cable or NEMA 5-15P — IEC320 C19 cable:



ADAPTERS/PIGTAILS

NEMA L5-20R — NEMA 5-20P adapter or NEMA L5-20R — NEMA 5-20P pigtail:

