

Set up

Leveling

Levels are on the front and left side of trailer.

Level side to side first. Most sites are usually pretty level. Wood blocks are provided if needed.



Chock Wheels / Stabilize



Install wheel chocks as shown. In front and back of tire. This help stabilize the camper too.

Level Front to Back

Make sure camper wheel chocks are in place first. Unhook camper. Then level front to back with Tongue Jack.

Stabilizer Jacks



The driver and crank are inside of storage compartment. All our campers have some version of this stabilizing jack. Using the tool provided, lower the jack to the ground. These need to be snug, but they are not made to lift the camper. It prevents the camper from moving as much when people are moving around inside.

Water Hookup



Hook up the water. Always use the white hose for camper connection. We provide the hose.

Electrical Hookup



When you get to the campground, you will find an electrical box such as this. Shut off all breakers, plug in the camper, then turn breakers on. Use the 3 prong 30amp plugin.

Turn on your A/C, check fridge, & RELAX!!

Setup is now complete!