

INSTRUCTION MANUAL

For more tips and instructional videos, visit: www.lceGenieTips.com

IMPORTANT SAFETY INSTRUCTIONS:

- Only use Ice Genie™ Cube Maker as described in the manual
- Always store in a clean and dry place
- Ice Genie™ Cube Maker is **top rack** dishwasher safe
- Keep away from extreme heat
- Ice Genie™ Cube Maker is NOT microwave safe
- Made with BPA free material



USING THE ICE GENIE™ CUBE MAKER



Step 1: Insert the Cylinder into the Chamber. (Make sure the Cylinder reaches the bottom, creating a seal between the Cylinder and Chamber)

Note: Feel around the base of the chamber to see if the cylinder is properly seated.



Step 2: Fill water into the channel at the top of the Chamber. Fill until water reaches just above the top row of cubes.

Note: Pour out any water that overflows into the upper channel.



Step 3: Snap the Lid onto the Ice Genie[™] Cube Maker. Place into freezer until all the water is frozen. (4-6 hours)



Step 4: Once frozen, remove Ice Genie™ Cube Maker from the freezer. Remove the Lid, then firmly squeeze the Chamber on all sides.



Step 5: Remove any loose ice that has formed on the upper Chamber. Twist the Cylinder left/right until it is free. Then pull upward to remove it from the Chamber. If the Cylinder is difficult to remove, wait 30 seconds and repeat step 4/5.



Step 6: Once Cylinder is removed, squeeze the Chamber, releasing all the ice cubes into the middle area.

ADDITIONAL BATCHES



Step 1: After all the ice cubes are released, put the Cylinder back into the Chamber by pushing it into the Ice Genie™ Cube Maker. Move the cubes out of the way by twisting the Cylinder back and forth as you work the cylinder all the way

Note: Feel around the base of the chamber to see if the cylinder is properly seated.



After the Cylinder is fully seated in the Ice Genie TM Cube Maker, simply refill the channels of the Chamber, leaving the already made cubes in the center of the Cylinder.

Once the Chamber is fully filled, repeat steps 3-6.

Ice Genie™ Cube Maker can store up to three batches of ice at a given time.

CLEANING



Ice Genie™ Cube Maker can be cleaned by hand with warm soapy water and a sponge. Rinse thoroughly before use. The Ice Genie™ Cube Maker can also be washed in the top rack of a dishwasher.