

415 Nelson Place
La Crosse, WI 54601
608-785-1232
customerservice@chromacollections.com



TECHNICAL BULLETIN | RE: Cleaning and Care Recommendations

PRODUCTS COVERED

Decks Acoustical Panels

CLEANING RECOMMENDATIONS:

1. Dust or loose dirt may be removed using soft brush or by vacuuming with upholstery attachment.
2. Use care with both above methods to brush lightly and in single direction to avoid rubbing dust or dirt into surface.
3. If necessary, gently wipe with lightly dampened clean white cloth. Mild, non-staining detergents may also be used. Avoid bulk water, moisture, and other cleaning chemicals.

CARE:

1. Do not expose panels to abnormal conditions including, but not limited to: excessive dust, fire, smoke, chemical fumes, greases or oils, vibrations, presence of standing water, or moisture and excessive humidity coming into direct contact with the panels, such as could result from building leaks, condensation, splashing of water or any other sources of abnormal conditions.
2. Environmental conditions must be maintained with temperatures between 32°F (0°C) and 85°F (30°C) with relative humidity levels not exceeding 80%.
3. Decks Acoustical Panels shall not be used to support any other materials or equipment, including light fixtures, speakers, air diffusers, or security cameras.