

# Signalink™ USB Product Guide

This document can be used to find the Signalink USB, Radio Cable, and Jumper Module part number that is needed for a given radio. You can search this document for your radio model using your viewer's "Find" feature (CTRL-F), or select your radio manufacturer from the Bookmarks or menu below. Radios are organized alphabetically by manufacturer and listed in alpha-numeric order. If your radio isn't listed, then please contact us and we will confirm the part numbers that are needed.

Every effort has been made to insure that the information provided in this document is accurate. However, mistakes do sometimes happen, and it is simply not possible for us to be aware of the idiosyncrasies of every available radio. If you have any doubts or questions about the information provided here, or if you're not sure which part numbers you need for your radio, then please contact us before ordering.

Please note the following when selecting the part numbers for your radio:

- The Signalink USB is always supplied with a radio cable and the part number shown determines which cable is provided. For example, Signalink USB p/n "SLUSB6PM" includes radio cable p/n "SLCAB6PM".
- When multiple cable options are available, the Data, Accy or other rear panel connections will generally be listed first since they are usual preferred over the Mic jack connection. If the Signalink USB or Radio Cable part number is not noted as "DATA", "ACCY", "REAR", or "PACKET", then it is for use with the radio's Mic jack.
- If a Jumper Module part number is not listed for your radio or you see "Jumper Wires" shown, then you will need to configure the Signalink using the supplied push-in jumper wires.
- If you see "Contact us for cable wiring information", then please drop us an email through our Contact Form and we'll get back to you.
- Be sure to read any notes/footnotes shown for your radio as these detail important radio requirements or restrictions.

Select a Radio Manufacturer:

<b>ADI</b>	<b>Alinco</b>	<b>Anytone</b>
<b>Azden</b>	<b>Baofeng / BTECH</b>	<b>Bridgecom</b>
<b>Comm Radio</b>	<b>Connect Systems</b>	<b>CRT</b>
<b>Drake</b>	<b>Elecraft</b>	<b>Flex Radio</b>
<b>Icom</b>	<b>Jetstream</b>	<b>Jopix</b>
<b>JRC</b>	<b>Kenwood</b>	<b>Kirisun</b>
<b>Lab599</b>	<b>Leixen</b>	<b>Luiton</b>
<b>Midland</b>	<b>Motorola</b>	<b>Polmar</b>
<b>Powerwerx</b>	<b>President</b>	<b>Puxing</b>
<b>QYT</b>	<b>Radioddity</b>	<b>Radio Shack</b>
<b>Ranger</b>	<b>Raytheon</b>	<b>Retevis</b>
<b>Sainsonic</b>	<b>SGC</b>	<b>Ten-Tec</b>
<b>TYT</b>	<b>uBITX</b>	<b>USDX</b>
<b>Vero VGC</b>	<b>Wouxun</b>	<b>Xiegu</b>
<b>Yaesu</b>		

## ADI

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
AR-146	SLUSB8R	SLCAB8R	Jumper Wires
AR-147	SLUSB8R	SLCAB8R	Jumper Wires
AR-446	SLUSB8R	SLCAB8R	Jumper Wires

## ALINCO

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
ALD-24T	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-22HT	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-22T	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-72T	SLUSB8R	SLCAB8R	SLMOD8RK
DJ-47E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-47T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-G29T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-G7T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-S17	SLUSBVXY	SLCABVXY	SLMODHT
DJ-S47E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V17	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V27T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V57E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V57T	SLUSBVXY	SLCABVXY	SLMODHT
DR-03T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-06T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-110T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-112T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-130T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135E	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135EMKIII	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135FXE	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135T	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135TMKIII	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135LH	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-138	SLUSB8R	SLCAB8R	SLMOD8RK
DR-138HE	SLUSB8R	SLCAB8R	SLMOD8RK
DR-138HT	SLUSB8R	SLCAB8R	SLMOD8RK
DR-150	SLUSB8R	SLCAB8R	SLMOD8RK
DR-235T	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK

## ALINCO (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
DR-235TMKIII	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-430T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435E	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435EMKIII	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435T	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435TMKIII	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435FXE	SLUSB135	SLCAB135	SLMOD6PM <sup>8</sup>
	SLUSB8R	SLCAB8R	SLMOD8RK
DR-438	SLUSB8R	SLCAB8R	SLMOD8RK
DR-438HE	SLUSB8R	SLCAB8R	SLMOD8RK
DR-510T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-570T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-590T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-592T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-599T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-600T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-605E	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-605T	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-610E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-610T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-620E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-620T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-635	SLUSB8R	SLCAB8R	SLMOD8RK
DR-638HE	SLUSB8R	SLCAB8R	SLMOD8RK
DR-735E	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-735T	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-1200	SLUSB8R	SLCAB8R	SLMOD8RK
DR-B185HE	SLUSB8R	SLCAB8R	SLMOD8RK
DR-B185HT	SLUSB8R	SLCAB8R	SLMOD8RK
DR-CS10	SLUSB8R	SLCAB8R	SLMOD8RK
DR-CS25	SLUSB8R	SLCAB8R	SLMOD8RK
DR-M03R	SLUSB8R	SLCAB8R	SLMOD8RK
DR-M06R	SLUSB8R	SLCAB8R	SLMOD8RK
DR-MD520E	SLUSBRJ4	SLCABRJ4	SLMOD578
DR-MD520T	SLUSBRJ4	SLCABRJ4	SLMOD578
DX-70	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70EH	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70T	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70TH	SLUSB8R	SLCAB8R	SLMOD8RK
DX-77	SLUSB8R	SLCAB8R	SLMOD8RK

## ALINCO (continued)

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DX-SR8T	SLUSB8R	SLCAB8R	SLMOD8RK
DX-SR8E	SLUSB8R	SLCAB8R	SLMOD8RK

## ANYTONE

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DX-SR9	SLUSB8R	SLCAB8R	SLMOD8RK
ARES II	SLUSB4R	SLCAB4R	Jumper Wires
DORIS	SLUSB6R	SLCAB6R	Jumper Wires
HERA	SLUSBRJ4	SLCABRJ4	Jumper Wires
METIS	SLUSB4R	SLCAB4R	Jumper Wires
SMART II	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-318UV	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-398UV	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-3208UVII	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-500M	SLUSB6R	SLCAB6R	Jumper Wires
AT-500MII NRC	SLUSB6R	SLCAB6R	Jumper Wires
AT-588	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-708	SLUSB6R	SLCAB6R	Jumper Wires
AT-888	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-778UV	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-779UV	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-5189	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-5289	SLUSB6R	SLCAB6R	Jumper Wires
AT-5555+	SLUSB4R	SLCAB4R	Jumper Wires
AT-5555n	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-5555nII	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-5888UV	SLUSBRJ4	SLCABRJ4	Jumper Wires
AT-6666	SLUSB6R	SLCAB6R	Jumper Wires
AT-D578UV	SLUSBRJ4	SLCABRJ4	SLMOD578
AT-D578UV PRO	SLUSBRJ4	SLCABRJ4	SLMOD578
AT-D578UV+	SLUSBRJ4	SLCABRJ4	SLMOD578
AT-D868UV	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-D878	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-D878S	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-D878UV	SLUSBHTW	SLCABHTW	SLMOD6PM
AT-D878UV+	SLUSBHTW	SLCABHTW	SLMOD6PM

## AZDEN

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
PCS 5000	SLUSB8R	SLCAB8R	Jumper Wires
PCS 6000	SLUSB8R	SLCAB8R	Jumper Wires
PCS 7000	SLUSB8R	SLCAB8R	Jumper Wires

## BAOFENG / BTECH

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
BF-320	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-490	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-520	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-530	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-568	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-658	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-758A	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-758S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-666S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-777	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-777S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-888S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-999	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-999S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8+	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8HP	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F9V2	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V6	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V7	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V8	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V85	SLUSBHTW	SLCABHTW	SLMOD6PM
C-150	SLUSBHTW	SLCABHTW	SLMOD6PM
DMR-6x2	SLUSBHTW	SLCABHTW	SLMOD6PM
DMR-6x2 PRO	SLUSBHTW	SLCABHTW	SLMOD6PM
FRS-A1	SLUSBHTW	SLCABHTW	SLMOD6PM
FRS-B1	SLUSBHTW	SLCABHTW	SLMOD6PM
GMRS-50V2	SLUSBRJ4	SLCABRJ4	Jumper Wires
GMRS-V1	SLUSBHTW	SLCABHTW	SLMOD6PM
GMRS-V2	SLUSBHTW	SLCABHTW	SLMOD6PM
GMRS-PRO	SLUSBHTW <sup>9</sup>	SLCABHTW <sup>9</sup>	SLMOD6PM
GT-3	SLUSBHTW	SLCABHTW	SLMOD6PM
MURS-V1	SLUSBHTW	SLCABHTW	SLMOD6PM
MURS-V2	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-3	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-3R+	SLUSBHTW	SLCABHTW	SLMOD6PM

## BAOFENG / BTECH (continued)

<u>Radio</u>	<u>SignalLink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
UV-5	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5R	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RA	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RB	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RC	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RD	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RE	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RE+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RX3	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5X3	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-8	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-8D	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-9R+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17L	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17MAX	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17PRO	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17R	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17v2	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-17PROGPS	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-82C	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-82HP	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-B5	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-25x2	SLUSBHTY	SLCABHTY	Jumper Wires
UV-25x4	SLUSBHTY	SLCABHTY	Jumper Wires
UV-50x2	SLUSBRJ4	SLCABRJ4	Jumper Wires
UV-50x3	SLUSB6PM <sup>5</sup>	SLCAB6PM <sup>5</sup>	SLMOD6PM
	SLUSB8PM (ACC)	SLCAB8PM (ACC)	Jumper Wires
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
UV-82	SLUSBHTW	SLCABHTW	SLMOD6PM

## BRIDGECOM

<u>Radio</u>	<u>SignalLink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
BCH-220	SLUSBHTW	SLCABHTW	SLMOD6PM
BCH-270	SLUSBHTW	SLCABHTW	SLMOD6PM
BCH-700	SLUSBHTW	SLCABHTW	SLMOD6PM
BCM-144	SLUSBRJ4	SLCABRJ4	Jumper Wires
BCM-220	SLUSBRJ4	SLCABRJ4	Jumper Wires
BCM-440	SLUSBRJ4	SLCABRJ4	Jumper Wires
D-30	SLUSBHTW	SLCABHTW	SLMOD6PM
D-500	SLUSBHTW	SLCABHTW	SLMOD6PM

## COMM RADIO

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
CTX-10	SLUSB6PM (ACC)	SLCAB6PM (ACC)	SLMOD6PM

## CONNECT SYSTEMS

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
CS-108G	SLUSB6PM (ACC)	SLCAB6PM (ACC)	Jumper Wires
CS-800	SLUSBRJ4	SLCABRJ4	Jumper Wires
CS-800D	SLUSBRJ4	SLCABRJ4	Jumper Wires

## CRT

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
2000	SLUSBRJ4	SLCABRJ4	Jumper Wires
2000H	SLUSBRJ4	SLCABRJ4	Jumper Wires
2M	SLUSBRJ4	SLCABRJ4	Jumper Wires
4M	SLUSBRJ4	SLCABRJ4	Jumper Wires
7M	SLUSBRJ4	SLCABRJ4	Jumper Wires
Electro UV V3	SLUSBRJ4	SLCABRJ4	Jumper Wires
MegaPRO	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
Micron UV V2	SLUSBRJ4	SLCABRJ4	Jumper Wires
SS6900	SLUSB4R	SLCAB4R	Jumper Wires
SS7900	SLUSBRJ4	SLCABRJ4	Jumper Wires
SS9900	SLUSB6R	SLCAB6R	Jumper Wires
Smini	SLUSB4R <sup>10</sup>	SLCAB4R <sup>10</sup>	Jumper Wires

## DRAKE

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
TR-7	SLUSB4R	SLCAB4R	Jumper Wires
TR-22	SLUSB4R	SLCAB4R	Jumper Wires
TR-33	SLUSB4R	SLCAB4R	Jumper Wires
UV-3	SLUSB4R	SLCAB4R	Jumper Wires



## ELECRAFT

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
K2	SLUSB8R	SLCAB8R	SLMOD8RK
K3	SLUSBK3 (REAR)	SLCABK3 (REAR)	SLMODK3
	SLUSB8R	SLCAB8R	SLMOD8RK
K3/0-Mini	SLUSB8R	SLCAB8R	SLMOD8RK
K3/S	SLUSBK3 (REAR)	SLCABK3 (REAR)	SLMODK3
	SLUSB8R	SLCAB8R	SLMOD8RK
K4	SLUSBK3 (REAR)	SLCABK3 (REAR)	SLMODK3
	SLUSB8R	SLCAB8R	SLMOD8RK
KX2	SLUSBKX3	SLCABKX3	SLMODKX3
KX3	SLUSBKX3	SLCABKX3	SLMODKX3

## FLEX-RADIO

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
FLEX-1500	SLUSBRJ4	SLCABRJ4	Jumper Wires
FLEX-3000	SLUSBRJ4	SLCABRJ4	Jumper Wires
FLEX-5000	SLUSB8R	SLCAB8R	Jumper Wires

## ICOM

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
IC-22	SLUSB4R	SLCAB4R	SLMOD4RI
IC-22U	SLUSB8R	SLCAB8R	SLMOD8RI
IC-25	SLUSB8R	SLCAB8R	SLMOD8RI
IC-27	SLUSB8R	SLCAB8R	SLMOD8RI
IC-28	SLUSB8R	SLCAB8R	SLMOD8RI
IC-37A	SLUSB8R	SLCAB8R	SLMOD8RI
IC-38A	SLUSB8R	SLCAB8R	SLMOD8RI
IC-45	SLUSB8R	SLCAB8R	SLMOD8RI
IC-47	SLUSB8R	SLCAB8R	SLMOD8RI
IC-48	SLUSB8R	SLCAB8R	SLMOD8RI
IC-77	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-78	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-202	SLUSB4R	SLCAB4R	SLMOD4RI
IC-207H	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-208H	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-215	SLUSB4R	SLCAB4R	SLMOD4RI
IC-228	SLUSB8R	SLCAB8R	SLMOD8RI
IC-229	SLUSB8R	SLCAB8R	SLMOD8RI
IC-245	SLUSB4R	SLCAB4R	SLMOD4RI

## ICOM (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
IC-251A	SLUSB8R	SLCAB8R	SLMOD8RI
IC-251E	SLUSB8R	SLCAB8R	SLMOD8RI
IC-255	SLUSB8R	SLCAB8R	SLMOD8RI
IC-260	SLUSB8R	SLCAB8R	SLMOD8RI
IC-271	SLUSB8R	SLCAB8R	SLMOD8RI
IC-275A	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-280	SLUSB4R	SLCAB4R	SLMOD4RI
IC-281A	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-281E	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-281H	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-290	SLUSB8R	SLCAB8R	SLMOD8RI
IC-375	SLUSB8R	SLCAB8R	SLMOD8RI
IC-402	SLUSB4R	SLCAB4R	SLMOD4RI
IC-471	SLUSB8R	SLCAB8R	SLMOD8RI
IC-475	SLUSB8R	SLCAB8R	SLMOD8RI
IC-490	SLUSB8R	SLCAB8R	SLMOD8RI
IC-502	SLUSB4R	SLCAB4R	SLMOD4RI
IC-505	SLUSB8R	SLCAB8R	SLMOD8RI
IC-551	SLUSB4R	SLCAB4R	SLMOD4RI
IC-560	SLUSB8R	SLCAB8R	SLMOD8RI
IC-575A	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-575H	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-701	SLUSB4R	SLCAB4R	SLMOD4RI
IC-703	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-705	SLUSB705	SLCAB705	SLMODHT
IC-706	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-706MKII	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-706MKIIG	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-707	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-718	SLUSB13I (ACCY)	SLCAB13I (ACCY)	SLMOD13I
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-720	SLUSB8R	SLCAB8R	SLMOD8RI
IC-720A	SLUSB8R	SLCAB8R	SLMOD8RI
IC-725	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-726	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-728	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI

## ICOM (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
IC-729	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-730	SLUSB8R	SLCAB8R	SLMOD8RI
IC-735	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-736	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-737	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-738	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-740	SLUSB8R	SLCAB8R	SLMOD8RI
IC-745	SLUSB8R	SLCAB8R	SLMOD8RI
IC-746	SLUSB8PD (ACCY) <sup>2</sup> SLUSB8R	SLCAB8PD (ACCY) <sup>2</sup> SLCAB8R	SLMOD8PD SLMOD8RI
IC-746PRO	SLUSB6PM (DATA) SLUSB8PD (ACCY) <sup>2</sup> SLUSB8R	SLCAB6PM (DATA) SLCAB8PD (ACCY) <sup>2</sup> SLCAB8R	SLMOD6PM SLMOD8PD SLMOD8RI
IC-751	SLUSB8R	SLCAB8R	SLMOD8RI
IC-756	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-756PRO	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-756PROII	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-756PROIII	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-761	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-765	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-775	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-775DSP	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-781	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-820H	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-821H	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-901	SLUSB8R	SLCAB8R	SLMOD8RI
IC-910H	SLUSB6PM (DATA) SLUSB8PD (ACCY) SLUSB8R	SLCAB6PM (DATA) SLCAB8PD (ACCY) SLCAB8R	SLMOD6PM SLMOD8PD SLMOD8RI
IC-970**	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI

\*\*The 13-pin Accy Port on the IC-970 uses a non-standard pin-out and CANNOT be used with our SLCAB13I Accy Port cable.

## ICOM (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
IC-1201	SLUSB8R	SLCAB8R	SLMOD8RI
IC-1271	SLUSB8R	SLCAB8R	SLMOD8RI
IC-1275	SLUSB8R	SLCAB8R	SLMOD8RI
IC-2000	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2100	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2100H	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2200H	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2300H	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2400	SLUSB8R	SLCAB8R	SLMOD8RI
IC-2500	SLUSB8R	SLCAB8R	SLMOD8RI
IC-2700	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2720H	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2730A	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2730E	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2800	SLUSB6PM (DATA) <sup>1</sup>	SLCAB6PM (DATA) <sup>1</sup>	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-2820	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-3200	SLUSB8R	SLCAB8R	SLMOD8RI
IC-3210	SLUSB8R	SLCAB8R	SLMOD8RI
IC-3220	SLUSB8R	SLCAB8R	SLMOD8RI
IC-3230	SLUSB8R	SLCAB8R	SLMOD8RI
IC-5011	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-7000	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB13I (ACCY) <sup>1</sup>	SLCAB13I (ACCY) <sup>1</sup>	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-7100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB13I (ACCY) <sup>1</sup>	SLCAB13I (ACCY) <sup>1</sup>	SLMOD13I
	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-7200	SLUSB13I (ACCY) <sup>1</sup>	SLCAB13I (ACCY) <sup>1</sup>	SLMOD13I
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7300	SLUSB13I (ACCY) <sup>1</sup>	SLCAB13I (ACCY) <sup>1</sup>	SLMOD13I
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7400	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7410	SLUSB13I (ACCY) <sup>1</sup>	SLCAB13I (ACCY) <sup>1</sup>	SLMOD13I
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7600	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7610	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7700	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-7800	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI

## ICOM (continued)

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
IC-9100	SLUSB6PM (DATA) SLUSB13I (ACCY) <sup>1</sup> SLUSB8R	SLCAB6PM (DATA) SLCAB13I (ACCY) <sup>1</sup> SLCAB8R	SLMOD6PM SLMOD13I SLMOD8RI
IC-9700	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD8PD SLMOD8RI
IC-F110	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-F121	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-M600	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M700PRO	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M710	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M801E	SLUSB135 (ACCY)	SLCAB135 (ACCY)	Jumper Wires
IC-M802	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M803	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-T7H	SLUSBHTI	SLCABHTI	SLMODHT
IC-V86	SLUSBHTI	SLCABHTI	SLMODHT
IC-V3500	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-V8000	SLUSBRJ4	SLCABRJ4	SLMODR4I
IC-W32A	SLUSBHTI	SLCABHTI	SLMODHT
ID-51A	SLUSBHTI	SLCABHTI	SLMODHT
ID-52	SLUSBHTI	SLCABHTI	SLMODHT
ID-800H	SLUSB8PM (DATA) SLUSBRJ4	SLCAB8PM (DATA) SLCABRJ4	Jumper Wires SLMODR4I
ID-880	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4I
ID-4100A	SLUSBRJ4	SLCABRJ4	SLMODR4I
ID-4100E	SLUSBRJ4	SLCABRJ4	SLMODR4I
ID-5100A	SLUSBRJ4	SLCABRJ4	SLMODR4I
ID-5100E	SLUSBRJ4	SLCABRJ4	SLMODR4I

## JETSTREAM

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
JT-270MH	SLUSBRJ4	SLCABRJ4	Jumper Wires
JT-220M	SLUSB8R	SLCAB8R	SLMOD8RK

## JOPIX

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
CB-514	SLUSBHTW	SLCABHTW	SLMOD6PM

## JRC

<b><u>Radio</u></b>	<b><u>Signalink USB</u></b>	<b><u>Radio Cable Only</u></b>	<b><u>Jumper Module</u></b>
JSB-176	SLUSB8R	SLCAB8R	Jumper Wires
JST-135	SLUSB8R	SLCAB8R	SLMOD8RY
JST-145	SLUSB8R	SLCAB8R	SLMOD8RY
JST-245	SLUSB8R	SLCAB8R	SLMOD8RY

## KENWOOD

<b><u>Radio</u></b>	<b><u>Signalink USB</u></b>	<b><u>Radio Cable Only</u></b>	<b><u>Jumper Module</u></b>
NXR-810	SLUSBRJ4	SLCABRJ4	SLMODR4K
TH-D7	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7AG	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D75A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D75E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F6	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F6A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F7	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F7E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-G71	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-G71A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-G71E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2AT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2ET	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K20	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21BT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21T	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22AT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22E	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-80	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	Jumper Wires
TK-90	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-240	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-250	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-255	SLUSBHTW	SLCABHTW	SLMOD6PM

## KENWOOD (continued)

<b><u>Radio</u></b>	<b><u>Signalink USB</u></b>	<b><u>Radio Cable Only</u></b>	<b><u>Jumper Module</u></b>
TK-260	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-260G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-270	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-270G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-272G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-278	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-278G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-340	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-349	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-350	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-353	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-360	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-360G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-370	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-370G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-373G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-378	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-378G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-430	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-431	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-715	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-760G	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-760HG	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-762HG	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-805D	SLUSBRJ1	SLCABRJ1	Jumper Wires
TK-863G	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-2100	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2102	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2107	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2118	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2160	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3100	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3101	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3102	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3107	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3118	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3160	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-7102H	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7108HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7108M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7162E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7180E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7189E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8108HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8108M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8160E	SLUSBRJ4	SLCABRJ4	SLMODR4K

## KENWOOD (continued)

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
TK-8160M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8162E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8180E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8189	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-M707	SLUSB8R	SLCAB8R	SLMOD8RK
TM-201	SLUSB8R	SLCAB8R	SLMOD8RK
TM-211	SLUSB8R	SLCAB8R	SLMOD8RK
TM-221	SLUSB8R	SLCAB8R	SLMOD8RK
TM-231	SLUSB8R	SLCAB8R	SLMOD8RK
TM-241	SLUSB8R	SLCAB8R	SLMOD8RK
TM-251	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-255	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-261	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-271**	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-271A**	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
<b>**European models only. All other TM-271 / TM-271A models must use the RJ-45 Mic jack.</b>			
TM-281	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-321	SLUSB8R	SLCAB8R	SLMOD8RK
TM-331	SLUSB8R	SLCAB8R	SLMOD8RK
TM-401	SLUSB8R	SLCAB8R	SLMOD8RK
TM-421	SLUSB8R	SLCAB8R	SLMOD8RK
TM-431	SLUSB8R	SLCAB8R	SLMOD8RK
TM-441	SLUSB8R	SLCAB8R	SLMOD8RK
TM-451	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-455	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-461	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-481A	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-521	SLUSB8R	SLCAB8R	SLMOD8RK
TM-531	SLUSB8R	SLCAB8R	SLMOD8RK
TM-541	SLUSB8R	SLCAB8R	SLMOD8RK
TM-621	SLUSB8R	SLCAB8R	SLMOD8RK
TM-631	SLUSB8R	SLCAB8R	SLMOD8RK
TM-641	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-642	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-701	SLUSB8R	SLCAB8R	SLMOD8RK
TM-721	SLUSB8R	SLCAB8R	SLMOD8RK
TM-731	SLUSB8R	SLCAB8R	SLMOD8RK
TM-732	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-733A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-741	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-742	SLUSBRJ4	SLCABRJ4	SLMODR4K



## KENWOOD (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
TM-941	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-942	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-2530	SLUSB8R	SLCAB8R	SLMOD8RK
TM-2550	SLUSB8R	SLCAB8R	SLMOD8RK
TM-2570	SLUSB8R	SLCAB8R	SLMOD8RK
TM-3530	SLUSB8R	SLCAB8R	SLMOD8RK
TM-D700	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D700A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710E	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710G	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710GA	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-G707	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V7A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V71A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V71E	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V708	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TR-50	SLUSB8R	SLCAB8R	SLMOD8RK
TR-751	SLUSB8R	SLCAB8R	SLMOD8RK
TR-851	SLUSB8R	SLCAB8R	SLMOD8RK
TR-7200A	SLUSB4R	SLCAB4R	SLMOD4RK
TR-7400A	SLUSB4R	SLCAB4R	SLMOD4RK
TR-7500	SLUSB4R	SLCAB4R	SLMOD4RK
TR-7800	SLUSB6R	SLCAB6R	Jumper Wires
TR-7850	SLUSB6R	SLCAB6R	Jumper Wires
TR-7930	SLUSB6R	SLCAB6R	Jumper Wires
TR-7950	SLUSB6R	SLCAB6R	Jumper Wires
TR-8400	SLUSB6R	SLCAB6R	Jumper Wires
TR-9000	SLUSB6R	SLCAB6R	Jumper Wires
TR-9130	SLUSB6R	SLCAB6R	Jumper Wires
TRC-80	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	Jumper Wires SLMOD8RK
TS-50	SLUSB8R	SLCAB8R	SLMOD8RK
TS-60	SLUSB8R	SLCAB8R	SLMOD8RK
TS-120S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-130S	SLUSB4R	SLCAB4R	SLMOD4RK

## KENWOOD (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
TS-130SE	SLUSB4R	SLCAB4R	SLMOD4RK
TS-140S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-180S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-430S	SLUSB8R	SLCAB8R	SLMOD8RK
TS-440S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-440SAT	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-450	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-480HX	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TS-480SAT	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TS-511S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-520	SLUSB4R	SLCAB4R	SLMOD4RK
TS-530	SLUSB4R	SLCAB4R	SLMOD4RK
TS-570	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-570D	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-570DG	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-570S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-570SG	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-590S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-590SG	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-600	SLUSB4R	SLCAB4R	SLMOD4RK
TS-660	SLUSB8R	SLCAB8R	SLMOD8RK
TS-670	SLUSB8R	SLCAB8R	SLMOD8RK
TS-680S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-690	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-690S	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-700	SLUSB4R	SLCAB4R	SLMOD4RK
TS-701	SLUSB8R	SLCAB8R	SLMOD8RK
TS-711	SLUSB8R	SLCAB8R	SLMOD8RK
TS-780	SLUSB8R	SLCAB8R	SLMOD8RK
TS-790	SLUSB13K (ACCY)	SLCAB13K (ACCY)	SLMOD13K
	SLUSB8R	SLCAB8R	SLMOD8RK
TS-811	SLUSB8R	SLCAB8R	SLMOD8RK
TS-820	SLUSB4R	SLCAB4R	SLMOD4RK

## KENWOOD (continued)

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
TS-830	SLUSB4R	SLCAB4R	SLMOD4RK
TS-850	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-870	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-890S	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-930	SLUSB8R	SLCAB8R	SLMOD8RK
TS-940	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-950	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-990	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-2000	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-2000X	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TW-4000	SLUSB8R	SLCAB8R	SLMOD8RK
TW-4100	SLUSB8R	SLCAB8R	SLMOD8RK

## KIRISUN

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
PT-8100	SLUSBRJ4	SLCABRJ4	SLMODR4K

## LAB599

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
TX-500	SLUSBTX5	SLCABTX5	SLMOD6PM

## LEIXEN

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
VV-898S	SLUSBRJ4	SLCABRJ4	SLMODR4K
UV-25HX	SLUSBRJ4	SLCABRJ4	SLMODR4K

## LUITON

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
LT-590	SLUSBRJ4	SLCABRJ4	Jumper Wires

## MIDLAND

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
13-510	SLUSB4R	SLCAB4R	Jumper Wires

## MOTOROLA

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
CDM-1250	SLUSBRJ4	SLCABRJ4	Jumper Wires
CM200	SLUSBRJ4	SLCABRJ4	Jumper Wires
CM300	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM300	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM340	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM360	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM380	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM640	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM680	SLUSBRJ4	SLCABRJ4	Jumper Wires
GM1280	SLUSBRJ4	SLCABRJ4	Jumper Wires
CP200	SLUSBHTX	SLCABHTX	SLMODHTX

## POLMAR

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DB-50M	SLUSBRJ4	SLCABRJ4	Jumper Wires

## POWERWERX

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DB-750X	SLUSBRJ4	SLCABRJ4	Jumper Wires

## President

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
Lincoln II	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
Lincoln II+	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
Richard	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
Ronald	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires

## PUXING

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
PX-328	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-333	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-666	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-777	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-888	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-888K	SLUSBHTW	SLCABHTW	SLMOD6PM

## QYT

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
KT-780	SLUSBRJ4	SLCABRJ4	SLMODR4K
KT-980+	SLUSBRJ4	SLCABRJ4	SLMODR4K
KT-7900	SLUSBRJ4	SLCABRJ4	SLMODR4K
KT-8900D**	SLUSBHTY	SLCABHTY	Jumper Wires

\*\*This radio is reported to have a very slow switching time which makes it virtually impossible to use for Vara or Packet. It's possible that turning OFF menu 53 & 54 will fix this, but this has not been confirmed.

## RADIODDITY

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DB-25	SLUSBHTY	SLCABHTY	Jumper Wires
GD-77	SLUSBHTW	SLCABHTW	SLMOD6PM
QB25	SLUSBHTY	SLCABHTY	Jumper Wires
QB25PRO	SLUSBHTY	SLCABHTY	Jumper Wires
QB45	SLUSBRJ4	SLCABRJ4	SLMODR4K
QT60	SLUSBRJ4	SLCABRJ4	Jumper Wires

## RADIO SHACK

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
HTX-10	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
HTX-100	SLUSB8R	SLCAB8R	Jumper Wires
HTX-212	SLUSBRJ4	SLCABRJ4	Jumper Wires
HTX-242	SLUSBRJ4	SLCABRJ4	Jumper Wires

## Ranger

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
RCI-2950	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2950DX	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2950DX-CD	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2970	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2970N2	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2970N3	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-2970N4	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires
RCI-5054DX	SLUSB6R <sup>10</sup>	SLCAB6R <sup>10</sup>	Jumper Wires

## RAYTHEON

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
RAY-152	SLUSB8R	SLCAB8R	Jumper Wires

## RETEVIS

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
RT2	SLUSBHTW	SLCABHTW	SLMOD6PM
RT3	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5R	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5RV	SLUSBHTW	SLCABHTW	SLMOD6PM
RT8	SLUSBHTW	SLCABHTW	SLMOD6PM
RT23	SLUSBHTW	SLCABHTW	SLMOD6PM
RT82	SLUSBHTW	SLCABHTW	SLMOD6PM
RT-95	SLUSBRJ4	SLCABRJ4	Jumper Wires

## SAINSONIC

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
VV-898E	SLUSBRJ4	SLCABRJ4	SLMODR4K

## SGC

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
SGC-2000	SLUSB4R	SLCAB4R	Jumper Wires
SGC-2020	SLUSB8R	SLCAB8R	SLMOD8RK

## TEN-TEC

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
Argonaut V	SLUSB5PD (ACCY) SLUSB4R	SLCAB5PD (ACCY) SLCAB4R	SLMOD5PD SLMOD4RT
Argonaut VI	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
Corsair 561	SLUSB4R	SLCAB4R	SLMOD4RT
Delta II	SLUSB4R	SLCAB4R	SLMOD4RT
Eagle	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
Jupiter	SLUSB5PD (ACCY) SLUSB4R	SLCAB5PD (ACCY) SLCAB4R	SLMOD5PD SLMOD4RT
Omni VI	SLUSB4R	SLCAB4R	SLMOD4RT
Omni VII	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
Orion	SLUSB8PD (ACCY) SLUSB4R	SLCAB8PD (ACCY) SLCAB4R	SLMOD5PD SLMOD4RT
Orion II	SLUSB8PD (ACCY) SLUSB8R	SLCAB8PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
Orion 526	SLUSB4R	SLCAB4R	SLMOD4RT
Paragon	SLUSB4R	SLCAB4R	SLMOD4RT
Paragon II	SLUSB4R	SLCAB4R	SLMOD4RT
Patriot	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	Jumper Wires
Pegasus	SLUSB5PD (ACCY) SLUSB4R	SLCAB5PD (ACCY) SLCAB4R	SLMOD5PD SLMOD4RT
Scout	SLUSB4R	SLCAB4R	SLMOD4RT

## TYT

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
DM-380	SLUSBHTW	SLCABHTW	SLMOD6PM
DM-390	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-7800	SLUSBRJ1	SLCABRJ1	SLMODR1Y
TH-7900	SLUSBRJ1	SLCABRJ1	Jumper Wires
TH-9000D	SLUSBRJ4	SLCABRJ4	Jumper Wires
TH-9800	SLUSBRJ4	SLCABRJ4	Jumper Wires
TH-UV8000D	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-UV8000E	SLUSBHTW	SLCABHTW	SLMOD6PM

## uBITX

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
uBITX	SLUSBTRS	SLCABTRS	Jumper Wires

## USDX

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
uSDX	SLUSBHTY	SLCABHTY	Jumper Wires
TruSDX	SLUSBTRS	SLCABTRS	Jumper Wires
uSDX+	SLUSBHTW	SLCABHTW	SLMOD6PM

## VERO VGC

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
VR-N75	SLUSBHTW <sup>9</sup>	SLCABHTW <sup>9</sup>	SLMOD6PM
VR-N7500	SLUSBRJ4	SLCABRJ4	Jumper Wires
VR-6600PRO	SLUSB6PM <sup>5</sup>	SLCAB6PM <sup>5</sup>	SLMOD6PM
	SLUSB8PM (ACC)	SLCAB8PM (ACC)	Jumper Wires
	SLUSBRJ1	SLCABRJ1	SLMODR1Y



## WOXUN

<b><u>Radio</u></b>	<b><u>Signalink USB</u></b>	<b><u>Radio Cable Only</u></b>	<b><u>Jumper Module</u></b>
KG-S88G	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UVD1P	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV3D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV3X	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV6D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV6X	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV8D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV8H	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV9P	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV920P	SLUSBRJ4	SLCABRJ4	Jumper Wires
KG-UV950P	SLUSBRJ4	SLCABRJ4	Jumper Wires
KG-UV980P	SLUSBRJ4	SLCABRJ4	Jumper Wires
KG-659	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-669	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-669+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-679	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-679+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-816	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-819	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-689	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-689+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-699	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-1000G	SLUSBRJ4	SLCABRJ4	Jumper Wires

## XIEGU

<b><u>Radio</u></b>	<b><u>Signalink USB</u></b>	<b><u>Radio Cable Only</u></b>	<b><u>Jumper Module</u></b>
G90	SLUSB8PM (ACC)	SLCAB8PM (ACC)	SLMOD6PM
G106	SLUSB8PM (ACC)	SLCAB8PM (ACC)	SLMOD6PM
G1M	SLUSBTRS	SLCABTRS	Jumper Wires
X-1M	SLUSB847	SLCAB847	Jumper Wires
X-1MPRO	SLUSB847	SLCAB847	Jumper Wires
X-108G	SLUSB6PM (ACC)	SLCAB6PM (ACC)	Jumper Wires
X-5105	SLUSB8PM (ACC)	SLCAB8PM (ACC)	SLMOD6PM

# YAESU

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
FT-1	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-1D	SLUSBHTY	SLCABHTY	SLMODHT
FT-2DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-3DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-4XR	SLUSBHTX	SLCABHTX	SLMODHTX
FT-5DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-7B	SLUSB4R	SLCAB4R	SLMOD4RY
FT-50	SLUSBHTY	SLCABHTY	SLMODHT
FT-60	SLUSBHTY	SLCABHTY	SLMODHT
FT-60R	SLUSBHTY	SLCABHTY	SLMODHT
FT-65	SLUSBHTX	SLCABHTX	SLMODHTX
FT-70DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-77	SLUSB8R	SLCAB8R	SLMOD8RY
FT-80C	SLUSB8R	SLCAB8R	SLMOD8RY
FT-90	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-90R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	Jumper Wires
FT-100D	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	Jumper Wires
FT-101	SLUSB4R	SLCAB4R	SLMOD4RY
FT-101ZD	SLUSB4R	SLCAB4R	SLMOD4RY
FT-102	SLUSB8R	SLCAB8R	SLMOD8RY
FT-107	SLUSB8R	SLCAB8R	SLMOD8RY
FT-107M	SLUSB8R	SLCAB8R	SLMOD8RY
FT-221	SLUSB4R	SLCAB4R	SLMOD4RY
FT-225	SLUSB4R	SLCAB4R	SLMOD4RY
FT-227R	SLUSB4R	SLCAB4R	SLMOD4RY
FT-250R	SLUSBHTY	SLCABHTY	SLMODHT
FT-270R	SLUSBVXY	SLCABVXY	SLMODHT
FT-290	SLUSB8R	SLCAB8R	SLMOD8RY
FT-301	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301D	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301S	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301SD	SLUSB4R	SLCAB4R	SLMOD4RY
FT-450	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FT-450D	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FT-480R	SLUSB8R	SLCAB8R	SLMOD8RY
FT-600	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FT-707	SLUSB8R	SLCAB8R	SLMOD8RY
FT-710	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-726R	SLUSB8R	SLCAB8R	SLMOD8RY
FT-736	SLUSB8R	SLCAB8R	SLMOD8RY
FT-736R	SLUSB8R	SLCAB8R	SLMOD8RY
FT-747	SLUSB8R	SLCAB8R	SLMOD8RY

## YAESU (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
FT-757	SLUSB8R	SLCAB8R	SLMOD8RY
FT-757GX	SLUSB8R	SLCAB8R	SLMOD8RY
FT-767GX	SLUSB8R	SLCAB8R	SLMOD8RY
FT-817	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-817ND	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-818ND	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-840	SLUSB8R SLUSB6PM (DATA) <sup>3</sup>	SLCAB8R SLCAB6PM (DATA) <sup>3</sup>	SLMOD8RY SLMOD6PM
FT-847	SLUSB847 (DATA I/O) <sup>2</sup> SLUSB8R SLUSB6PM (DATA) <sup>3</sup>	SLCAB847 (DATA I/O) <sup>2</sup> SLCAB8R SLCAB6PM (DATA) <sup>3</sup>	SLMODHT SLMOD8RY SLMOD6PM
FT-857	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-857D	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-890	SLUSB8R	SLCAB8R	SLMOD8RY
FT-891	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-897	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-897D	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-900	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FT-901DM	SLUSB4R	SLCAB4R	SLMOD4RY
FT-920	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-950	SLUSB6PM (DATA) SLUSB8R	SLCAB6PM (DATA) SLCAB8R	SLMOD6PM SLMOD8RY
FT-980	SLUSB8R	SLCAB8R	SLMOD8RY
FT-990	SLUSB8R	SLCAB8R	SLMOD8RY
FT-991	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-991A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-1000	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1000D	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1000MP	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1000MPMKV	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1000MPMKVF	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1500M	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-1802	SLUSBRJ1	SLCABRJ1	SLMODR1Y

## YAESU (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
FT-1900R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2000	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-2200	SLUSB8R	SLCAB8R	SLMOD8RY
FT-2400	SLUSBRJ4	SLCABRJ4	Jumper Wires
FT-2500	SLUSBRJ4	SLCABRJ4	Jumper Wires
FT-2600M	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2800M	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2900R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2980R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-3000M	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-5100	SLUSB8R	SLCAB8R	SLMOD8RY
FT-7100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-7800R	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-7900R	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-8000	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8500	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8800R	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-8900R	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTDX10	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FTDX101D	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8R	SLCAB8R	SLMOD8RY
FTDX101MP	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX1200	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX3000	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX5000	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX5000D	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX5000MP	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
FT-DX9000	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FT-DX9000D	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FT-DX9000MP	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FTM-100DR	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
FTM-200DR	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
FTM-300	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y

## YAESU (continued)

<b>Radio</b>	<b>Signalink USB</b>	<b>Radio Cable Only</b>	<b>Jumper Module</b>
FTM-350	SLUSB6PM (DATA) <sup>5</sup>	SLCAB6PM (DATA) <sup>5</sup>	SLMOD6PM
	SLUSB8PM (DATA)	SLCAB8PM (DATA)	Jumper Wires
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-350R	SLUSB6PM (DATA) <sup>5</sup>	SLCAB6PM (DATA) <sup>5</sup>	SLMOD6PM
	SLUSB8PM (DATA)	SLCAB8PM (DATA)	Jumper Wires
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-350AR	SLUSB6PM (DATA) <sup>5</sup>	SLCAB6PM (DATA) <sup>5</sup>	SLMOD6PM
	SLUSB8PM (DATA)	SLCAB8PM (DATA)	Jumper Wires
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-400DE	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-400DR	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-400XDE	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-400XDR	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-500DE	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
FTM-500DR	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
FTM-3000M	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FTM-3100R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-3200DR	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-4100	SLUSBRJ4	SLCABRJ4	SLMODR4I
FTM-6000R	SLUSB6PM (DATA) <sup>4</sup>	SLCAB6PM (DATA) <sup>4</sup>	SLMOD6PM
FTM-7250DR	SLUSBRJ1	SLCABRJ1	SLMODR1Y
VX-1R	SLUSBHTY	SLCABHTY	SLMODHT
VX-2R	SLUSBHTY	SLCABHTY	SLMODHT
VX-3R	SLUSBHTY	SLCABHTY	SLMODHT
VX-5R	SLUSBHTY	SLCABHTY	SLMODHT
VX-6R	SLUSBVXY	SLCABVXY	SLMODHT
VX-7R	SLUSBVXY	SLCABVXY	SLMODHT
VX-110	SLUSBHTY	SLCABHTY	SLMODHT
VX-120	SLUSBVXY	SLCABVXY	SLMODHT
VX-150	SLUSBHTY	SLCABHTY	SLMODHT
VX-160	SLUSBHTY	SLCABHTY	SLMODHT
VX-170	SLUSBVXY	SLCABVXY	SLMODHT
VX-177	SLUSBVXY	SLCABVXY	SLMODHT
VX-230	SLUSBHTY	SLCABHTY	SLMODHT
VX-350	SLUSBHTY	SLCABHTY	SLMODHT
VX-410	SLUSBHTY	SLCABHTY	SLMODHT
VX-420	SLUSBHTY	SLCABHTY	SLMODHT
VX-420A	SLUSBHTY	SLCABHTY	SLMODHT
VX-8R	SLUSBHTY <sup>6</sup>	SLCABHTY <sup>6</sup>	SLMODHT
VX-8DR	SLUSBHTY <sup>6</sup>	SLCABHTY <sup>6</sup>	SLMODHT
VX-8RE	SLUSBHTY <sup>6</sup>	SLCABHTY <sup>6</sup>	SLMODHT
VX-8GR	SLUSBHTY	SLCABHTY	SLMODHT
VX-1700	SLUSB6PM	SLCAB6PM	SLMOD6PM
VX-2000U	SLUSBRJ4 <sup>7</sup>	SLCABRJ4 <sup>7</sup>	Jumper Wires

## YAESU (continued)

<u>Radio</u>	<u>Signalink USB</u>	<u>Radio Cable Only</u>	<u>Jumper Module</u>
VX-2100	SLUSBRJ4 <sup>7</sup>	SLCABRJ4 <sup>7</sup>	Jumper Wires
VX-2200	SLUSBRJ4 <sup>7</sup>	SLCABRJ4 <sup>7</sup>	Jumper Wires
VX-3000U	SLUSBRJ4 <sup>7</sup>	SLCABRJ4 <sup>7</sup>	Jumper Wires

## Footnotes:

1. This jack does NOT mute the microphone when it is in use. If you attach the Signalink to this jack then you will either need to turn down the radio's Mic Gain control, or disconnect the microphone to avoid having a ōhotō mic.
2. This jack is for HF use only. For VHF or UHF operation, you will need to attach the Signalink to a different jack on the radio.
3. This jack is for FM use only. It does NOT support USB/LSB operation.
4. Requires Yaesu's CT-164 adapter to convert from the radio's 10-pin mini-DIN connector to a standard 6-pin mini-DIN. This adapter should be available from any authorized Yaesu dealer.
5. Requires Yaesu's CT-141 adapter to convert from the radio's 8-pin mini-DIN connector to a standard 6-pin mini-DIN. This adapter should be available from any authorized Yaesu dealer.
6. Requires Yaesu's CT-131 adapter. This adapter should be available from any authorized Yaesu dealer.
7. This radio provides differential / balanced audio on the External Speaker jack. You must use an external isolation transformer when connecting this audio output to the Signalink or you could damage the radio.
8. The SLMOD6PM jumper module is for 1200 baud audio only on this radio. It does NOT support 9600 baud audio as it does with other radio brands. You MUST use jumper wires for 9600 baud audio ó Contact us for details.
9. Requires BTECH GMRS-PRO K1 Adapter Cable.
10. Your Signalink USB must have a ōREV 400ō circuit board or newer. This is required for radios that use both a TX Ctrl line and an RX Ctrl line. Earlier board revisions will not work with these radios.

## General Notes:

Where applicable, the Signalink USB supports PTT operation on the radio's Main/Primary band only. For proper operation on radios that offer a Sub/Secondary band, simply insure that the radio is set to Main/Primary.

CB / FRS / GMRS / MURS / MARINE radios are shown for informational purposes only. Digital mode operation, remote voice / repeater operation, RoIP and VoIP is legal in *some* countries on non-Ham bands. Tigertronics does not condone or support illegal radio operation, or provide legal advice. Legal operation of any radio is the sole responsibility of the end user. ***Consult your countries regulations / laws to be sure that your radio operation is legal!***