

Arcade Game Console Instructions

Make sure power button is on



This is the menu button




If the screen is in a game use the menu button to insert coins to play or exit from that game to go to another game. What the A, B, C etc. buttons do are listed at the bottom of each screen.

All games are accessed in the BYOG menu at the top of the home screen




Use the joystick to highlight BYOG then press A

Use the joystick to highlight ADDON X and press A



Use the joystick to access left side menu and choose ARCADE.



Use the joystick to move into the games section and choose your game. Once in the game you want use the menu key to insert coins. Have Fun!